











<p><b>Safety</b></p> <p>In order to ensure the phone is used safely and correctly, please read the precautions below carefully before use.</p> <p><b>1.1 General precaution</b></p> <ul style="list-style-type: none"> <li>Your phone is only suitable for the battery and charger approved by our company or else it may cause the battery to leak, overheat, explode or even catch fire.</li> <li>Do not knock, vibrate or throw the phone heavily to avoid malfunction, fire, overheating, explosion or fire.</li> <li>If there are abnormal phenomena, like temperature rising, color change or distortion during the usage, charging or storage of the battery, please stop using it and replace it with a new battery.</li> <li>It may burn the skin if liquid in the battery leaks onto skin or clothes. If this happens please flush with plenty of clean water immediately and go to a hospital at once.</li> <li>Please keep the battery away from fire to avoid fire and explosion if the battery leaks or emits a strange smell.</li> <li>Do not place exposed the battery to moisture or it may cause overheating, fumes and corrosion.</li> <li>Do not use or place the battery under direct sunlight, or in hot places as it may cause leakage and overheating, thus reducing performance and shortening the lifespan.</li> <li>Do not charge the battery for over 24 hours continuously.</li> <li>Use careful with the earphone maybe excessive sound pressure from earphones and headphones can cause hearing loss.</li> </ul> <p><b>1.2 Precaution for the use of charger</b></p> <ul style="list-style-type: none"> <li>Do not cause short circuit to the charger, or it may cause electric shock, fumes and damage to the charger.</li> <li>Do not use the charger if the power wire is broken, or it may cause fire and electric shock.</li> <li>Please remove accumulated dust on the power plug.</li> <li>Do not put water containers next to the power supply to avoid overheating, fire, electric shock and malfunction in case they come into contact.</li> <li>Do not disassemble or tamper with the charger or it may cause personal injury, electric shock, fire and the damage of the charger.</li> <li>Do not use the charger in places of high humidity, like bathrooms, or it may cause electric shock, fire and damage of charger.</li> <li>Do not touch the charger, power cord or power plug with wet hands; or it can cause electric shock.</li> <li>Do not put heavy objects on the power cord or changing the power cord or it may cause electric shock and fire.</li> <li>Please unplug the power socket before cleaning and maintenance.</li> <li>Please hold the charger to unplug the socket as pulling the power cord may damage the power wire and cause electric shock and fire.</li> </ul>	<p><b>1.3 Cleaning and maintenance</b></p> <ul style="list-style-type: none"> <li>As the phone, battery and charger are not waterproof, do not use them in places of high humidity and avoid them being wet by rain.</li> <li>Please clean the battery and charger with a soft dry cloth.</li> <li>Never use alcohol, thinner or solvents, like benzene, to wipe the phone, or else it may cause the battery to leak, overheat, explode or even catch fire.</li> <li>Dirty sockets can cause poor contact and power down, and even make recharging unavailable. So, please clean them periodically.</li> </ul> <p><b>1.4 Common Precaution</b></p> <p><b>Mobile Phone</b></p> <ul style="list-style-type: none"> <li>Please use the phone in an environment with temperature between -10°C-40°C and humidity of &lt;math&gt;\leq 75\%&lt;/math&gt;.</li> <li>Please use the phone far away from regular telephones, TV sets, radio sets and office automation equipment, to avoid affecting the normal use of these equipments and mobile phone.</li> </ul> <p><b>Battery</b></p> <ul style="list-style-type: none"> <li>Store the battery in cool and ventilated place without direct sunlight.</li> <li>The battery has a limited lifespan. The usage of battery will be shortened progressively due to frequent charging. Once the battery is out of use, it means that its lifespan has ended, and you will need to replace it with an approved new battery.</li> <li>Do not dispose of old batteries as household waste. Give them to specified disposal places and follow any stipulated instructions for disposal.</li> </ul> <p><b>CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.</b></p> <p><b>Charger</b></p> <ul style="list-style-type: none"> <li>Do not charge under following conditions: <ul style="list-style-type: none"> <li>places with direct sunlight</li> <li>places with ambient temperature less than -10°C or over 40°C, wet or dusty places with strong vibrations (it may cause malfunction);</li> <li>places near electrical appliances (it may affect the image and sound) like TV set, radio, etc.</li> </ul> </li> <li>Adapter shall be installed near the equipment and shall be easily accessible. The plug considered as disconnect device of adapter.</li> </ul> <p><b>Environmentally friendly design</b></p> <p>Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The presence of old appliances is considered as being the equivalent to these collecting points in certain collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of our substances.</p> 	<p><b>Getting to know your touch phone</b></p>  <ol style="list-style-type: none"> <li>1 Front camera</li> <li>2 Volume key</li> <li>3 Power on/off key</li> <li>4 Menu key</li> <li>5 Home key</li> <li>6 Back key</li> </ol>  <ol style="list-style-type: none"> <li>7 Back camera/Flash light</li> <li>8 Back camera/Flash light</li> </ol>	<p><b>Starting up the device</b></p> <p><b>To install the SIM card</b></p> <ul style="list-style-type: none"> <li>Open the SIM card slot and Memory card rubber.</li> <li>Locate the SIM card slot, and then insert the SIM card with its gold contacts facing up.</li> </ul> <p><b>Note: The phone supports one SIM card. The card will support 3G card and 2G card. If you need to use 4G/3G operation, please insert a 4G/3G card in the card slot.</b></p> <p><b>To install a memory card</b></p> <ul style="list-style-type: none"> <li>Open the Memory card slot, and then insert the Memory card with its gold contacts facing up.</li> <li>Locate the Memory card slot, and then insert the Memory card with its gold contacts facing up.</li> </ul> <p><b>Charging the Battery</b></p> <p>New batteries are shipped partially charged. Before you start using your device, it is recommended that you install and charge the battery. Some batteries perform best after several full charge/discharge cycles.</p> <p>Note: Only the AC adapter and USB sync cable provided with your device must be used to charge the device.</p> <p>Connect the USB connector of the AC adapter to the sync connector on your device, and then plug in the AC adapter to an electrical outlet to start charging the battery.</p> <p>As the battery is being charged while the device is on, a charging icon appears in the title bar of the Home screen. After the battery has been fully charged, a full battery icon appears in the title bar of the Home screen.</p> <p>Warning:</p> <ul style="list-style-type: none"> <li>Do not remove the battery from the device while you are charging it using the AC or car adapter.</li> <li>As a safety precaution, the battery stops charging before it overheats.</li> </ul> <p><b>Power on/off</b></p> <p>To power off your phone, press &amp; hold <b>POWER</b>. On release, the Phone options menu opens. Select <b>Power off</b> and confirm.</p> <p>To power on again, press &amp; hold <b>POWER</b>.</p>	<p><b>SAR</b></p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <p>(1) This device may not cause harmful interference.</p> <p>(2) This device must accept any interference received, including interference that may cause undesired operation.</p> <p><b>NOTE:</b> Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p><b>NOTE:</b> This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</p> <p>If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> <li>Reorient or relocate the receiving antenna.</li> <li>Increase the separation between the equipment and receiver.</li> <li>Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</li> <li>Consult the dealer or an experienced radio/TV technician for help.</li> </ul> <p><b>Body-worn Operation</b></p> <p>This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 1.5cm must be maintained between the user's body and the handset, including the antenna.</p> <p>Third-party belt-clip, holsters, and similar r or ar of the antenna. This may affect the performance of the antenna.</p> <p>Do not use the phone, press &amp; hold <b>POWER</b>. On release, the Phone options menu opens. Select <b>Power off</b> and confirm.</p> <p>To power on again, press &amp; hold <b>POWER</b>.</p>	<p>This Model Meets International Guidelines for Exposure to Radio Waves.</p> <p>Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.</p> <p>The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 1.6 W/kg and the highest SAR value for this device when tested at the ear was 0.7 W/kg per 10 gram of tissue. As mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this user guide. It is recommended to keep it away from your body at least 10cm during operation, but the distance of 10cm between the head and the device.</p> <p>As SAR is measured utilizing the devices highest transmitting power the actual SAR of this device while operating is typically below that indicated above. This is due to automatic changes to the power level of the device to ensure it only uses the minimum level required to reach the network.</p> <p>The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. They note that if you want to reduce your exposure then you can do so by limiting the length of calls or using a hands-free device to keep the mobile phone away from the head and body.</p> <p>Additional information can be found on the websites of the World Health Organization (<a href="http://www.who.int/emf">http://www.who.int/emf</a>).</p>		
---	--	--	--	--	--	--	--

<p><b>1. Switch Main Menu style</b></p> <p>(1) In default Home screen, slide your fingertip left and right along the screen to reveal the more home screen.</p>  <p>(2) On Home screen, click icon on the bottom of the screen (Main menu icon) to enter the main menu screen, slide your fingertip left and right along the screen to reveal the more applications.</p> 	<p><b>2. Home screen</b></p> <p>(1) Read your notifications</p> <p>When you see a notification in the status bar, touch the bar and slide your finger down the screen to open the list of notifications displayed in the sliding window.</p> <p>Notifications report activities such as call forwarding ON, current call status, song playing.</p> <p>Notifications report the arrival of new messages, calendar events, and alarms. You can clear notifications by selecting "Clear" notifications at the top of the notifications window.</p> <p>To open the message, reminder or other notification, you can touch the items. To close the notifications window, slide your finger up the screen.</p> <p>(2) Create Home screen shortcuts and widgets.</p> <p>From the Home screen, touch and hold the blank screen, and select "Widgets". Enter the main menu screen, slide your fingertip left to reveal the widget, select a shortcut to some of your saved information (such as a play list), a widget (a clock) for your Home screen.</p>  <p>(3) Move objects on the Home screen</p> <ul style="list-style-type: none"> <li>To move an icon or other item on the Home screen, you must first touch &amp; hold it to enter move mode. The object will magnify when it's ready to be moved.</li> <li>Without lifting your finger (or you'll drop out of move mode), drag the object to the new position. To move an item to a section of the Home screen not in view, move it to the edge of the screen and hold it there for a moment. The screen view will shift; position the object and release.</li> </ul>	<p><b>3. Camera</b></p> <p>All the pictures you can capture or view on your phone are stored on a memory card, which is the phone storage or the installed SD card in your phone. Before you use the Camera or view pictures in Gallery, make sure you have a card installed.</p>  <p><b>4. GPRS/WLAN network</b></p> <p>Your device's networking capabilities allow you to access the Internet or your corporate network through WLAN, GPRS, or WCDMA (if SIM card supported).</p> <p>You can also add and set up a VPN or proxy connection.</p> <p>To use WLAN on your device, you need access to a wireless access point or "hotspot".</p> <p>Note: The availability and range of your device's WLAN signal depends on the number, infrastructure, and other objects through which the signal passes.</p> <p>To open the Browser you need to be connected to a network.</p> 	<p><b>5. U-disk storage</b></p> <p>This phone supports movable storage, i.e., the U-disk function.</p> <p>When the phone is switched on, you can use the icon in the status bar on the top of the screen when it's connected to a PC by a data line. Touch the bar and slide your finger down the screen to open the list of notifications displayed in the sliding window. Select [USB connected] and touch [Turn on USB storage] to confirm, then you can use the phone as a U-disk.</p> <p>The product shall only be connected to a USB interface of version USB2.0.</p> 	<p><b>7. Bluetooth</b></p> <p>The phone supports Bluetooth(BT) functions, you can establish a wireless connection between the phone with other compatible devices, and data transmission. You can establish a wireless connection between devices in the phone with a distance of up to 10 meters. Bluetooth connection may be interference by obstacles, such as walls or other electronic device.</p> <ol style="list-style-type: none"> <li>Enter the setting menu. Touch the Bluetooth to open the function, side screen will display BT icon in the status bar.</li> <li>Open the BT discoverable, and other devices can search the phone.</li> <li>Before using the phone as a Bluetooth device, you need to pair the phone with the target device as follows: <ul style="list-style-type: none"> <li>Make sure your phone has Bluetooth-enabled.</li> <li>Touch "Scan for devices". Bluetooth devices within the range of the phone will start scanning.</li> <li>Touch the device you want to pair, to confirm password to complete the pairing.</li> <li>You can use Bluetooth to share the pictures, videos or music files with family and friends.</li> </ul> </li> </ol>	<p><b>9. FM radio</b></p> <p>The phone supports FM radio, but you need an earphone as antenna. Please plug in earphone before searching for channels.</p> 	<p><b>Technical Specification</b></p> <p>Weight: 111.5g (including battery)</p> <p>Dimensions: 121*48*16.6mm</p> <p>Band: GSM900MHz/GPRS1800MHz/UMTS850MHz/PCS1900MHz/WCDMA1900MHz/WCDMA3500MHz</p> <p>Battery Type: Li-Ion</p> <p>Battery Voltage: 4.2V</p> <p>Battery Capacity: 1400mAh</p> <p>Talk Time: about 7.5h</p> <p>Standby Time: about 300h</p> <p>Battery Time (No prior or separate notice is required for capacity changes)</p> <p>Note: Actual operating conditions depend on the local network environment, SIM, and user behavior.</p> <p>Warning: Any consequences caused by misuse, abuse, or not following any and all of the above-written suggestions and instructions shall not hold the producer in any way responsible to any degree.</p> <p>Announcement: The manufacturer reserves the right to change or upgrade specifications or software versions without prior or separate notice. Trade marks mentioned or used in this material belong to their respective owners.</p>	
---	--	---	---	--	---	--	--

### **§ 15.19 Labelling requirements.**

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

**§ 15.21 Information to user.** Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**§ 15.105 Information to the user. Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **Body-worn Operation**

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of **1.0 cm** must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.