



**MPOW**  
MODEL: BH142A




**Wireless Headset**  
FOR MORE INFORMATION PLEASE VISIT  
• <https://www.xmpow.com/>

H1

**1 Packages**




**2 Diagram**



**3 How To Use**  
WIE MAN BENUTZT  
MOYEN DE L' UTILISATION  
MODALITÀ DI UTILIZZARE

**Step1:**




Long press it for 4 seconds to enter the pairing mode. Meanwhile, the red and blue indicator lights flash alternately. Turn on the Bluetooth of the mobile phone, search the Bluetooth device and find "Mpow H1" in the list to connect it. When it doesn't connect to the Bluetooth device of the phone, it will power off automatically after 10 minutes. Voice Dial: Continuously double press it to enter voice dial.

Drücken Sie es nochmals lange für 4 Sekunden, um in den Pairing-Modus zu gelangen. Inzwischen blinken die roten und blauen Kontrollleuchten abwechselnd. Schalten Sie das Bluetooth des Mobiltelefons ein, suchen Sie das Bluetooth-Gerät und finden Sie "Mpow H1" in der Liste, um es zu verbinden. Wenn es nach Einschalten nicht an dem Bluetooth-Gerät des Telefons verbindet, schaltet es sich in zehn Minuten automatisch aus.

Appuyer longuement pendant 4 secondes pour entrer dans le mode d'appairage. Pendant ce temps, les voyants rouge et bleu clignotent alternativement. Allumez le Bluetooth du téléphone mobile, recherchez le périphérique Bluetooth et trouvez "Mpow H1" dans la liste pour le connecter. Lorsqu'il ne se connecte pas à aucun équipement Bluetooth, il s'éteint automatiquement en dix minutes.


Premere a lungo per 4 secondi per accedere alla modalità di collegamento. Nel frattempo, le spie rosso e blu lampeggiano alternativamente. Accendete il Bluetooth del cellulare, cercate il dispositivo Bluetooth e trovate "Mpow H1" nella lista per collegarlo. Quando non si connette al dispositivo Bluetooth del telefono, si spegne automaticamente in dieci minuti.

**Step2:**




**4 Play/ Pause/ Make a Call/ Answer a Call/ Hang up a Call/ Reject a Call**

- ▶ Abspielen / Anhalten / Anrufen / Anruf Annehmen/ Anrufauflegen / Anruf abwetsen
- ▶ Reproducir / Pausa / Hacer Una Llamada / Responder Una Llamada / Colgar Una Llamada / Rechazar Una Llamada
- ▶ Riproduci / Pausa / Effettuare una chiamata / Rispondere a una chiamata / Terminare una chiamata / Rifutare unachiamata
- ▶ Lecture/Pause/Appel/ Répondre à un Appel / Raccrochez un Appel / Rejeter un Appel
- ▶ 再生/一時停止/電話をかける/電話を受ける/電話を切る/電話を拒否する



**5 Clearing Pairing Information**


- ▶ Löschen der Kopplungsinformationen
- ▶ Borrar la Información de Emparejamiento
- ▶ Cancellazione delle Informazioni di Accoppiamento
- ▶ Supprimer des informations d'appariement
- ▶ ペアリング情報を削除する



**6 Volume Control /Music Control**

- ▶ Lautstärkeregelung / Musiksteuerung
- ▶ Control de Volumen / Control de la Música

**7 Charge Battery**




Output DC 5V adapter

4H

**8 Controllo di Volume / controllo di Musica**

**9 Contrôle du Volume / Contrôle de la Musique**

**10 音量調整/音楽調整**



**NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:**

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.