


We are appreciate for purchasing our new Mpow H3 product. This guide contains instructions for setting up and using your Mpow H3 easily. ① Package X1 X1 ② <u>Diagram</u> ANC... - III- M4

**5**5

Werkseinstellungen wiederherstellen

(L) 2.5H

**|||||| \* → •** 



Long press for 4 s until the red and blue indicator lights flash quickly. When you complete the pairing, you'll hear a voice prompt and search.


Bluetooth devices and select "Mpow H3" to connect.

Lang für 4 Sekunden drücken, bis die rote und blaue Anzeigeleuchte schnell abwechselnd blinkt. Wenn Sie die Kopplung abgeschlossen haben, hören Sie eine Sprachansage suchen Sie Bluetooth-Geräte und wählen Sie "Mpow H3", um eine Verbindung herzustellen.

bleu clignotent rapidement. Lorsque vous avez terminé l'appariement, vous entendez une invite vocale. Recherchez des appareils Bluetooth et sélectionnez "Mpow H3" pour connecter.

Mantenga presionado durante 4 s hasta que las luces indicadoras rojas y azules parpadeen rápidamente. Cuando complete el emparejamiento, escuchará un mensaje de voz. Busque dispositivos Bluetooth y selectione "Mpow H3" para conectarse.





(5) Restore Factory Defaults

## Ecc Statement

Operation is subject to the following three conditions:

- (3) This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

- Reorient or relo cate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.