

### \*\*\*IR remote Auto Learn Mode.

For use when your Set Top Box is not listed in PRESETS.

- 1) Start with the CableSAT Receiver power disconnected.
- 2) Using a pen or paperclip, press and hold the "PGM" switch.
- 3) Connect power to CableSAT Command Receiver.
- 4) Hold in the "PGM" switch until the "power" and "learn" LEDs are solid.
- 5) Release the "PGM" switch. Transmitter is now in AUTO LEARN mode.
- 6) Point the TV's IR remote control at the red IR window on the side panel of the CableSAT Receiver.
- 7) Begin by pressing the Channel Up key on the remote control.
- 8) The learn LED will flicker and the Programmed LED will light solid once the command has been learned. The learn LED will then light solid again.
- 9) Press the Channel Down key on the remote control.
- 10) Again the Learn LED will flicker and the Programmed LED will light solid once the command has been learned. Learn LED will light solid again.
- 11) Press the following keys in succession. Be sure to wait for the Learn and Program LED to light up as each key is learned.
- 12) Press: 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, and "Enter" on the remote.
- 13) Once this is complete, All LEDs will flash briefly to indicate that the CableSAT receiver is programmed and ready for use.

\*\*\*\*A red ERROR light means there was a problem learning the IR remote. Remove power from the receiver and start again.

#### FCC COMPLIANCE STATEMENT MYE Entertainment CableSAT MWCS-T

This device complies with Part 15 of the FCC Rules.

Operation of this device is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment has been verified to comply with the limits for a Class B computing device, pursuant to the FCC Rules. Operation with non-approved equipment is likely to result in interference to radio and TV reception. The user is cautioned that changed and modifications made to the equipment without the approval of the manufacturer could void the user's authority to operate this equipment.

#### LIMITED WARRANTY

MYE ENTERTAINMENT (MYE) WARRANTS ALL NEW MYE PRODUCTS TO BE FREE FROM DEFECTS IN MATERIALS AND MANUFACTURERS FOR THE WARRANTY PERIODS SET FORTH BELOW. THE WARRANTY PERIOD COMMENCES ON THE ORIGINAL DATE OF THE ORIGINAL PURCHASE. THIS WARRANTY APPLIES ONLY AGAINST DEFECTS DISCOVERED WITHIN THE WARRANTY PERIOD AND EXTENDS ONLY TO THE ORIGINAL PURCHASER OF THE PRODUCT. PARTS REPAIRED OR REPLACED UNDER THE TERMS OF THIS WARRANTY WILL BE WARRANTED FOR THE REMAINDER OF THE ORIGINAL WARRANTY PERIOD ONLY. TO CLAIM UNDER THIS WARRANTY, THE BUYER MUST NOTIFY MYE OR YOUR AUTHORIZED MYE ENTERTAINMENT DEALER WITHIN 30 DAYS AFTER THE DATE OF DISCOVERY OF ANY NONCONFORMITY AND MAKE THE AFFECTED PRODUCT AVAILABLE FOR INSPECTION BY MYE ENTERTAINMENT OR ITS SERVICE REPRESENTATIVE. MYE ENTERTAINMENT PRODUCTS DEEMED DEFECTIVE BY A MYE ENTERTAINMENT REPRESENTATIVE WILL BE ISSUED A RETURN AUTHORIZATION NUMBER. MYE ENTERTAINMENT WILL NOT ACCEPT RETURNS WITHOUT A RETURN AUTHORIZATION NUMBER. MYE ENTERTAINMENT RESERVES THE RIGHT, AT THEIR OPTION, TO REPAIR OR REPLACE THE PRODUCT AFTER VERIFICATION OF DEFECT. PRODUCT THAT FAILS AFTER THE WARRANTY PERIOD EXPIRES WILL BE REPAIRED OR REPLACED AT THE CURRENT PART AND LABOR PRICING AFTER AUTHORIZATION FROM THE CUSTOMER. REPAIRS ARE WARRANTED FOR 90 DAYS. MYE ENTERTAINMENT'S OBLIGATIONS UNDER THIS WARRANTY ARE LIMITED AS SET FORTH BELOW:

WARRANTY PERIOD AND COVERAGE: 2 YEARS (REPAIR OR REPLACEMENT AND ONE WAY SHIPPING)

#### CONDITIONS AND RESTRICTIONS:

THE WARRANTY APPLIES TO THE MYE ENTERTAINMENT PRODUCT ONLY 1) WHILE IT REMAINS IN THE POSSESSION OF THE ORIGINAL PURCHASER AND PROOF OF PURCHASE IS DEMONSTRATED. 2) IT HAS NOT BEEN SUBJECT TO ACCIDENT, MISUSE, ABUSE, IMPROPER SERVICE, MECHANICAL OR ELECTRICAL NON-MYE ENTERTAINMENT AUTHORIZED MODIFICATION. 3) CLAIMS MADE WITHIN THE WARRANTY PERIOD. THIS WARRANTY DOES NOT COVER DAMAGED OR FAILURE CAUSED BY ELECTRICAL WIRING NOT BEING IN COMPLIANCE WITH ELECTRICAL CODES OR MYE'S OWNER MANUAL SPECIFICATIONS.

WARRANTIES OUTSIDE THE U.S. AND CANADA MAY VARY.

LIMITED WARRANTY SHALL NOT APPLY TO:

- 1) SOFTWARE UPGRADES.
- 2) NORMAL WEAR AND TEAR, CONSUMABLES AND COSMETIC ITEMS INCLUDING BUT NOT LIMITED TO LABELS.
- 3) REPAIRS PERFORMED ON MYE PRODUCTS MISSING A SERIAL NUMBER OR WITH A SERIAL TAG THAT HAS BEEN ALTERED, RETACHED OR DEFACED.
- 4) SERVICE CALLS TO CORRECT INSTALLATION OF THE PRODUCT OR INSTRUCT OWNERS ON HOW TO USE THE PRODUCT.
- 5) PICK UP AND DELIVERY INVOLVING REPAIRS.
- 6) ANY LABOR COSTS INCURRED BEYOND THE APPLICABLE LABOR WARRANTY PERIOD.
- 7) THE USER IS CAUTIONED THAT CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE MANUFACTURER OF THE PRODUCT COULD VOID THE USER'S AUTHORITY TO OPERATE THE PRODUCT.

THE WARRANTIES PROVIDED HEREIN ARE THE EXCLUSIVE WARRANTIES GIVEN BY MYE ENTERTAINMENT AND SUPERSEDE ANY PRIOR, CONTRARY OR ADDITIONAL REPRESENTATIONS, WHETHER ORAL OR WRITTEN. ANY IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE THAT APPLY TO ANY PARTS DESCRIBED IN ABOVE ARE LIMITED TO THE PERIOD OF EXPRESS WARRANTIES GIVEN ABOVE FOR THOSE SAME PARTS. MYE HEREBY DISCLAIMS AND EXCLUDES THOSE WARRANTIES THEREAFTER. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. MYE ENTERTAINMENT ALSO HEREBY DISCLAIMS AND EXCLUDES ALL OTHER OBLIGATIONS OR LIABILITIES, EXPRESS OR IMPLIED, ARISING BY LAW OR OTHERWISE, WHETHER RESULTING FROM NON-DELIVERY OR FROM THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. THIS EXCLUSION APPLIES EVEN IF THE ABOVE WARRANTY FAILS OF ITS ESSENTIAL PURPOSE. RIGHT, CLAIM OR REMEDY IN TORT, WHETHER OR NOT ARISING FROM THE NEGLIGENCE OF MYE OR ITS SUPPLIERS (WHETHER ACTIVE, PASSIVE OR IMPLIED), OBLIGATION, LIABILITY, RIGHT, CLAIM OR REMEDY FOR LOSS OF OR DAMAGE TO ANY PRODUCT. THIS DISCLAIMER AND RELEASE SHALL APPLY EVEN IF THE EXPRESSED WARRANTY SET FORTH ABOVE FAILS OF ITS ESSENTIAL PURPOSE. FOR ANY PRODUCT DESCRIBED ABOVE THAT FAILS TO CONFORM TO ITS WARRANTY, MYE ENTERTAINMENT WILL PROVIDE, AT THEIR OPTION ONE OF THE FOLLOWING: 1) REPAIR, 2) REPLACEMENT OR 3) REFUND OF THE PURCHASE PRICE.

MYE AND/OR ITS SUPPLIERS SHALL HAVE NO OBLIGATION OR LIABILITY, WHETHER ARISING IN CONTRACT (INCLUDING WARRANTY), TORT (INCLUDING ACTIVE, PASSIVE, OR IMPLIED NEGLIGENCE AND STRICT LIABILITY), OR OTHERWISE, FOR DAMAGE TO THE PRODUCT, PROPERTY DAMAGE, LOSS OF USE, REVENUE OR PROFIT, COST OF CAPITAL, COST OF SUBSTITUTE PRODUCT, ADDITIONAL COSTS INCURRED BY BUYER (BY WAY OF CORRECTION OR OTHERWISE) OR ANY OTHER INCIDENTAL, SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, WHETHER RESULTING FROM NON-DELIVERY OR FROM THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. THIS EXCLUSION APPLIES EVEN IF THE ABOVE WARRANTY FAILS OF ITS ESSENTIAL PURPOSES AND REGARDLESS OF WHETHER SUCH DAMAGES ARE SOUGHT FOR BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE OR STRICT LIABILITY IN TORT OR UNDER ANY OTHER LEGAL THEORY. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.



## MWCS-AT9-MYA

### MYE 900MHz (Wireless) CableSAT



For model: MWCS-T

MYE Entertainment, Inc.

1-661-964-0217

www.myeclubtv.com

MYE Entertainment, Inc. All Rights Reserved 2016



## Transmitter Installation

1. Remove any rear cover or shroud and expose the TV's connections.
2. Locate the RJ45 port on the rear panel labeled "CableSAT."
3. Remove the CableSAT RJ45 dust plug.
4. Plug one end of the MCC-X cable into the CableSAT port on the back of the TV.
4. Plug the other end of the MCC-X cable into the CableSAT "Control IN" port.
6. Test. The "B" light should flash briefly for each keypress.
7. Peel off the Velcro backing and install the CableSAT transmitter.
7. Reinstall any rear covers or shrouds.



Control of channel up / down and direct channel access is dependent on model of TV and the manufacturer's console being installed on.

## Receiver Installation

Connecting the receiver to a SET TOP BOX can be achieved by one of these two options.

- OPTION 1:** PLUG THE MWCS-IR EMITTER CABLE INTO THE RECEIVER AND ATTACHED THE EMITTER TO THE SET TOP BOX IR WINDOW.
- OPTION 2:** ALIGN THE RECEIVER'S IR WINDOW WITH THE SET TOP BOX IR WINDOW.



Once the receiver is installed you can select your Set Top Box (below).

\*Unit is shipped in AT&T mode. Match the lit LEDs to your Set Top Box type.

- 1) Start with the CableSAT Receiver power disconnected.
- 2) Using a pen or paperclip, press and hold the "PGM" switch.
- 3) Connect power to CableSAT Command Receiver.
- 4) Hold in the "PGM" switch until the "power" and "learn" LEDs are solid.
- 4) Release the "PGM" switch. Transmitter is now in AUTO LEARN mode.
- 5) Press and release the switch a 2<sup>nd</sup> time.
- 6) All LEDs will light briefly, followed by the Power LED. This indicates you are now in the set top box series of Presets.
- 7) To select one of the set top boxes listed press the "PGM" switch to cycle through the Presets. Set Top Boxes are represented in the chart below.
- 8) Once the desired set top box is displayed, press and hold the "PGM" switch until the red "error" LED turns solid.
- 9) Release the "PGM" key. All LEDs will flash briefly to indicate the CableSat Receiver is programmed and ready for use.

	LED	LEARN MODE	LEARNED COMMANDS	AT&T	COMCAST	DIRECTV	VERIZON, RCN, GRANDE, MEDIACOM, ROGERS CHARTER (ARRIS)	TIME WARNER, COX, WOW, BRIGHT HOUSE, CABLEVISION, OPTIMUM, CHARTER (CISCO)	DISH, BELL CANADA	COX MINI BOX
1	POWER	●	●		●		●		●	
2	LEARN	●		●	●			●	●	
3	PROGRAMMED					●	●	●	●	
4	ERROR									●