

# iDynamo6 Installation and Operation Manual



September 2018

Version 001

## **Content**

1	Installation Guide .....	2
2	Operation Guide.....	3

3	Transactions Guide.....	4
---	-------------------------	---

## 1. Installation Guide

The terminal is dedicated for the iPhone. And it can be used when an additional lightning adaptor cable is used. To install the terminal, follow the steps below.

- 1、 Press the iDynamo 5 Gen 2 main body, lock the 2 parts.



## 2 Operation Guide

To use a MSR card

To swipe card, make sure the MSR is on the bottom side, press the card to the bottom of the slot and swipe it.



## 3 TransactionsGuide

Refer to the guide of the software. Operate as the instrument of the iPhone/other host device.

## **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.