

PPVN

Quick Install Guide






VIANET PRECISION PANEL

Applicaton: Provides power and ViaNet to and IR from four TS2s.

Connects to the ViaNet port on a rack mounted Home Controller or to the ViaNet punchdown of a PPCM when using can mounted controllers.

Location: Head-end

Wiring Basics: Cat5 connects to TS2s located in zones as well as to additional PPVNs and/or PPCM. Cat5 jumper from RJ-45 to PPWM.



Sample System Layout

