



Dora's R/C Jeep WRANGLER

Works best with "Everyday Dora" doll

Press the arrows on the cell phone remote control to steer Jeep WRANGLER® backward and forward.



NICK JR.
Play to Learn with Nick Jr.!

Nick Jr.'s Play to Learn philosophy revolutionized the way kids learn on TV. Our shows encourage them to think, explore, problem solve, master cognitive skills, and boost self-esteem - all while playing along with characters they love.

are, commitment, and play that we put into Nick Jr. Learning also goes into our products. So when your child plays along with their favorite friends, they're learning to LEARN!



Not suitable for children under 36 months - Small parts may be generated.



Jeep® and the Jeep® grille design are registered trademarks of the DaimlerChrysler Corporation. Jeep® Wrangler® and its trade dress are used under license from DaimlerChrysler. ©DaimlerChrysler Corporation 2006.

This product is not recommended for use on loose dirt or wet surfaces. Do not immerse in water.

www.fisherprice.com

COLORS AND DECORATIONS MAY VARY.



Mattel Canada
Mississauga, Ontario L5R
Mattel East Asia Ltd., Room
South Tower, World Finance C
Harbour City, Tsimstansui, HK, C
Made in C

©2006 Viacom International Inc.
 All Rights Reserved. Nickelodeon, Nick Jr., Dora the Explorer
 and all related titles, logos and characters are trademarks of
 Viacom International Inc.
 Fisher-Price, Inc., a subsidiary of Mattel, Inc.,
 East Aurora, NY 14052 U.S.A.
MADE IN CHINA.

Manufactured for Fisher-Price.
 ©2006 Mattel, Inc. All Rights Reserved.
 Fisher-Price and the Fisher-Price logo are
 U.S. trademarks of Mattel, Inc.

CONFORMS TO THE SAFETY REQUIREMENTS OF ASTM F963.

Packaging and address should be retained for future reference.
 Mattel Canada Inc., Mississauga, Ontario L5R 3W2.
 Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB.
 Mattel Australia Pty., Ltd., Richmond, Victoria 3121-
 Consumer Advisory Service 1300 135 312 (Valid only in Australia).
 Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre,
 Harbour City, Tsimshatsui, HK, China.
 Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd. (993532-P) Lot 13.5,
 Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ.
 Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 U.S.A.

BATTERY SAFETY INFORMATION

In exceptional circumstances batteries may leak fluids that
 can cause a chemical burn injury or ruin your toy (product).

To avoid battery leakage;

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being
 charged (if designed to be removable).
- Rechargeable batteries are only to be charged under adult supervision
 (if designed to be removable).
- Do not mix alkaline, standard (carbon-zinc), or rechargeable
 (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as
 recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product.

- The supply terminals are not to be short-circuited.
- Dispose of battery(ies) safely.
- Do not dispose of this product in a fire. The batteries inside
 may explode or leak.



For longer life use only alkaline batteries.
 Requires 4 "C" (LR14) & 1 "9-Volt" (6 LR61) batteries.

BATTERY INSTALLATION:

Please keep these instructions for future reference
 as they contain important information.



Unscrew and lift cover away
 from bottom of product.
 Install batteries as shown.



This equipment has been tested and found to comply with the limits for a
 Class B digital device, pursuant to part 15 of the FCC rules. These limits are
 designed to provide reasonable protection against harmful interference in a
 residential installation. This equipment generates, uses and can radiate radio
 frequency energy and, if not installed and used in accordance with the
 instructions, may cause harmful interference to radio communications.
 However, there is no guarantee that interference will not occur in a particular
 installation. If this equipment does cause harmful interference to radio or
 television reception, which can be determined by turning the equipment off
 and on, the user is encouraged to try to correct the interference by one or
 more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which
 the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Mattel Inc. 333 Continental Blvd. El Segundo, CA (310) 252-2400
 NOTE: Changes or modifications not expressly approved by the
 party responsible for compliance could void the user's authority to
 operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to
 the following two conditions:
 (1) This device may not cause harmful interference, and (2) this device must
 accept any interference received, including interference that may cause
 undesired operation.



Protect the environment by not disposing of
 this product with household waste
 (2002/96/EC). Check your local authority for
 recycling advice and facilities (Europe only).



Questions?
service.fisher-price.com
 In US and Canada
 1-800-432-5437

K3422

