



Quick Start Guide

1. Power ON the Unimax Router and connect to a computer using the ethernet cable provided.
2. Open internet browser (Internet Explorer for Windows and Safari for Mac).
3. Type <http://192.168.0.1> default IP of Unimax in the address bar.
4. Enter username and password in the pop-up window that prompts for login details. Username and password is "admin" by default.
5. Web interface of Unimax will come up with connection status and device information. Once logged into the Unimax, settings can be customised to suit your needs or applications.

For more information and documentation please refer to the User Guide in Help section of the web interface of the Unimax or visit <http://www.maxon.com.au/unimax-hspa+.php>

For further queries please contact Maxon Australia's support team on +612 8707 3000 or visit www.maxon.com.au