Multi Media Card Reader

OWNER'S MANUAL

maycom Co., Ltd.
www.emaycom.com

▪ Model: UR-1000 ▪

Information to user : Part 15, Paragraph 15.21 and 15.105(b)
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

FCC Notice

NOTE : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

UR-1000 Reader

The UR-1000 which is being supplied with maycom MP3 player is a MMC card reader to download the MP3 file form the PC(or Mac.) which has USB port.

- Contents -

Package

UR-1000 Card Reader

Install CD

Installing in Windows XP

1) After booting OS, insert the CD-ROM into your CD-ROM drive.

2) After connecting UR-1000 card reader to your USB port,
   select "install the software automatically" and click
"next".

3) Like below picture, the Windows XP should be displayed
   correctly in installed CD-ROM.

4) During processing installation, if it show the certification
   like below picture click the "Continue Anyway" to proceed.

5) On the picture as follow, click "finish" and complete the
   driver installation.

6) If you open searcher, there is moveable disk.

Using MMC card

1) Connect UR-1000 card reader to the PC.
   (Refer to the former page about installation.)

2) Insert MMC card to UR-1000 card reader.

3) Check the moveable disk in searcher of Windows.

Windows XP	Removable(E:)

Other versions	Removable Disk (E:)

4) Copy MP3 file or others to MMC card through searcher.

5) After complete copy, take out the MMC card from
   UR-1000 card reader and insert it to MP3 player.

Caution

MP3 file can work well in MP3 player
when the expander of file is .mp3.

Installing in Macintosh

1) Connect UR-1000 to USB port of your Mac and insert
   CD-ROM of installation into CD-ROM Drive.

2) Practice "SD installer" in CD-ROM.

3) Click "install" on the following screen.

* If you want to remove the driver of UR-1000 card reader,
 click "remove".

4) On the following screen, Clack the "restart" when the
   installation is finished

5) After restarting, insert the MMC card into card reader.
   The moveable disk icon will be appeared on the screen.

Windows XP	

Other versions	

6) Copy MP3 file or others to the disk by drag with mouse.

7) After finish the copy, put the moveable disk, MMC card to
   trash box and remove MMC card from reader.

8) After finish all of upper working, insert it to MP3 player
   and use it.

Reference

UR-1000 card reader works well in Mac OS 9.0
or more version.

You can get the information and detail from

our home page, www.emaycom.com.

Memo

maycom Co., Ltd.