

A .Features

- 1、 Music supported in MP3/WMA formats, FM transmission
- 2、 7 frequency bands supported: 106.7、 106.9、 107.1、 107.3、
107.5、 107.7、 107.9
- 3、 Line In/Out interface for earphone and audio frequency
devices such as CD, VCD, DVD, MP3, computer.
- 4、 Can be used as U drive for file storage.

B. User Instructions

- 1、 Download music in MP3/WMA formats from your
computer to the Car Music Player using the USB cable
attached.
- 2、 Insert the Car Music Player in the cigarette adaptor when
the electricity system in your car is turned on.
- 3、 Select the transmission frequency for the Car Music Player
based on the local usage of frequency and set the frequency
for the Car Music Player as selected.
- 4、 Turn on the radio in your car and set the reception
frequency as selected. The Car Music Player is now ready
to play.
- 5、 Adjust the volume to your desired level.
- 6、 Push “<<” or “>>” to select the music you wish to play.

F. Notes

- 1、 Music formats of MP3/WMA only.
- 2、 12V car power supply. 24V can be supplied upon request.
- 3、 Do not let Car Music Player sit idle for long term in cigarette adaptor and keep your Car Music Player in safe storage.
- 4、 Switch to a different frequency if you get too much interference static noise
- 5、 Press and hold down PLAY/PAUSE key, system records the current frequency being used and music being played and then shuts down automatically.
- 6、 Music damaged or virus affected will not play properly and should be deleted or virus cleared.
- 7、 Please refer to the User Manual for what else not specified herein.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.