


MD-3119无线充


User Guide



MD-3119

Bluetooth Speaker with Wireless Charging


FCC ID:2AB5T-MD-3119



What's in the box


- 1 x Bluetooth Speaker
- 1 x 3.5mm Audio Cable
- 1 x USB Charging Cable
- 1 x User Guide
- 1 x Warranty Card

Overview



1. Power on/off button
2. Bluetooth button
3. Volume up/Skip forward button
4. Play/Pause/Call control button
5. Volume down/Skip backward button
6. Wireless charging zone
7. USB charging port
8. Audio jack

Connections




EN-1

Indicator Light

Indicator light display	System status
Flashing Blue	In Pairing Mode
Solid Blue	Paired

Indicator light display	System status
Flashing Blue	Charging Your Device



EN-2

Functions


Button/Icon	Operation	System Status
⏻	Press Once/Press and Hold for 2 Seconds	Power on/off
📶	Press and Hold for 2 Seconds	Bluetooth off
⏮	Press Once/Press and Hold for 2 Seconds	Volume up/Skip Forward
⏸	Press Once	Play/Pause/Phone call Control
⏭	Press and Hold for 2 Seconds	Dial the Latest Phone Number
⏪	Press Once/Press and Hold for 2 Seconds	Volume Down/Skip Backward
🔋	Put a Supported Device on ⚡ Zone	Charging Your Mobile Device

NOTICE: Make sure to use 5V/2A adapter to charge the speaker. After fully charged, red LED indicator turns off.

EN-3

Bluetooth Connection

1. Power on the speaker by pressing and hold ⏻ for 2 seconds.
2. Enable your Bluetooth features on your mobile device.
3. Tap the speaker name "MD-3119" and connect.



EN-4

CARE AND MAINTENANCE

- Do not drop, crush, bend or apply excessive force to the device.
- Do not expose your device to moisture, extreme or prolonged heat, cold, humidity, or other adverse conditions. Avoid storing it in damp, humid or wet places, as it is not waterproof.
- Clean the unit with a soft cloth or damp chamois leather. Never use solvents.
- The Unit can only be opened by qualified personnel.
- This device contains magnets. Keep magnetic field sensitive products such as credit cards and video screen away from this device to avoid damage.

FAQ

Q1: My Bluetooth speaker do not switch on.
 • The battery level is low. Charge the speaker.
 • Make sure the speaker is powered on.
 • Make sure your device's Bluetooth feature is on.
 • Make sure the speaker is not paired by another device. If it is, press 📶 button to disconnect them. Then, pair again.
 • Move your device closer to the speaker and away from any interference or obstructions.


Q2: I have difficulty to pair my device to the speaker.
 • Refer to the user manual of your device. Select to play through the speaker.
 • Some of the music/video players may need you to go to the settings and select to play through the speaker from output device list.

Q3: My Bluetooth speaker is connected to a Bluetooth enabled device, but music can not play on my speaker.
 • Refer to the user manual of your device. Select to play through the speaker.
 • Some of the music/video players may need you to go to the settings and select to play through the speaker from output device list.

Q4: The audio quality is poor and crackling noise can be heard.
 • The Bluetooth device is out of range. Reduce the distance between your speaker and Bluetooth device, or remove obstacles between them.

EN-4


使用说明



MD-3119

无线充电蓝牙音响


FCC ID:2AB5T-MD-3119



包装内容


- 1x无线充电蓝牙音箱
- 1x USB充电线
- 1xAUX音频线
- 1x说明书

功能介绍



1. 电源开关键
2. 蓝牙键
3. 音量+/下一曲键
4. 暂停/播放键
5. 音量-/上一曲键
6. 无线充电放置区
7. USB充电接口
8. AUX连接口

连接与充电



中文-1

状态指示灯

指示灯	状态
蓝灯闪烁	等待蓝牙连接
蓝灯常亮	蓝牙已连接

指示灯	状态
蓝色呼吸灯闪烁	移动设备充电中

指示灯	状态
红灯常亮	正在充电中

注：充电需用5V/2A电源适配器。充满电后，红灯熄灭。

功能使用

按键/图标	操作	状态
⏻	短按一下/长按2秒	开机/关机
📶	长按2秒	断开蓝牙连接
⏮	短按一下/长按2秒	音量+/下一首
⏸	短按一下	播放、暂停、接听、挂断电话
⏭	长按2秒	拨打通话列表中最后一个号码
⏪	短按一下/长按2秒	音量-/上一首
🔋	将手机放置🔋中心位置	移动设备充电中

中文-2

蓝牙连接

1. 长按 ⏻ 2秒，蓝灯闪烁并自动进入配对模式；
2. 打开您移动设备上的蓝牙功能；
提示：蓝牙功能通常在“设置”菜单中；
3. 从设备列表中选择蓝牙名“MD-3119”，点击连接。



无线充电

1. 将移动设备放置在无线充电区
2. 蓝色呼吸灯亮起

提示：
 1. 确保您的移动设备支持无线充电功能
 2. 当充电完成后，蓝色呼吸灯关闭

中文-3

保养与维护

- 请勿跌落、挤压、弯曲或对设备施加过大的力。
- 请勿将设备放在潮湿、寒冷、极端环境或者长时间的高温中，湿度过高/过低可能会导致电池发生起火/爆炸，避免将设备放置在潮湿的地方，以免内置的电路出现不良反应。
- 请勿用挥发、刺激性的液体擦拭产品，最好的方法是用软布或专业的皮具清洁剂清洗产品。
- 非电子专业人员请勿私自拆卸产品，否则可能造成短路，进而导致火灾或者触电。如果处于某种原因(包括正常磨损和损坏或开裂)需要更换本产品的任何部件，请与商家联系。
- 本机包含磁铁。请将磁铁敏感型产品(如信用卡和视频屏幕)远离本机，以防止损坏。

疑义解答

问题1：蓝牙音箱无法开机。
 • 电池电量不足，请给音箱充电。
问题2：设备无法与音箱配对。
 • 确保音箱已开机。
 • 确保设备的蓝牙功能已打开。
 • 确保音箱未与其他设备配对。如果已配对，请按 📶 键断开连接，然后再次配对。
问题3：蓝牙音箱已连接到支持蓝牙的设备(手机、电脑、平板等)，但音乐不能通过音箱播放。
 • 将设备靠近音箱并远离任何干扰或障碍物。
问题4：音质差，有噪音。
 • 蓝牙设备超出范围。请缩短音箱和蓝牙设备之间的距离，并远离任何干扰或障碍物。

中文-4

重要安全说明

请阅读并保留所有安全和使用说明。

重要安全说明

1. 请阅读这些说明。
2. 请保留这些说明。
3. 请注意所有警告。
4. 请遵守所有说明。
5. 请勿在水附近使用本产品。
6. 请勿用干布进行清洁。
7. 只能使用制造商指定的附件/配件。
8. 任何维修服务均应向合格的人员咨询。如果设备有任何损坏，均需进行维修，例如电源线或插头受损、液体溅入或物体落入设备内、设备受淋或受潮、不能正常工作或跌落。

警告/小心

- 为减少着火或电击的危险，请勿使本产品受潮或受淋。
- 本产品不得受液体溅或喷洒，不得将装有液体的物体(如花瓶等)置于本产品上或本产品附近。
- 未经授权切勿改装本产品。
- 仅在经相关部门批准且符合本地监管要求的电源(如 UL、CSA、VDE、CCC)条件下使用本产品。
- 如果电池漏液，请避免让液体与皮肤或眼睛接触。如果接触到了液体，请咨询医生。
- 请勿使含有电池的的产品过热(例如避免阳光直射并远离火源等)。

包含小部件，可能会导致窒息。不适合3岁以下的儿童使用。

本产品含有磁性材料。关于其是否会影响到植入的医疗设备，请咨询医生。

中文-5

产品售后服务条例

一. 本公司提供的售后服务方式

1. 包换服务: 包换期内的产品, 若出现因原厂原因造成的质量问题, 用户可以到经销商处免费换新或维修。
2. 保修服务: 保修期内的产品, 若出现质量问题, 用户可以到经销商处或寄回原厂免费维修。

二. 用户自购买日起, 在正常使用情况下产品若出现质量问题, 按照国家有关三包法律规定整机7天包退, 15天包换, 一年内免费保修。

1. 购买日期以购货发票日期为准(无购货发票和售后服务中心的, 但能有效证明产品确属服务期内, 可以修理、换货, 不能提供有效证明的, 以生产日期为准)。
2. 无序列号产品本公司不承担售后服务义务。
3. 质量问题不包括用户对音质、音色等的主观异议。
4. 包换、保修服务只限于正常使用的情况下有效。一切人为损坏(例如用户自行拆机、进行不适当的连接使用、接入不当电压的电源、未依操作指南使用等)、因运输及其他意外而造成之损坏、自然灾害等不可抗力、售后服务卡上的内容与商品实物标识不符的、非经本公司认可之修改和改造等均不在免费保修范围内, 维修服务适当收费。

三. 要求服务时请携带此卡及购机发票正本。请妥善保管此卡及购机发票, 此卡不得涂改, 否则作废。

四. 使用本产品前, 请仔细阅读本产品的操作指南。

中文-6

用户资料

用户姓名: _____ 联系电话: _____

用户地址: _____

产品型号: _____ 产品序列号: _____ 购机日期: _____年____月____日

售机单位: _____ 售机单位联系电话: _____

售机单位地址: _____ 邮编: _____

维修记录

维修单位: _____ 联系电话: _____

地址: _____ 邮编: _____

送修故障: _____

修理结果: _____

日期: _____ 经手人: _____

送修故障: _____

修理结果: _____

日期: _____ 经手人: _____

中文-7

监管信息

根据中国《电子产品污染控制管理办法》

部件标准	有害物质或元素						
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)	
金属成分	×	0	0	0	0	0	0
塑胶部件	0	0	0	0	0	0	0
电线电缆	×	0	0	0	0	0	0
电路板组件	×	0	0	0	0	0	0
外壳	0	0	0	0	0	0	0
喇叭单元	0	0	0	0	0	0	0
附件(电源线、连接线)	×	0	0	0	0	0	0

0: 表示该有害物质在该部件所有均质材料中含量均符合SJ/T11363-2006标准规定的限量要求。
 ×: 表示该有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006标准规定的限量要求。
 备注: 表中带有“×”的所有部件应符合欧盟RoHS法规(2011/EU指令)。
 1. 电源线: 插头的铜合金中含铅。
 2. 电路板组件: 电子元器件的陶瓷或者玻璃中含铅。
 3. 环保使用期限取决于产品正常工作的温度和湿度等条件。

以上数据均来自实验室, 仅供参考。

制造商: 深圳市德动智能股份有限公司
 电话: 86 (0)755-29166636
 网站: www.cowingroup.com.cn
 地址: 深圳市宝安区西乡铁岗村湾仔科技园B栋三楼
 技术标准: GB17625.1-2012 GB8898-2011 GB13837-2012

3C证书编号: 2013010801630948 FCC ID: 2AB5T-MD-3119

中文-8

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.