

Meisida Eagle Radio Control Series

Missile Launcher R/C Car

MSD2003



Operation Manual

(Please read this manual carefully before operation)



Meisida Electronic Toys Co.,Ltd.

Add:No.1 of the 8th Block of Anping Development Zone, Anhai,Jinjiang,Fujian,China
Tel:0595-5788889 Zip Code:362261 Cable:4388
Executing Standards: GB6675-86, GB52965-1996
Suitable Ages:Over 8



⚠ Warnings!

- 1.How to use the charger
 - In case of smoke, strange smell or noise, operation shall be stopped in order to avoid fire or electric shock. Pull the plug and get ready for repair after confirming that there is no more smoke.
- 2.How to use the battery
 - Leakage from battery may lead to blindness. Clean the polluted eye immediately with clear water and consult doctors thereafter.
- 3.Warning: Do not insert the fingers into the clearance in case of any danger while the car is in movement.



⚠ Cautions!

- 1.How to use the charger
 - Do not touch the plug or socket with wet hand to avoid electric shock.
 - Pull the plug upon completing the charge for the risk of fire.
- 2.How to use the battery
 - (Improper use of battery may lead to dangers such as heat, breakage or leakage. Note the following items)
 - Strictly observe the methods and cautions of the operation manual.
 - Avoid short circuit as it may lead to great currents.
 - Leakage from the battery may hurt skin. Clean the skin when contaminated.
 - Do not drop the battery into water or fire or even dissolve the battery.



⚠ Cautions!

- Do not use ,charge or store the battery in places that are close to fire or heat or moist.
- Do not charge the battery upon fulfillment.Overcharging may be hazardous.
- Make sure to install the positive pole and negative pole correctly.
- Make sure to switch off and take out the battery after play.

3.Cautions in operation:

(Please note the following items for the sake of avoiding accidents)

- Play on roads or crowded places may be risky,choose a safe outdoor place for operation.
- Do not distort the antenna or twist may injure people.
- Do not damage glass or furniture when play indoors.
- Avoid the risk of finger or hair's being involved when the wheel is in operation.

4.Rules for play

- Do not run the toy car on rainy day or wet surface,this shall lead to breakdown of the car.
- Avoid operation on soil or fine sand.
- Do not store the car in heating room or places next to fire.
- Do not play outdoors when thundering.
- Do not play near some wireless transmitting facilities.
- Do not play near some radio control car which is of the same frequency so as to avoid being interfered.

Material used: Plastic, hardware, Electronic oven

⚠ Cautions!

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This equipment has been tested and found to comply with limits for a Class B digital-device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - 1, Reorient or relocate the receiving antenna.
 - 2, Increase the separation between the equipment and receiver.
 - 3, Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - 4, Consult the dealer or an experienced radio / TV technician for help.