



IMMERSE GH50 WIRELESS

繁體中文

簡介

感謝選擇 MSI IMMERSE GH50 WIRELESS 用於驚豔音效和電競體驗的享受。本說明書提供使用說明及顯示，幫助您認識產品，以及首次使用設定說明。

第一次於PC上使用時，系統會自行安裝驅動程式；待安裝後，建議於電競前，重新啟動PC。

外觀檢視

- 1. 麥克風靜音 / 配對鈕
- 2. 電源按鈕
- 3. 充電狀態指示燈
- 4. 麥克風連接埠（可拆式麥克風）
- 5. 音量控制
- 6. 充電埠（USB Type-C）
- 7. 重置按鈕
- 8. 外接音源埠
- 9. 發射器配對按鈕
- 10. 發射器配對指示燈

設定

無線模式

- 於你的電腦上連接無線USB發射器並開啟耳機電源
- 無線USB發射器連接後，發射器指示燈亮起：

 - 白色燈號恆亮：與耳機連線已配對
 - 白色燈號緩慢閃爍：與耳機連線已斷開
 - 白色燈號快速閃爍：耳機與發射器正在配對中

- 重置耳機與發射器的連線：以尖頭狀的物體（如別針）插入孔洞中並推轉按鈕一下，耳機復位並進入關機

- 耳機充電：以USB-C線連接充電埠和另一端的電力來源
- 充電狀態指示燈：

 - 充電完成，紅色燈號恆亮
 - 充電中，紅色燈號呼吸閃爍
 - 電量低，紅色燈號緩慢閃爍*

有線模式（3.5mm）

- 於外接音源埠連接3.5mm音源線，耳機會自動關機並轉換至有線模式

Playstation

- 於PS4或PS5上任一USB埠上，連接無線USB發射器
- 於Playstation系統中更改設定，將Output to Headphones調整為All Audio

Wireless Headset

Operating Frequency: 2403.35-2479.35MHz
Output power: < xx dBm

EU compliance statement

English: MSI Inc. hereby declares that this wireless device is in compliance with Directive 2014/53/EU.

Français: MSI déclare par la présente que ce dispositif sans fil est conforme à la Directive 2014/53/UE.

Deutsch: Hiermit erklärt MSI Inc., dass sich dieses drahtlose Gerät in Übereinstimmung mit der Richtlinie 2014/53/EU befindet.

Italiano: MSI Inc. dichiara che questo dispositivo wireless è conforme alla Direttiva 2014/53/UE.

Español: Por medio de la presente, MSI Inc. declara que este dispositivo inalámbrico cumple con la Directiva 2014/53/UE.

JAPAN VCCI CLASS B STATEMENT

この装置は、クラスB情報技術装置です。この装置は、家庭環境で使用する事を目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。取扱説明書に従って正しく取り扱って下さい。VCCI-B

本製品は、EMC準拠の周辺機器およびシステムコンポーネント間にシールドケーブル（イヤーサーツワーカーブル）が使用されている状況で、EMCへの準拠が実証されています。

ラジオ、テレビ、およびその他の電子機器への干渉が発生する可能性を低減するため、EMC

準拠の周辺機器およびシステムコンポーネント間にシールドケーブルを使用することが重要です。

重要: MSIの許諾を得ることなく本製品に変更または変更を加えると、電磁両立性（EMC）お

および無線準拠しなくなり、製品を操作するための許諾が取り消されるおそれがあります。

XXX-XXXXXX

NCC警語

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或更換原設計之外特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信；發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法之規定作業之無線電通信。低功率射頻器材忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

XXXXXXXXXXXXXX


English

Introduction

Thank you for choosing MSI IMMERSE GH50 WIRELESS to enjoy an astonishing audio and gaming experience. This guide provides instructions and illustrations to help you get the most from this product including the first time setup.

The first time to use the headset on a PC, the operating system will automatically install the device driver. After the device driver loads, we recommend you reboot your PC before gaming.

Product Overview



- 1. MIC Mute / Pairing Button
- 2. Power Button
- 3. Charging Status Indicator
- 4. Mic Connector (Detachable Microphone)
- 5. Volume Control
- 6. Charging Port (USB Type-C)
- 7. Reset Button
- 8. AUX Port
- 9. Transmitter Pairing Button
- 10. Transmitter Status Indicator

English

Setup

Wireless mode

• Connect the Wireless USB Transmitter to your PC, and turn on the headset.

• The Transmitter Status Indicator will illuminate when the Wireless USB Transmitter is plugged

- The white light stays on: the headset is connected.

- The white light flashes slowly: the headset is disconnected

- The white light flashes quickly: the headset and the transmitter are pairing

• To reset the connectivity of the headset and the transmitter: insert a pointed object such as a pin into the hole and push the button for 2 seconds

Wired mode (3.5mm)

• Connect the 3.5mm audio cable with the AUX port, the headset will automatically power off and switch to wired mode (LINE IN).

Playstation

• Connect the wireless USB transmitter to any USB port on your PS4 or PS5 console.

• Change the settings in the PlayStation system to set "Output to Headphones" to "All Audio".

Controls

Power Button

• To power on: press and hold for 3 seconds

• To power off: press and hold for 2 seconds

• The Power Button will illuminate when the headset is turned on:

- The white light stays on: the headset is connected with the transmitter

- The white light flashes slowly: the headset is disconnected with the transmitter

- The white light flashes quickly: the headset is pairing

Mic Mute / Paring Button

• Press to mute the microphone, the red light stays on.

• Press to unmute the microphone, the red light goes off.

• To pair the headset and the transmitter: press and hold for 3 seconds, the white light on power button flashes quickly.

Volume Control

• To turn up the volume: scroll up the control wheel

• To turn down the volume: scroll down the control wheel

• Beep sound pops up: when them volume is adjusted to the maximum or minimum

English

Reset Button

• To reset the headset to factory settings: insert a pointed object such as a pin into the hole and push the button, the headset will be reset and powered off automatically.

Battery Life & Charging

• To Charge the headset: connect the USB-C cable to the charging port and the other end to a power source

Charging Status Indicator

- When fully charged, the red light stays on

- When charging, the red light breathes

- When battery is low, the red light flashes slowly

Notice

1. The maximum input voltage to recharge this headset is 5.5V

2. Use of chargers labeled with 5V voltage and 500mA current purchased from official channels is recommended.

3. When the battery is exhausted, please recharge the headset as soon as you can.

4. It is recommended to fully charge the headset if it is not in use for a long time.

5. It is recommended to connect the microphone with a gentle force and prevent damage to the connector.

6. Please do not disassemble the product since it may cause damages.

English

繁體中文

控制說明

電源按鈕

• 電源開啟：按壓並維持3秒

• 電源關閉：按壓並維持2秒

• 當耳機電源開啟後，電源按鈕會亮起：

- 白色燈號恆亮：耳機與發射器已配對

- 白色燈號緩慢閃爍：耳機與發射器配對已斷開

- 白色燈號快速閃爍：耳機進入配對模式

麥克風靜音 / 配對按鍵 Mic Mute / Paring Button

• 按壓一次靜音麥克風，則紅色燈號恆亮

• 按壓一次取消麥克風靜音，則紅色燈號熄滅

• 配對耳機與發射器：按壓並維持3秒，則電源按鈕白色燈號快速閃爍

音量控制

• 調大音量：向上滾動控制滾輪

• 調降音量：向下滾動控制滾輪

• 哔聲響起：當音量已調整至最大或最小值

重置按鈕

• 重置耳機：以尖頭狀的物體（如別針）插入孔洞中並推轉按鈕一下，耳機復位並進入關機

電池使用時間 & 充電說明

• 耳機充電：以USB-C線連接充電埠和另一端的電力來源

充電狀態指示燈：

- 充電完成，紅色燈號恆亮

- 充電中，紅色燈號呼吸閃爍

- 電量低，紅色燈號緩慢閃爍*

音量控制

• 調大音量：向上滾動控制滾輪

• 調降音量：向下滾動控制滾輪

• 哔聲響起：當音量已調整至最大或最小值

重置按鈕

• 重置耳機：以尖頭狀的物體（如別針）插入孔洞中並推轉按鈕一下，耳機復位並進入關機

電池使用時間 & 充電說明

• 耳機充電：以USB-C線連接充電埠和另一端的電力來源

充電狀態指示燈：

- 充電完成，紅色燈號恆亮

- 充電中，紅色燈號呼吸閃爍

- 電量低，紅色燈號緩慢閃爍*

有線模式（3.5mm）

耳機充電

• 以USB-C線連接充電埠和另一端的電力來源

充電狀態指示燈：

- 充電完成，紅色燈號恆亮

- 充電中，紅色燈號呼吸閃爍

- 電量低，紅色燈號緩慢閃爍*

JAPAN VCCI CLASS B STATEMENT

この装置は、クラスB情報技術装置です。この装置は、家庭環境で使用する事を目的としている

ます。この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起

こすことがあります。取扱説明書に従って正しく取り扱って下さい。VCCI-B

本製品は、EMC準拠の周辺機器