

# MSR Cam

 ***This symbol identifies safety and health messages in this Device Guide***

 **WARNING: Read Safety & Health Info**

Read this guide for important safety and health information and the terms of the Limited Warranty that apply to the Microsoft® device that you have purchased. Keep all printed guides for future reference. Failure to follow instructions and properly set up, use, and care for this product can increase the risk of serious injury or death, or damage to the device or devices.

 **WARNING: Do Not Attempt Repairs**

Do not attempt to take apart, open, service, or modify the product, accessories, or battery. Doing so could present the risk of electric shock or other hazard. Any evidence of any attempt to open and/or modify this device, including any peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.

 **CAUTION: Cable and cord safety**

Arrange all cables and cords so that people and pets are not likely to trip over or accidentally pull on them as they move around or walk through the area. Do not allow children to play with cables and cords.

**To avoid damaging the USB cable:**

- Protect the cable from being walked on.
- Protect cable from being pinched or sharply bent, particularly where they connect to the devices.
- Do not jerk, knot, sharply bend, or otherwise abuse the cable.
- Do not expose the cable to sources of heat.
- Keep children and pets away from the cable. Do not allow them to bite or chew on them.
- When disconnecting the cable, pull on the plug—do not pull on the cord.
- If a cable becomes damaged in any way, stop using it immediately.
- Unplug your device during lightning storms or when unused for long periods of time.

 **WARNING: Battery Safety**

This device contains a built-in battery, improper use of which may result in explosion.

- Do not heat, open, puncture, mutilate, or dispose of the product in fire.
- Do not leave the device in direct sunlight for an extended period of time, which could cause melting or battery damage.
- Do not leave this product in a vehicle, particularly on a car dash on a hot day.

- Do not strike, throw, step on, or subject the product to severe physical shock.

Do not wear the device while the battery is charging. The battery in this device is not user replaceable and should only be replaced by Microsoft or a Microsoft Authorized Service Provider.

 **WARNING: Use Near Water**

This device is not waterproof. To reduce the risk of fire or shock do not expose it to excessive rain or moisture. Do not attempt to charge this device in rain or excessive moisture conditions. Do not attempt to dry device with a hair dryer or a microwave oven.

 **WARNING: Lanyard**

Avoid possible injury by entanglement, entrapment, or strangulation. This device and lanyard are not toys. Do not allow small children to play with or wear the lanyard. Take great care if using the device with the lanyard near equipment, machinery, or environments where the lanyard could become entangled or entrapped.

 **WARNING: Environmental Conditions**

In order to reduce the risk of fire or explosion, use of batteries and storage conditions for batteries should not exceed their temperature ratings as shown in the Regulatory Information section of this document.

 **WARNING: Airbag Avoidance**

For vehicles equipped with airbags, do not place the device or other objects on or near the airbags. If an airbag deploys, objects placed on or near the airbag could cause serious personal injury or even death.

 **WARNING: Choking Hazard**

This device may contain small parts which may be a choking hazard to children under 3. Keep small parts away from children.

 **WARNING: Follow Instructions to Avoid Interference Problems**

Turn off your mobile device in any location where posted notices instruct you to do so. In an aircraft, turn off your device whenever instructed to do so by airline staff, or prior to packing a wireless device in luggage. Please consult airline staff about using it in flight.

 **WARNING: Potentially Explosive Atmospheres**

Areas with potentially explosive atmospheres are often, but not always, posted and can include fueling areas, such as below decks on boats, fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain dust, or metal powders. When you are in such an area, turn off your mobile device, and do not remove or install battery

chargers, AC adapters, or any other accessory. In such areas, sparks can occur and cause an explosion or fire.

 **WARNING: Personal Medical Devices**

Radio-frequency emissions from electronic equipment can negatively affect the operation of other electronic equipment, causing them to malfunction. Although the device is designed, tested, and manufactured to comply with regulations governing radio frequency emission in countries such as the United States, Canada, the European Union, and Japan, the wireless transmitters and electrical circuits in the device may cause interference in other electronic equipment. Therefore, please take the following precautions:

**Pacemakers**

The Health Industry Manufacturers Association recommends that a minimum separation of 15 cm (6 inches) be maintained between a wireless device and a pacemaker to avoid potential interference with the pacemaker.

Persons with pacemakers:

- Should always keep the device more than 15 cm (6 inches) from the pacemaker when the wireless device is turned on.
- Should not carry in the breast pocket.
- If you have any reason to suspect that interference is taking place, turn the device off immediately.

**Other Medical Devices**

If you use any other personal medical device, consult the medical device manufacturer or your physician to determine if it is appropriate for you to use other electronic devices near your medical device.

 **CAUTION: Heat Related Concerns**

The device may become warm during normal use. The device complies with the user-accessible surface temperature limits defined by the International Standard for Safety of Information Technology Equipment (IEC 60950-1). To reduce heat related concerns, follow these guidelines:

- If you are wearing your device and it becomes uncomfortably warm, then discontinue wearing it until it cools off
- Avoid wearing your device while syncing data with your smartphone or PC

**CARING FOR YOUR ACCESSORY**

- Do not use near any heat sources.
- Only use attachments/accessories specified by Microsoft.
- Clean only with a dry cloth.

**REGULATORY INFORMATION**

## Disposal of Waste Batteries and Electrical & Electronic Equipment



This symbol on the product or its batteries or its packaging means that this product and any batteries it contains must not be disposed of with your household waste. Instead, it is your responsibility to hand this over to an applicable collection point for the recycling of batteries and electrical and electronic equipment. This separate collection and recycling will help to conserve natural resources and prevent potential negative consequences for human health and the environment due to the possible presence of hazardous substances in batteries and electrical and electronic equipment, which could be caused by inappropriate disposal. For more information about where to drop off your batteries and electrical and electronic waste, please contact your local city/municipality office, your household waste disposal service, or the shop where you purchased this product. Contact [weee@microsoft.com](mailto:weee@microsoft.com) for additional information on WEEE and waste batteries. This product contains a Lithium-ion Battery.

This device is not intended for use in machinery, medical or industrial applications. Any changes or modifications not expressly approved by Microsoft could void the user's authority to operate this device. This product is for use with NRTL Listed (UL, CSA, ETL, etc.), and/or IEC/EN 60950-1 compliant (CE marked) Information Technology equipment. No serviceable parts included. This device is rated as a commercial product for operation at +32°F (+0°C) to +95°F (+35°C).

### For Customers in the United States and Canada

This Class B digital apparatus complies with, as applicable, Part 15 of the U.S. Federal Communications Commission (FCC) rules, Canadian ICES-003, RSS-Gen and RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Exposure to Radio Frequency (RF) Energy

This device contains Wi-Fi and Bluetooth radio transmitters and has been designed, manufactured and tested to meet the Federal Communications Commission (FCC), Industry Canada and European guidelines for RF exposure and Specific Absorption Rate.

Additional information about RF safety can be found on the FCC website at [www.fcc.gov/oet/rfsafety](http://www.fcc.gov/oet/rfsafety) and the Industry Canada website at [www.ic.gc.ca/eic/site/smt-gst.nsf/eng/sf01904.html](http://www.ic.gc.ca/eic/site/smt-gst.nsf/eng/sf01904.html)

### Radio and TV Interference Regulations

The Microsoft hardware device(s) can radiate radio frequency (RF) energy. If not installed and used in strict accordance with the instructions given in the printed documentation and/or onscreen help files, the device may cause harmful interference with other radio-communications devices (for example AM/FM radios, televisions, baby monitors, cordless phones, etc.). There is, however, no guarantee that RF interference will not occur in a particular installation. To determine if your hardware device is causing interference to other radio-communications devices, turn off and unplug the device from any external power source. If the interference stops, it was probably caused by the device. If this hardware device does cause interference, try the following measures to correct it:

- Relocate the antenna of the other radio-communications device (for example AM/FM Radios, televisions, baby monitors, cordless phones, etc) until the interference stops.
- Move the hardware device farther away from the radio or TV, or move it to one side or the other of the radio or TV.
- Plug the device into a different power outlet so that the hardware device and radio or TV are on different circuits controlled by different circuit breakers or fuses.
- If necessary, ask your device dealer or an experienced radio-TV technician for more suggestions. For more information about interference issues, go to the FCC Web site at: <http://www.fcc.gov/cgb/consumerfacts/interference.html>. You can also call the FCC at 1-888-CALL FCC to request Interference and Telephone Interference fact sheets.

## **COPYRIGHT**

Information and views expressed in this document, including URL and other Internet Web site references, may change without notice.

This document does not provide you with any legal rights to any intellectual property in any Microsoft product. You may copy and use this document for your internal, reference purposes.

© 2014 Microsoft Corporation. *Bluetooth* is a registered trademark of Bluetooth SIG, Inc. All other trademarks are property of their respective owners.

## **NO WARRANTY, AND LIMITATION ON AND EXCLUSION OF REMEDIES AND DAMAGES**

**BY USING YOUR MICROSOFT MSR CAM (“MICROSOFT HARDWARE”), YOU AGREE TO THE FOLLOWING TERMS. BEFORE USING THE MICROSOFT HARDWARE, PLEASE READ THESE TERMS CAREFULLY. IF YOU DO NOT ACCEPT THEM, DO NOT USE YOUR MICROSOFT HARDWARE AND RETURN IT UNUSED TO MICROSOFT.**

**MSR CAM IS NOT FOR SALE BY MICROSOFT OR ANY AUTHORIZED RETAILER. MICROSOFT PROVIDES THE MICROSOFT HARDWARE “AS IS” AND MAKES NO REPRESENTATION OR WARRANTY WHATSOEVER AS TO ITS MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.**

**TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL MICROSOFT OR ITS SUPPLIERS BE LIABLE FOR ANY DIRECT, SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS OR CONFIDENTIAL OR OTHER INFORMATION, FOR BUSINESS INTERRUPTION, FOR PERSONAL INJURY, FOR LOSS OF PRIVACY, FOR FAILURE TO MEET ANY DUTY INCLUDING OF GOOD FAITH OR OF REASONABLE CARE, FOR NEGLIGENCE, AND FOR ANY OTHER PECUNIARY OR OTHER LOSS WHATSOEVER) ARISING OUT OF OR IN ANY WAY RELATED TO THE USE OF OR INABILITY TO USE THE MICROSOFT HARDWARE, THE PROVISION OF OR FAILURE TO PROVIDE PROGRAM OR SUPPORT SERVICES, OR OTHERWISE UNDER OR IN CONNECTION WITH ANY PROVISION OF THESE TERMS, EVEN IN THE EVENT OF THE FAULT, TORT (INCLUDING NEGLIGENCE), STRICT**

**LIABILITY, BREACH OF CONTRACT OR BREACH OF WARRANTY OF MICROSOFT OR ANY SUPPLIER, AND EVEN IF MICROSOFT OR ANY SUPPLIER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, AND EVEN IF ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE. Some States or Provinces do not allow the exclusion or limitation of incidental or consequential damages, so this limitation or exclusion may not apply to You.**