



## Getting started with Surface Laptop

1. Plug the power cable into your Surface Laptop and then into the wall.
2. Press the power button.
3. Windows will guide you through the setup process, help you sign on to Wi-Fi, and choose your language preference.
4. If you already have a Microsoft account, use it to sign in and you'll be able to sync your settings and content across multiple devices.
5. If you need to set up a Microsoft account, remember that you can use any email address.

For more information on the benefits of using a Microsoft account with Surface, visit **[windows.microsoft.com/account](https://windows.microsoft.com/account)**

For help with setup or troubleshooting, visit **[support.microsoft.com](https://support.microsoft.com)**

## Windows Hello

Configure **Windows Hello** using the integrated camera in Microsoft Surface Laptop

1. Swipe in from the right and go to **All settings**.
2. Open **Accounts** and select **Sign-in Options**
3. Create a pin
4. Click on **Windows Hello** and configure your Microsoft Surface Laptop for Face Authentication

## To troubleshoot or learn more

Open the Surface app on your Surface Laptop

- Hit the Windows key, type **Surface** and open the Surface app
- Here you can learn more about your Microsoft Surface Laptop

If you'd like to learn more about Windows, visit [windows.microsoft.com/how-to](https://windows.microsoft.com/how-to)

To learn more about the accessibility features of your Surface Laptop, go to the on-line user guide at [microsoft.com/surface/support/userguides](https://microsoft.com/surface/support/userguides).

## Caring for your keyboard

Clean your keyboard frequently to keep it looking great. To keep it clean just use a screen cleaning wipe and gently wipe the fabric and keys.

For more persistent spots wipe it with a damp lint-free cloth using mild soap and water.

**NOTE:** Do not apply liquids to your keyboard.

## Caring for your screen

To avoid scratches, use a screen cleaning wipe to gently wipe the screen. You don't need to rub hard to remove finger prints or oily spots.

[support.microsoft.com](https://support.microsoft.com)

© 2016 Microsoft.



X21-20884-01