

Product Instruction

Warning

Please read all of the included instructions carefully before using your lamp.

1. Please only use the included power adapter.
 2. Please avoid looking directly at the lamp's light source. Doing so could cause discomfort and/or vision damage. Child supervision is recommended.
 3. Please turn the lamp off when it is not in use.
 4. Use of this lamp on a metal surface is not recommended and may cause unintended operation.
 5. Please do not use this lamp in hot and humid environments.
 6. Use of corrosive and abrasive materials to wipe or clean this lamp is not recommended and may cause permanent damage.
 7. Use of this lamp in flammable and/or explosive environments is not advised.
 8. Use of this lamp on flammable surfaces (bed, sofa, etc.) is not advised.
 9. Please keep this lamp and all included parts out of reach of children.
 10. Please ensure that the power supply cord is firmly plugged into the lamp, and avoid kinking, knotting, or any other action that introduces unnecessary stress onto the cord.
 11. If the power supply cable becomes damaged, exhibits excessive heat, or any other unexpected operation, please stop using it immediately and contact Microsun for a replacement.
 12. Do not disassemble or modify this product. Doing so may result in damage to property and/or physical harm.
 13. If this lamp exhibits unexpected functionality immediately disconnect the power and contact Microsun.
 14. Static electricity may interfere with the capacitive touch controls of this lamp and result in unintended operation.
 15. Dielectric withstand tests or Hipot tests may cause damage to the LEDs used in this product.
 16. Electromagnetic interference may cause unintended operation and/or damage to the product.
- *Use of this product must conform to the guidelines in this instruction manual. Failure to do so may result in damage to persons and/or property. Microsun is not responsible for any damage caused by misuse of this or any other product.


Avertissement

Veillez lire attentivement toutes les instructions avant d'utiliser votre lampe.

1. Veuillez utiliser uniquement l'adaptateur d'alimentation inclus.
 2. Veuillez éviter de regarder directement la source lumineuse de la lampe. Cela pourrait causer un inconfort et/ou des dommages oculaires. Les enfants doivent utiliser cette lampe sous la surveillance d'un adulte.
 3. Veuillez éteindre la lampe lorsqu'elle n'est pas utilisée.
 4. Il n'est pas recommandé d'utiliser cette lampe sur une surface métallique, car cela peut entraîner un fonctionnement indésiré.
 5. Ne pas utiliser cette lampe dans des environnements chauds et humides.
 6. Il n'est pas recommandé d'utiliser des matériaux corrosifs et abrasifs pour essuyer ou nettoyer cette lampe, car cela peut causer des dommages permanents.
 7. Il n'est pas recommandé d'utiliser cette lampe dans des environnements inflammables et/ou explosifs.
 8. Il n'est pas recommandé d'utiliser cette lampe sur des surfaces inflammables (lit, canapé, etc.).
 9. Veuillez tenir cette lampe et toutes les pièces incluses hors de la portée des enfants.
 10. Assurez-vous que le câble d'alimentation est fermement inséré dans la lampe et évitez de faire des pliures, des nouages ou toute autre action qui entraînerait un stress inutile dans le câble.
 11. Si le câble d'alimentation inclus est endommagé, présente une chaleur excessive ou toute autre opération inattendue, arrêtez immédiatement de l'utiliser et contactez Microsun pour un remplacement.
 12. Ne pas démonter ou modifier ce produit, cela pourrait entraîner des dommages matériels et/ou physiques.
 13. Si cette lampe présente une fonctionnalité inattendue, mettez-le hors de tension immédiatement et contactez Microsun.
 14. L'électricité statique peut interférer avec les commandes tactiles capacitatives de cette lampe et causer un fonctionnement inattendu.
 15. Les tests de rigidité diélectrique ou les tests Hipot peuvent endommager les LED utilisées dans ce produit.
 16. Les interférences électromagnétiques peuvent provoquer un fonctionnement imprévu et/ou endommager le produit.
- * L'utilisation de ce produit doit être conforme au manuel d'instructions. Le non-respect de ces instructions peut entraîner des dommages aux personnes et/ou aux biens. Microsun n'est pas responsable de tout dommage causé par une utilisation incorrecte de ce produit ou de tout autre produit.

Specifications

Product Name: moonlyte
Category: LED Table Lamp
Power: 12W
Illumination Wattage: 2W
Wireless charging Wattage: 5W (5V/1A)
USB charging Wattage: 3.5W (5V/0.7A)
Model No.: 4008-SI
Input Voltage: 5V---2A
Color Temperature: 3000K
Color Rendering Index: Ra≥80
Control: Capacitive touch control (Three step dimming)
Anti shock protection class: Class II
IP Rating: IP20
Storage environment:
Temperature: 15°F~105°F
Humidity: RH 15%~RH 50%




Operating Instructions

The moonlyte utilizes an advanced capacitive touch control system allowing it to be operated with simple taps to any metal surface.

Double Tap: On/Off
Single Tap: Cycle brightness level

Brightness Levels:
Initial power on state: 20%
1st tap: 50%
2nd tap: 100%
3rd tap: 20%(Pattern Repeats)

Notes: A double tap is defined as two taps within a 300ms time span.



Unit:mm(in)

FCC Warning

This device complies with part 18 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.