

Moov V Series Hardware Manual

Important safety information

PLEASE READ CAREFULLY BEFORE INSTALLING PRODUCT IN VEHICLE

<u> </u>	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.			
≜ WARNING	WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.			
▲ CAUTION	CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.			
CAUTION	CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.			



Removing original equipment, adding accessories or modifying your vehicle could affect the vehicle's safety or make it illegal to operate in some jurisdictions.

Follow all product instructions and all instructions in your vehicle owner's manual regarding accessories or modifications.

Consult your country's and/or state's laws regarding operation of a vehicle with any accessories or modifications.

It is your sole responsibility to place, secure and use your Mio in a manner that will not cause accidents, personal injury or property damage. Always observe safe driving practices.

Do not mount your Mio in a way that may interfere with the safe operation of the vehicle, the deployment of air bags or other safety equipment.

Do not operate your Mio while driving.

Before you use your Mio for the first time, familiarize yourself with your device and its operation.

On main roads, the distance to an exit calculated by your Mio may be further than the distance shown on road signs. Road signs show the distance to the start of an exit while your Mio shows the distance to the next intersection, i.e., the end of the exit ramp or road. To prepare to exit a road, always follow distance information on road signs.

The use of information regarding safety or speed camera locations may be subject to local laws in the country of use. You are responsible for checking that you can legally use the information in your country or in the country where the information will be used.

Products with FM Transmitter feature may be operated in the following countries:

AT	BE	BG	СН	CZ	DE	DK	EE
ES	FI	GB	HU	IE	IS	IT	LI
LT	LU	LV	MT	NL	NO	PL	PT
RO	SE	SI	SK				

The FM transmitter function is not allowed to use in Cyprus, France and Greece. Please turn off the FM Transmitter in those areas.

The TV and video player features MUST NOT be used when driving. Using the features may cause an accident. Please make sure you comply with this warning. Mio accepts NO liability whatsoever in this regard.



Do not handle your Mio while it is hot. Let the product cool, out of direct sunlight.

At full power, prolonged listening to your Mio via headphones or earphones can damage the ear of the user.

CAUTION

Do not expose your Mio to direct sunlight in an unattended vehicle for prolonged periods. Overheating may damage the unit.

To discourage theft, do not leave your Mio, mounting bracket or any cables in plain view in an unattended vehicle.

Warning Notice to Drivers in the United States

State law may prohibit drivers in states such as Arizona, California and Minnesota from mounting objects on their windshields while driving. Please make sure you research and follow your most current State laws. An alternative mounting option may be provided in the box with your product; or see our website for additional mounting alternatives. Mio does not take any responsibility for any fines, penalties, or damages that may be incurred as a result of disregarding this notice.

Home charger-specific safety information



To charge your Mio from the mains power, use the home charger supplied by Mio as an accessory (may be sold separately). Using other home chargers with your Mio could result in serious injury or property damage.

Never use the charger if the plug or cord is damaged.

Do not expose the charger to moisture or water. Do not use the charger in a high moisture environment. Exposure to water may cause electrical sparks or fires.

Never touch the charger when your hands or feet are wet.

Allow adequate ventilation around the charger when using it to operate your Mio or charge the internal battery. Do not cover the charger with paper or other objects that will reduce ventilation. Do not use the charger while it is inside a carrying case or other container.

Ensure that the charger is connected to a power source with the correct fitting and voltage requirements. The voltage requirements can be found on the home charger casing and/or packaging.

Do not attempt to service the charger as this could result in personal injury. Replace the charger if it is damaged or exposed to excess moisture.

About charging

- Use only the charger supplied with your Mio. Use of another type of charger will result in malfunction and/or danger.
- This product is intended to be supplied by a LISTED Power Unit marked with "LPS", "Limited Power Source" and output rated + 5 V dc / 2.0 A".
- Use a specified battery in the equipment.

About the charger

- Do not use the charger in a high moisture environment. Never touch the charger when your hands or feet are wet.
- Allow adequate ventilation around the charger when using it to operate your Mio or charge the battery. Do not cover the charger with paper or other objects that will reduce cooling. Do not use the charger while it is inside a carrying case.
- Connect the charger to a proper power source. The voltage requirements are found on the product case and/or packaging.
- Do not use the charger if the cord becomes damaged.
- Do not attempt to service the unit. There are no serviceable parts inside. Replace the unit if it is damaged or exposed to excess moisture.

Internal battery-specific safety information



Your Mio contains a non-replaceable internal lithium-ion battery. The battery may burst or explode if mishandled, releasing hazardous chemicals. To reduce the risk of fire or burns, do not disassemble, crush or puncture the battery.

Recycle or dispose of the battery safely and properly according to local laws and regulations. Do not dispose of the battery in fire or water.



Only use the correct home charger (sold separately) or in-car charger supplied by Mio to charge your Mio internal battery.

Only use your Mio internal battery with your Mio unit.

The Mio battery will stop charging when the ambient temperature is less than 0°C (32°F) or more than 45°C (113°F).

Failure to adhere to these warnings and cautions may lead to death, serious injury or property damage. Mio disclaims all liability for installation or use of your Mio that causes or contributes to death, injury or property damage or that violates any law.

About the battery

- Use a specified battery in the equipment.
- CAUTION: The battery can burst or explode, releasing hazardous chemicals. To reduce the risk of fire or burns, do not
 disassemble, crush, puncture, or dispose of in fire or water.
- Important instructions (for service personnel only)
 - Caution: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
 - Replace only with the same or equivalent type recommended by the manufacturer.
 - The battery must be recycled or disposed of properly.
 - Use the battery only in the specified equipment.

Contents

Home charger-specific safety information	
About charging	
About the charger	
About the battery	ა ვ
Welcome	
Important information for using the manual	
Formatting	5 5
lcons	
Terms	
Mounting your Mio in a vehicle	6
Mounting on the windshield	6
V500 Series	6
V700 Series	
Mounting on the dashboard	
V700 Series	
V500 Series	
V700 Series	
Enabling Traffic (TMC) Reception	9
Installing the optional digital TV card	10
Getting to know your Mio	11
V500 Series	11
V700 Series	12
How do I turn on my Mio?	13
Using the power switch	13
How do I charge the battery?	
How do I charge the battery in a vehicle?	14
How do I charge the battery via my computer? (V500 Series only)	1.1
How do I charge the battery at home or work?	14
How do I charge the battery at home or work? How do I insert a memory card?	14
How do I insert a memory card?	14 15 16
How do I insert a memory card?	14 15 16
How do I insert a memory card?	14 15 16
How do I insert a memory card? How do I use the remote control? Installing the battery for the remote control.	14 15 16 16
How do I insert a memory card? How do I use the remote control? Installing the battery for the remote control Remote control buttons Other features How do I receive current traffic information?	14 15 16 16 18
How do I insert a memory card? How do I use the remote control? Installing the battery for the remote control Remote control buttons. Other features. How do I receive current traffic information? How do I play music or video?	14 15 16 16 18 18
How do I insert a memory card? How do I use the remote control? Installing the battery for the remote control	14151616181818
How do I insert a memory card? How do I use the remote control? Installing the battery for the remote control	1415161618181818
How do I insert a memory card? How do I use the remote control? Installing the battery for the remote control. Remote control buttons. Other features. How do I receive current traffic information? How do I play music or video? How do I receive audio through my vehicle speakers? Reference. What is GPS?	141516161818181819
How do I insert a memory card? How do I use the remote control? Installing the battery for the remote control Remote control buttons. Other features. How do I receive current traffic information? How do I play music or video? How do I receive audio through my vehicle speakers? Reference. What is GPS? How does my Mio receive GPS signals?	141516181818181919
How do I insert a memory card? How do I use the remote control? Installing the battery for the remote control. Remote control buttons. Other features. How do I receive current traffic information? How do I play music or video? How do I receive audio through my vehicle speakers? Reference. What is GPS? How does my Mio receive GPS signals? Caring for your Mio.	14151616181818181919
How do I insert a memory card? How do I use the remote control? Installing the battery for the remote control. Remote control buttons. Other features. How do I receive current traffic information? How do I play music or video? How do I receive audio through my vehicle speakers? Reference. What is GPS? How does my Mio receive GPS signals? Caring for your Mio. Troubleshooting.	
How do I insert a memory card? How do I use the remote control? Installing the battery for the remote control Remote control buttons. Other features. How do I receive current traffic information? How do I play music or video? How do I receive audio through my vehicle speakers? Reference. What is GPS? How does my Mio receive GPS signals? Caring for your Mio. Troubleshooting. For more information.	
How do I insert a memory card? How do I use the remote control? Installing the battery for the remote control Remote control buttons. Other features. How do I receive current traffic information? How do I play music or video? How do I receive audio through my vehicle speakers? Reference. What is GPS? How does my Mio receive GPS signals? Caring for your Mio. Troubleshooting. For more information. Online support.	141516181818191919191920
How do I insert a memory card? How do I use the remote control? Installing the battery for the remote control Remote control buttons. Other features. How do I receive current traffic information? How do I play music or video? How do I receive audio through my vehicle speakers? Reference. What is GPS? How does my Mio receive GPS signals? Caring for your Mio. Troubleshooting. For more information.	
How do I use the remote control? Installing the battery for the remote control. Remote control buttons. Other features. How do I receive current traffic information? How do I play music or video? How do I receive audio through my vehicle speakers?. Reference. What is GPS? How does my Mio receive GPS signals? Caring for your Mio. Troubleshooting. For more information. Online support. Register your Mio with MioClub.	

Welcome

Thank you for purchasing this Mio. Please read this manual carefully before using your Mio for the first time. Keep this manual in a safe place and use as your first point of reference.

Important information for using the manual

It is important to understand the terms and typographical conventions used in this manual.

Formatting

The following formatting in the text identifies special information:

Convention	Type of Information		
Bold	Components or items displayed on screen, including buttons, headings, field names and options.		
Italics	Indicates the name of a screen.		

Icons

The following icons are used throughout this manual:

Icon	Description
①	Note
(Tip
<u>^</u>	Warning

Terms

The following terms are used throughout this manual to describe user actions.

Term	Description		
Press	Press and release a button quickly.		
Press and hold	Press and hold a button for 2-3 seconds.		
Тар	Press and release an item displayed on the touch screen.		
Tap and hold	Tap and hold an item displayed on the touch screen for 2-3 seconds.		
Select	Tap an item in a list or tap a command from a menu.		


Mounting your Mio in a vehicle


CAUTION:

- Never mount your Mio where the driver's field of vision is blocked.
- If the windscreen is tinted with a reflective coating, it may be athermic and impact the GPS reception. In this
 instance, please mount your Mio where there is a "clear area" usually just beneath the rear-view mirror.
- To protect your Mio against sudden surges in current, connect the in-car charger only after the car engine has been started.

Mounting on the windshield


V500 Series





Mounting on the dashboard

V700 Series



If you transfer the suction cup between vehicles, the adhesion could be reduced. To restore adhesion, please clean with water.

If you find it difficult to mount the suction cup to the dashboard, you can use the optional mounting plate to help with the mounting:



Installing the external antenna

An external antenna may be supplied with your Mio for better signal reception.

Connect the external antenna to the connector for external antenna on your Mio, then attach the antenna to the windshield (as shown in the diagram).

V500 Series



V700 Series



If you are in an area with very poor signal reception, try placing the antenna outside the car.

Enabling Traffic (TMC) Reception

Traffic information is not available on all models and is only available in selected countries.

Depending on the model of your Mio you can receive live traffic information*.

For information on using traffic information on your Mio, see the Software User Manual.

* Subscription may be required. See www.mio.com for more details.

Installing the optional digital TV card

1. Open the TV card compartment cover as shown below.



2. Insert the digital TV card into the socket (1), and then press down to lock the card into place (2).



If you need to remove the digital TV card, press the locking clips ($\mathbf{0}$) to release the card and then remove it ($\mathbf{2}$).



Replace the compartment cover.




Getting to know your Mio

V500 Series



0	Power switch	0	Connector for in-car charger, USB cable, home charger (sold separately) and TMC accessory kit (may be sold separately)
0	Antenna	8	Slot for MicroSD memory card
6	Slot for digital TV card (may be sold separately)	0	Microphone
4	Cradle slot	•	Remote sensor
6	Speaker	•	Touch screen
6	Connector for external antenna	@	Main Menu button

V700 Series



0	Power switch	0	Microphone
9	Antenna	•	Battery indicator
€	Slot for digital TV card (may be sold separately)	•	Main Menu button
4	Speaker	@	Connector for in-car charger and home charger (sold separately)
6	Cradle slot	®	Connector for headphones and TMC accessory kit (may be sold separately)
6	Connector for external antenna	4	Slot for MicroSD memory card (underneath cover)
0	Touch screen	1	Connector for USB cable (underneath cover)
8	Remote sensor		

How do I turn on my Mio?

Using the power switch



To turn on your Mio, slide the power switch to the **ON** position.

 To turn off your Mio, slide the power switch to the OFF position, then tap Sleep. Your Mio will enter a suspended state. When you next turn it on, your Mio will return to the last screen that you used.

To reset your Mio, slide the power switch to the **RESET** position. When your Mio has turned off, slide the power switch to the **ON** position

To lock the screen, slide the power switch to the **OFF** position, then tap **Lock**.

• To unlock the screen, slide the power switch to the **ON** position, then tap **Unlock**.

How do I charge the battery?

Your Mio has an internal battery that when fully charged, should provide power for up to 2 hours. The battery can take up to 4 hours to fully charge.



The battery may not be fully charged when you use your Mio for the first time.

CAUTION: For optimal performance of the battery, note the following:

- Do not charge the battery when the temperature is high (e.g. in direct sunlight).
- There is no need to fully discharge the battery before charging.
- When leaving your Mio for long periods, slide the power switch to the RESET position to save internal battery power.
- Failure to follow the battery usage instructions could cause damage to your Mio, battery and even bodily injury
 or property damage and will void the warranty.

The battery indicator light on your Mio indicates the level of internal battery charge:

- Green battery full
- Orange battery charging

How do I charge the battery in a vehicle?

To charge your Mio in a vehicle:

V500 Series: plug the in-car charger into on the bottom of your Mio and the other end into the vehicle power socket.

V700 Series: plug the in-car charger into $\Theta \Theta \Theta$ on the left side of your Mio and the other end into the vehicle power socket.

How do I charge the battery via my computer? (V500 Series only)



For optimal charging results, ensure that your Mio is turned off while connected to your computer.

- 1. Turn on your computer.
- Plug the large end of the USB cable directly into a USB port on your computer (not a USB hub) and plug the small end into

CAUTION: When your Mio is turned on and connected to a computer, it is recognized as an external mass-storage device. Do NOT delete any files that are pre-installed on your Mio. Deleting the files can cause your Mio to crash.

How do I charge the battery at home or work?

You can use an optional home charger to charge the battery.

To charge your Mio using a mains power socket:

V500 Series: plug the home charger cable into • on the bottom of your Mio and the mains power charger into the power socket.

V700 Series: plug the home charger cable into $\Theta \oplus \oplus$ on the left side of your Mio and the mains power charger into the power socket.

The home charger is not included with all models and may be purchased separately (see www.mio.com for details).

How do I insert a memory card?

CAUTION: Do not apply pressure to the centre of the memory card.



Hold the MicroSD card by the edges and gently insert it into the slot as shown in the above diagrams of your Mio.

To remove a card, gently push the top edge of the card inwards to release it, then pull it out of the slot.

Mio Technology does not guarantee the product's compatibilities with the storage cards from all manufacturers.

How do I use the remote control?

Installing the battery for the remote control

- 1. Remove the plastic film from the remote control.
- Insert a small rod, such as a straightened paperclip, into the eject hole and push firmly (●) and pull out the battery holder (●).




- 3. Place the battery in the battery holder. Be sure to have the + end of the battery face up.
- 4. Slide the battery holder back into place and make sure it clicks into position.

CAUTION:

- Do not heat, open, puncture, mutilate, or dispose of batteries in fire.
- Use only the correct type of battery.
- When not using the battery for a long period (more than one month), remove to prevent damage from battery corrosion.
- In case the battery leaks, clean the liquid and install a new battery.
- Check the regulations of your local government for proper battery disposal.

Remote control buttons



	Name	Description
0	GPS button	Returns to the <i>Map</i> screen of the navigation program. (The TV feature will be turned off if it is on.)
0	TV button	Turns on the TV feature.
€	Numeric keypad	Enters a channel number.
4	MODE	Switches the display to full screen or 4:3 mode.

	Name	Description	
9	4/▶	Switches to the previous or next channel.	
6	RETURN	Returns to the previous channel.	
0	Mute button	Mutes or unmutes the sound.	
8	ENTER	Press to confirm channel number choice.	
0	▲/ ▼	Adjusts the volume.	
0	Main Menu button	Returns to the Main Manu.	

Other features

How do I receive current traffic information?

Traffic information is not available on all models and is only available in selected countries.

You can receive current traffic information on your Mio using the Traffic Message Channel (TMC) service. The TMC service may require a subscription in some countries. See www.mio.com for details. Depending on your Mio model you may require a TMC accessory kit (may be sold separately).

For more information about Traffic, refer to the Software User Manual.

How do I play music or video?

Media playback is not available on all models and is only available in selected countries.

Using Media you can play music or video files that you have downloaded to your Mio or from your MicroSD card.

WARNING: The TV and video player features MUST NOT be used when driving. Using the features may cause an accident. Please make sure you comply with this warning. Mio accepts NO liability whatsoever in this regard.

For more information about playing music and video, refer to the Software User Manual.

How do I receive audio through my vehicle speakers?

FM transmitting and MP3 are not available on all models and are only available in selected countries.

Your Mio can be set to transmit sound at a particular FM frequency which you can then receive through your vehicle radio. This means that you can hear map voice guidance, mp3 files and video files clearly and loudly through your vehicle speakers.

WARNING: Products with FM Transmitter feature may be operated in the following countries:

AT	BE	BG	CH	CZ	DE	DK	EE
ES	FI	GB	HU	ΙE	IS	IT	LI
LT	LU	LV	MT	NL	NO	PL	PT
RO	SE	SI	SK				

The FM transmitter function is not allowed to use in Cyprus, France and Greece. Please turn off the FM Transmitter in those areas.

• For more information about FM transmitting, refer to the Software User Manual.

Reference

What is GPS?

The Global Positioning System (GPS) is available at any time, free of charge, and is accurate to within 5m (15ft). GPS navigation is made possible by a network of satellites that orbit the Earth at around 20,200km (12,552mi). Each satellite transmits a range of signals which are utilized by GPS receivers, such as your Mio, to determine an exact location. Although a GPS receiver can detect signals from up to 12 satellites at any time, only four signals are required to provide a position or "GPS fix" (latitude and longitude), for vehicle navigation systems.

How does my Mio receive GPS signals?

Your Mio receives GPS signals via the internal GPS antenna. To guarantee the optimum GPS signal strength, ensure your Mio is outdoors, or in a vehicle outdoors, and has an unobstructed view of the sky. GPS reception is not usually affected by weather, however, very heavy rain or snow may have a negative effect on your reception.





Caring for your Mio

Taking good care of your Mio will ensure trouble-free operation and reduce the risk of damage to your Mio:

- Keep your Mio away from excessive moisture and extreme temperatures.
- Avoid exposing your Mio to direct sunlight or strong ultraviolet light for extended periods of time.
- Do not place anything on top of your Mio or drop objects on your Mio.
- Do not drop your Mio or subject it to severe shock.
- Do not subject your Mio to sudden and severe temperature changes. This could cause moisture condensation inside the unit, which could damage your Mio. In the event of moisture condensation, allow your Mio to dry out completely before use.
- The screen surface can easily be scratched. Avoid touching it with sharp objects. Non-adhesive generic screen
 protectors designed specifically for use on portable devices with LCD panels may be used to help protect the
 screen from minor scratches.
- Never clean your Mio when it is turned on. Use a soft, lint-free cloth to wipe the screen and the exterior of your Mio.
- Do not use paper towels to clean the screen.
- Never attempt to disassemble, repair or make any modifications to your Mio. Disassembly, modification or any attempt at repair could cause damage to your Mio and even bodily injury or property damage and will void any warranty.
- Do not store or carry flammable liquids, gases or explosive materials in the same compartment as your Mio, its parts or accessories.

Troubleshooting

If you encounter a problem you cannot solve, contact an authorized service centre for assistance.

Problems	Solutions
Power does not turn on when using battery power.	The remaining battery power may be too low to operate your Mio. Charge the battery using the in-car charger, home charger (sold separately) or USB cable, then try again.
Screen responds slowly.	The remaining battery power may be too low to operate your Mio. If the problem still persists, reset your Mio.
Screen freezes.	Reset your Mio.
Screen is hard to read.	Increase the screen brightness.
Cannot establish a connection with a computer.	Ensure that your Mio and your computer are both turned on before trying to establish a connection.
	Make sure that the cable is securely plugged into the USB port on your computer and on your Mio. Connect the USB cable directly to your computer, not a USB hub.
	Reset your Mio before connecting the USB cable. Always disconnect your Mio before you restart your computer.

For more information

Online support

For 24/7 help and support with Mio products, visit our Technical Support website at: www.mio.com

Register your Mio with MioClub

If you have a faulty product or you would like to speak to a member of our Technical Support team, register your Mio on MioClub to obtain the Technical Support phone numbers for your region.

Disclaimer

Mio operates a policy of ongoing development. Mio reserves the right to make changes and improvements to any of the products described in this document without prior notice. Mio does not warrant that this document is error-free. The screenshots and other presentations shown in this manual may differ from the actual screens and presentations generated by the actual product. All such differences are minor and the actual product will deliver the described functionality as presented in this User Manual in all material respects.

Compliance



WARNING This product, its packaging and its components contain chemicals known to the State of California to cause cancer, birth defects or reproductive harm. This Notice is being provided in accordance with California's Proposition 65.



For regulatory identification purposes:

- Moov V500 Series is assigned a model number of N248.
- Moov V700 Series is assigned a model number of N236.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Marking labels located on the exterior of your Mio indicate the regulations that your model complies with. Please check the marking labels on your Mio and refer to the corresponding statements in this chapter. Some notices apply to specific models only.



Products with the CE marking comply with Radio & Telecommunication Terminal Equipment Directive (R&TTE) (1999/5/EC), the Electromagnetic Compatibility Directive (2004/108/EC) and the Low Voltage Directive (2006/95/EC) - issued by the Commission of the European Community. Compliance with these directives implies conformity to the following European Standards:

EN 301 489-1: Electronic compatibility and Radio spectrum Matters (ERM), Electromagnetic Compatibility (EMC) standard for radio equipment and services; Part 1: Common technical requirements.

EN 301 489-9: (Bluetooth and FM Transmitter): Electromagnetic compatibility and Radio spectrum Matters (ERM), ElectroMagnetic Compatibility (EMC) standard for radio equipment and services; Part 9: Specific conditions for wireless microphones, similar Radio Frequency (RF) audio link equipment, cordless audio and in-ear monitoring devices.

EN 301 489-17: Electronic compatibility and Radio spectrum Matters (ERM), Electromagnetic Compatibility (EMC) standard for radio equipment and services; Part 17: Specific conditions for 2.4 GHz wideband transmission systems and 5 GHz high performance RLAN

EN 300 328 (Bluetooth): Electromagnetic compatibility and Radio spectrum Matters (ERM); Wideband Transmission systems; Data transmission equipment operating in the 2.4 GHz ISM band and using spread spectrum modulation techniques; Harmonized EN covering essential requirements under article 3.2 of the R&TTE Directive

EN 301 357-2 (FM Transmitter): Electromagnetic compatibility and Radio spectrum Matters (ERM); Cordless audio devices in the range 25 MHz to 2000 MHz; Part 2: Harmonized EN covering essential requirements of article 3.2 of the R&TTE Directive.

L'utilisation de cet appareil n'est pas autorisée en France.

La Fonction de transmission FM n'étant pas autorisée en France, elle doit rester désactivée.

EN55013: Sound and television broadcast receivers and associated equipment. Radio disturbance characteristics. Limits and methods of measurement.

EN55020: Sound and television broadcast receivers and associated equipment. Immunity characteristics. Limits and methods of measurement

EN 55022: Radio disturbance characteristics

EN 55024: Immunity characteristics

EN 50332: Prolonged listening of music in maximum volume can damage the ears.

EN 61000-3-2: Limits for harmonic current emissions

EN 61000-3-3: Limitation of voltage fluctuation and flicker in low-voltage supply system

IEC 60950-1:2001: Product Safety

The manufacturer cannot be held responsible for modifications made by the User and the consequences thereof, which may alter the conformity of the product with the CE Marking.

Declaration of conformity

Hereby, Mio Technology declares that this N236/N248 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

The FM transmitter function is not allowed to use in Cyprus, France and Greece. Please turn off the function in those areas. (For models with FM transmitter capabilities only)

This equipment may be operated in:

AT	BE	BG	CH	CZ	DE	DK	EE
ES	FI	GB	HU	IE	IS	IT	LI
LT	LU	LV	MT	NL	NO	PL	PT
RO	SE	SI	SK				

The software is based in part on the work of the Independent JPEG Group.

The software application uses modified versions of the Minimal XML Library, Flickr Library and Python Library. The libraries and their use are covered by the GNU Lesser General Public License (www.gnu.org/licenses/lgpl.html). The modified source code is available from the following URLs:

- Minimal XML Library: http://download.mio.com/opensource/gnu/mxml.zip
- Flickr Library: http://download.mio.com/opensource/gnu/FlickrNet.zip
- Python Library: http://download.mio.com/opensource/gnu/python25.zip

Copyright

© 2009 MiTAC International Corporation. Mio is either a registered trademark or trademark of MiTAC International Corporation and is used under licence by Mio Technology Limited. All rights reserved.

The software contains proprietary information of MiTAC International Corporation; it is provided under a licence agreement containing restrictions on use and disclosure and is also protected by copyright law. Reverse engineering of the software is prohibited.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Mio.

Back-On-Track, Drive-Away, Slide Touch, MioMore Desktop, Mio Spirit, Navman Spirit and Turn-by-Turn are either registered trademarks or trademarks of MiTAC International Corporation and are used under licence by Mio Technology Limited. All rights

MicroSD and the MicroSD logo are trademarks of SD Card Association.

All other trademarks and registrations are the property of their respective owners.

Revision: R04 (8/2009)



Moov V Series User Manual

Important Safety Information

PLEASE READ CAREFULLY BEFORE INSTALLING PRODUCT IN VEHICLE

This is the safety alert symbol. It is used to alert you to potential personal injury had Obey all safety messages that follow this symbol to avoid possible injury or death.			
≜ WARNING	WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.		
▲ CAUTION	CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.		
CAUTION	CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.		



Removing original equipment, adding accessories or modifying your vehicle could affect the vehicle's safety or make it illegal to operate in some jurisdictions.

Follow all product instructions and all instructions in your vehicle owner's manual regarding accessories or modifications.

Consult your country's and/or state's laws regarding operation of a vehicle with any accessories or modifications.

It is your sole responsibility to place, secure and use your Mio in a manner that will not cause accidents, personal injury or property damage. Always observe safe driving practices.

Do not mount your Mio or attach the antenna in a way that may interfere with the safe operation of the vehicle, the deployment of air bags or other safety equipment.

Do not operate your Mio while driving.

Before you use your Mio for the first time, familiarise yourself with your device and its operation.

On main roads, the distance to an exit calculated by your Mio may be further than the distance shown on road signs. Road signs show the distance to the start of an exit while your Mio shows the distance to the next intersection, i.e., the end of the exit ramp or road. To prepare to exit a road, always follow distance information on road signs.

The use of information regarding safety or speed camera locations may be subject to local laws in the country of use. You are responsible for checking that you can legally use the information in your country or in the country where the information will be used.

Products with FM Transmitter feature may be operated in the following countries: Andorra, Austria, Belgium, Denmark, Finland, Germany, Ireland, Liechtenstein, Luxembourg, Monaco, Netherlands, Norway, Portugal, San Marino, Spain, Sweden, Switzerland, Great Britain and Vatican City. The FM Transmitter is not allowed to be used by law in France, Andorra, San Marino, and Vatican City. Please turn of the FM Transmitter in those areas.

The TV, video player and AV input features MUST NOT be used when driving. Using this feature may cause an accident. Please make sure you comply with this warning. Mio accepts NO liability whatsoever in this regard.



Do not handle your Mio while it is hot. Let the product cool, out of direct sunlight.

At full power, prolonged listening to your Mio via headphones or earphones can damage the ear of the user.



Do not expose your Mio to direct sunlight in an unattended vehicle for prolonged periods. Overheating may damage the unit.

To discourage theft, do not leave your Mio, mounting bracket or any cables in plain view in an unattended vehicle.

Warning Notice to Drivers in the United States

State law may prohibit drivers in states such as Arizona, California and Minnesota from mounting objects on their windscreens while driving. Please make sure you research and follow your most current State laws. An alternative mounting option may be provided in the box with your product; or see mio.com for additional mounting alternatives. Mio does not take any responsibility for any fines, penalties, or damages that may be incurred as a result of disregarding this notice.

Failure to adhere to these warnings and cautions may lead to death, serious injury or property damage. Mio disclaims all liability for installation or use of your Mio that causes or contributes to death, injury or property damage or that violates any law.

Contents

Important Safety Information	2
Welcome	5
How do I use the touch screen?	6
How do I get started?	7
Main Menu	8
How do I go from A-B?	9
What if I miss a turn?	
Using the Keyboard screen	
How can I set my keyboard preference?	
How do I plan my first trip?	
How do I set my route preferences?	12
How do I search for a Point of Interest (POI)?	13
How do I view my route?	15
How do I use the Explore map?	
How do I find a POI using the POI Cluster?	
How do I find a POI on my route?	
, ,	
How do I preview a route?	19
How do I view my route statistics?	20
How do I navigate to a recent place?	
How do I find the nearest POIs?	
My Places	
How do I save a location as My Place or Home?	23
How do I navigate to a location I have saved?	
How do I navigate to Home? How do I edit the name of a location in My Places?	24
How do I delete a saved location?	25
How do I delete a saved location?	25
How do I navigate to a NavPix TM in an album?	26
How do I view a NavPix TM in full-screen?	27
How do I save a NavPix TM as a favourite?	28
How do I add or edit a NavPix [™] title?	28
How do I delete NavPix [™] from an Album?	28
How do I capture a location or a journey?	
How do I capture the GPS co-ordinates of my location?	
How do I capture a location with a voice recording?	
How do I navigate to a location I have captured?	30
How to view a journey I have captured?	
How to share a journey I have captured?	
How do I create a trip with multiple stops?	31
How do I delete a waypoint from my trip?	33
How do I change the order of the waypoints?	33
How do I edit a planned trip title?	34
How do I skip a waypoint during a multi-stop trip?	34
What is Travel Book?	35
How do I search for a POI in a city I am visiting using Travel Book?	
How do I add / remove city guides on my Mio?	36
How do I watch digital TV?	
Watching TV programs	
vvalcriinu i v Diouranis	

Changing TV settings	38
How do I play media?	39
Playing audio files	39
How do I listen to a music file on my Mio?	
Playing video files How do I view a video file on my Mio?	4C
How do I view a video file on full screen?	41
How do I receive audio through my vehicle speakers?	
How do I set the audio output channel of my Mio through my car's FM radio?	
How do I receive current traffic information via TMC?	
How will I know when a Traffic Event occurs?	
Traffic Overview screen	
How do I view a list of all events on my route?	
How do I view traffic details?	
How do I know if a detour is recommended?	
How do I avoid an event on my route?	47
How do I cancel a detour around an event on my route?	
Traffic messagesTraffic preferences	
TMC service	
Traffic Event Notification	
Select event sorting type	
Walking mode	
How can I set my navigation mode to walking?	
What can I customise?	
Volume	
Safety options	
Route options	
Map display	
Screen brightness	
Language	
Voice	
Power management	
Units	
Touch audio	
List scrolling	
Delete saved information.	
Reset GPS	
Restore factory defaults	
Shop demo	
Screen saver	
About	59
Point of Interest categories	60
Traffic and other TMC Events	63
Appendices	64
For more information	
Speed Limit	
Safety Camera POIs	
FM Transmitter	
Disclaimer	
Copyright	65

Welcome

Thank you for purchasing this Mio. This manual has been prepared to guide you through the operation of your Mio from first set-up through to continuous use. Please read this manual carefully before using your Mio for the first time. Keep this manual in a safe place and use as your first point of reference.

Important information for using the manual

It is important to understand the terms and typographical conventions used in this manual.

Formatting

The following kinds of formatting in the text identify special information:

Convention	Type of Information	
Bold	Mio components or items displayed on screen, including buttons, headings, field names and options.	
Italics	Indicates the name of a screen.	

Icons

The following icons are used throughout this manual:

Icon	Description
	Note
①	Тір
<u>^</u>	Warning

Terms


The following terms are used throughout this manual to describe user actions.

Term	Description	
Тар	Press and release an item displayed on the touch screen.	
Tap and hold	Tap and hold an item displayed on the touch screen for 2-3 seconds.	
Select	Tap an item in a list or tap a command from a menu.	
Drag	Hold your fingertip on the screen and drag up/down/left/right or across the screen.	

How do I use the touch screen?

By default, your Mio starts in button mode, to scroll up or down, or dock/undock use the buttons to the right of the main page.






You can change to Slide TouchTM mode: tap **MY MIO** \rightarrow **List Scrolling**.

In Slide TouchTM mode, your Mio touch screen options change dynamically:

- To see all options on a menu, drag the screen up or down.
- To display the next screen, tap an icon or select an option.
- To dock a menu to the left, tap the left edge of the menu. To dock a menu to the right, tap the right edge of the menu.





Main Menu options and the order of the options may differ from the above, depending on your region, maps installed or model of Mio.

How do I get started?

The first time you use your Mio it may take several minutes to establish a GPS connection.

How do I turn my Mio on for the first time?

To get started for the first time, complete the following steps:

- 1. Read the Important Safety Information (see "Important Safety Information" on page 2).
- Position your Mio in your vehicle.

Follow the instructions in the Hardware User Manual.

CAUTION Ensure that your Mio does not obstruct the driver's view, or interfere with the operation of the vehicle airbags and safety devices.

3. Turn your Mio on

Your Mio will turn on and display the Language screen.

4. Select your preferred language

From the Select Language screen, tap your preferred language.

You can change your preferred language while using your Mio, see "Language" on page 55.

5. Read the warning message

- The Safety Agreement screen will display after you have selected your preferred language.
 Read the Safety Agreement message.
- To confirm that you have read and understood the message, tap Accept. The Tutorial will display.

6. View the Tutorial

- To skip the Tutorial screens, tap Skip.
- To move forward through the Tutorial screens, tap Next.

To view the previous screen, tap

To prevent the *Tutorial* from displaying on each start-up, tap the **Show on start-up** option to deselect it.

When you have finished the *Tutorial*, the *Map* screen will display. If you have a GPS fix, your current location will display on the map.

Main Menu

The Main Menu is your starting point for searching for a destination. The Main Menu also allows you to customise your Mio, receive updated traffic information (not available on all models) and make and receive phone calls (not available on all models).

To display the Main Menu, press on your Mio at any time.







Q	Search for places, areas and streets to help plan your route.	0	Access your saved locations, NavPix TM , journeys, etc.
+	Explore the area around your current position or destination.		Search for information and POIs for the city you are visiting using Travel Book.
4	Display the map screen.	7	Record GPS co-ordinates of a location or a journey.
Ŏ	Allows you to watch digital TV (if an optional digital TV card is installed on your Mio).	#	Configure your Mio to enhance your navigation experience.
	Search for the nearest petrol stations.	1	Add or begin a planned trip with multiple waypoints
A	Set or navigate to your home address.	\triangle	Receive live traffic information on your route and set traffic preferences. (may require optional TMC kit or subscription, available separately)
U	Play stored audio or video files installed on your Mio or on a memory card.	+	Search for the nearest emergency services, including hospitals and police.
11	Search for the nearest restaurants, cafes, fast-food premises and other dining establishments.	60	Search for the nearest tourist attractions.
P	Search for the nearest parking places.	S	Search for the nearest banks and ATMs.

Main Menu options and the order of the options may differ from the above, depending on your region, maps installed or model of Mio.

How do I go from A-B?

Your Mio is equipped with maps that provide street-level detail for door-to-door navigation, including Points of Interest such as accommodation, parking areas, petrol stations, railway stations and airports.

When you	Then	
need to search for an address	tap FIND then Find a street address to search for the address. If you know the address you are looking for, use the Map screen to enter an address	
need to find a named site, feature, landmark or public venue	tap FIND then Find by keyword to search for a Point of Interest.	
want to navigate to a recently visited location	tap MY PLACES then Recent places.	



WARNING For your safety, enter destination information before you start a journey. Do not enter a destination while driving.

What if I miss a turn?

Back-On-Track™ Automatic Rerouting

You will be redirected if you make a wrong turn. A message informing you that your route is being re-calculated will display at the top of the screen.

To cancel a route re-calculation, tap \mathbf{x} . A warning will display asking you to confirm the cancellation. If confirmed, both the re-calculation and your current route will be cancelled.

Using the Keyboard screen

The *Keyboard* screen will display when you are required to enter text, such as when searching for a street name. Search results will be listed in matching order, with the closest matches appearing on the screen. A maximum of 99 results will display.

The Keyboard screen can display with various layouts depending on the information you need to enter, including alphabet, number, alternate characters and combinations of these.

- To select a character, tap the character.
- To delete a character, tap DEL.
 Tap and hold DEL to delete the entire text.
- To display more characters, tap ito select an alternate keyboard screen.

How can I set my keyboard preference?

From the *Keyboard* screen, tap

The *Keyboard* preference screen will display.



How does predictive text (abc, def...) work?

Predictive text allows addresses to be searched by a single key-press for each letter, as opposed to the multiple key-presses. As you enter a letter of an address, your Mio will compare all possible combinations against the maps you have installed and determine which address you intended to type.

For example:


To enter London, tap JKL MNO MNO DEF.

Your Mio will compare all possible combinations and display **London** in the list of search results. You can add further letters to narrow the search.

How do I plan my first trip?

Using your Mio to plan your first trip is easy. There are several ways to select your destination. Complete the following to navigate to a street address that you know using the **FIND** address wizard.





Complete the following:

+ Explore this area

If you want to	Then	
calculate the route, open the <i>Map</i> screen and start navigating	tap The Map screen will display.	
save the location as Home	tap . The Save screen will display. tap Save as Home.	
save the location as a favourite	tap . The Save screen will display. tap Save as My Place.	
explore the area near the location	tap	

How do I set my route preferences?

You can enhance your navigation experience by modifying aspects of your route and route calculations.

From the MAP screen, tap the undock button and tap Route options.
 The Route options screen will display.

OR



The Route options screen will display.



2. Complete the following:


Complete the following.			
If you want to	Then		
set route type options for your route	tap Route type. The Route type screen will display.		
	Solect your route type preference form the list.		
	Shortest - The route with the shortest physical length		
	Easiest - The simplest route with the least number of turns and favours motorways where appropriate		
	Economical - The route with least number of stops, turns and urban areas which should save on fuel usage		
	Fastest - The route that should be the fastest when navigating		
	Selecting Shortest route type over Fastest route type can cause a much longer journey time.		
set types of road options for your route	tap Types of road . The <i>Types of road</i> screen will display.		
	 select your road preference form the list. 		
	Avoiding ferry routes may prevent you from navigating between certain countries, even when a bridge or tunnel exists.		
set your map screen preference	tap the Map option to select between a 3D or 2D view of the <i>Map</i> screen.		
Set the number of turns displayed on your	tap Displayed turns.		
turn list	The Displayed turns screen will display.		
	select your turn preference form the list.		
display Junction views on your route	tap the Junction views option to turn it On or Off .		
set how you want to receive the safety camera alerts	tap My Places alerts. The My Places alerts screen will display.		
	 select a safety camera category from the list and select the desired setting. 		
record mileage for your route to generate expense reports	tap the Mileage recorder option to turn it On or Off.		

If you want to	Then	
record a GPS log of your trip	tap the GPS logging option to turn it On or Off.	
record your journey	tap the Capture Journey option to turn it On or Off.	

How do I search for a Point of Interest (POI)?

A POI is a named site, feature, landmark or public venue which can be displayed as an icon on the map. POIs are grouped by category, such as petrol stations, parks, beaches and museums.














Complete the following:

If you want to	Then
calculate the route, open the <i>Map</i> screen and start navigating	■ tap ℂ . The <i>Map</i> screen will display.
save the location as a favourite	■ tap ♥. The Save screen will display. ■ tap Save as My Place.
place a phone call to the POI	tap . This feature is not available on all models.

If you want to	Then
explore the area near the location	 tap →. The Explore Map screen will display. tap the undock button or tap the docked menu in Slide Touch™ mode to see the menu options. complete one of the following: tap Streets to explore streets near your location tap Areas to explore areas around your location tap a POI category to explore POIs near your location

How do I view my route?

When a route has been calculated, the *Map* screen will display. You will be directed to your destination by spoken and visual instructions. Tap anywhere on the Map screen to show all options.



	Item	Description
0	Direction and distance of next turn	The direction and distance to your next turn. Tap b to repeat the vocal instruction.
0	Current route	Your current route is highlighted.
6	Current position	In Driving mode, your current position is marked with
		In Walking mode, your current position is marked with
4	Add waypoint to trip	Adds a location as a waypoint on your trip. Tap to remove the waypoint from your trip.
6	Detour	Detours your route to avoid next 1, 2, 5, 10 or 20 miles.
6	Pause route	Pauses your current route. ■ Tap ► to unpause your current route.
0	Cancel route	Cancels your current route.
8	Volume	Mutes or unmutes the volume.
9	Distance and Time Information	Tap to expand and select the following options: DTG (Distance to Go) TTG (Time to Go) km/h or mph (speed) and compass heading ETA (Estimated Time of Arrival) Time
0	Zoom	 To zoom out, tap and hold To zoom in, tap and hold +.

How do I use the Explore map?

The *Explore* map allows you to explore the local area to find Points of Interest (POIs) or navigate to an address. If you do not have a GPS fix, the map will display your last known position.

- Tap and drag the map to explore your desired local area.
- Tap the map to display a POI Cluster showing POIs in the surrounding area. Tap a POI icon to show more
 information and navigate to the POI.





	Item	Description
0	+, -	To zoom in or out, tap and hold – or +. Zooming in or out will increase or decrease the area contained within the Explore area.
0	②	Indicates the direction of your current position. Tap to return the map to your current position.
€	POI Cluster	To display a POI Cluster, tap an area on the <i>Explore</i> map. Tap an icon or street name in the POI Cluster to view information and options.
		Increases or decreases the number of POIs displayed on your map, which will affect the number of results returned. Only visible POIs will be displayed in the POI cluster.*

^{*} Zooming out too far will reduce the number of POIs displayed to zero and hence return no results.

How do I find a POI using the POI Cluster?







Tapping on the POI selected (in red square) will bring up the Explore menu with the POI destination details.

Complete the following:

If you want to	Then
calculate the route, open the Map	■ tap ್ .

If you want to	Then
screen and start navigating	The <i>Map</i> screen will display.
save the location as a favourite	tap ♥. The Save screen will display. tap Save as My Place.
place a phone call to the POI	tap L This feature is not available on all models.

How do I find a POI on my route?











Complete the following:

If you want to	Then
calculate a new route, open the <i>Map</i> screen and start navigating	■ tap C . The <i>Map</i> screen will display.
add the location as a waypoint	tap Add as waypoint. The Map screen will display and your route will be recalculated.
save the location as a favourite	■ tap ♥. The Save screen will display.
	tap Save as My Place.
place a phone call to the POI	■ tap 📞
	This feature is not available on all models.

How do I set my POI preferences?

Points of Interest (POIs) are grouped into categories. You may choose to either display (or hide) icons of all POI categories on the map screens, or only display the icons from selected categories.

For example, you may only be interested in entertainment venues and want to disable other categories such as schools.

From the Explore screen, tap the undock button or tap the docked menu in Slide Touch[™] mode and tap Places settings.

The Places settings screen will display.



2. Complete the following:

If you want to	Then
display all POI icons (i.e. icons from all categories)	tap Show all.
display no POI icons	tap Hide all .
	Hiding POIs will stop you from finding them when using explore mode/cluster search.
select a specific POI category icon for display on the map screen	 tap the required POI category to Show or Hide on the map screen.
	 Repeat until all required categories are selected.

Your preferences are automatically saved.

How do I preview a route?

Route demonstration allows you to:

- Preview a route.
- Plan and view a route without a GPS fix, such as when you are inside a building.

The following steps will show you how to preview a route.

Select a departure point.

If you have a GPS fix, you do not need to select a departure point unless you want the demonstrated route to start elsewhere.



The Find screen will display.

- b) Tap the undock button or tap the docked menu in Slide TouchTM mode to undock the menu screen.
- c) Scroll down and tap **Leaving from**. The *Leaving from...* screen will display.
- d) Tap **Find a place**, then use the Address Wizard to find your departure point.
- 2. Select a destination point using the **FIND** address wizard, the My Places menu or the *Explore* map.
- 3. From the *Preview* screen, tap \(\bigsize{\circ}\).
 Your route is calculated and the *Map* screen will display.
- Tap the undock button or the edge of the docked menu. The GO screen will display.
- 5. Tap Route simulation.

The Map screen will display the calculated route in route simulation mode.

6. Complete the following:

If you want to	Then
increase the speed of the simulation	tap .
decrease the speed of the simulation	tap 🎳.
pause the simulation	tap II .
cancel the simulation	tap ×.

How do I view my route statistics?

Your Mio provides information on your:

- distance to go
- estimated time of arrival
- distance travelled
- average speed
- maximum speed
- time taken for trip
- stationary time.

To view your route statistics during a planned route:



The Map screen will display.

- Tap the undock button or tap the docked menu in Slide Touch[™] mode to undock the menu screen.
- 3. Tap. The Route Statistics screen will display.




How do I navigate to a recent place?

To make navigating to an address easier, your Mio will automatically save all your start locations and destinations in a list of recent places.



The My Places screen will display.

- 5. Tap the undock button or tap the docked menu in Slide TouchTM mode to undock the menu screen.
- Tap Recent places.
 The Recent Places screen will display.



7. Tap a recent place.
The *Preview* screen will display.




8. Complete the following:

If you want to	Then
calculate the route, open the <i>Map</i> screen and start navigating	■ tap ℂ . The <i>Map</i> screen will display.
save the location as a favourite	■ tap ♥. The Save screen will display. ■ tap Save as My Place or tap Save as Home.
explore the area near the location	tap The Explore Map screen will display. tap the undock button or tap the docked menu in Slide Touch™ mode to see the menu options. complete one of the following: tap Streets to explore streets near your location tap Areas to explore areas around your location tap a POI category to explore POIs near your location
save it as a waypoint in your current route	■ tap Recent places. ■ select a location from the list. ■ tap Add as waypoint.


How do I find the nearest POIs?

1. Complete the following:




- 2. A list of the selected POI category based upon your current location is displayed.
- 3. Tap the desired item from the list, then tap \P on the Preview screen.





If you have a route planned, two distances will display: distance from your current location and detour distance.





My Places

My Places has all your saved and captured locations. It also contains POIs, NavPixTM and albums you have downloaded onto your Mio via MioMore Desktop.

How do I save a location as My Place or Home?


1. Search for an address until the *Preview* screen is displayed.



Tap Add to My Places.
 The Save screen will display.



3. Tap **Save as My Place**. The *Preview* screen will display.



4. Complete the following:

If you want to	Then
calculate the route, open the <i>Map</i> screen and start navigating	■ tap ℂ . The <i>Map</i> screen will display.

If you want to	Then
explore the area near the location	tap The Explore Map screen will display. tap the undock button or tap the docked menu in Slide Touch™ mode to see the menu options. complete one of the following: tap Streets to explore streets near your location tap Areas to explore areas around your location tap a POI category to explore POIs near your location
add or edit location name	tap Rename. The Keyboard screen will display. after you have entered a name for the favourite, tap OK. The My Places preview screen will display.
delete the favourite location	■ tap 🗓.

How do I navigate to a location I have saved?



 \rightarrow

The My Places screen will display.

 Tap the favourite destination you want to travel to. The *Preview* screen will display.



3. Tap **C**. Your Mio will calculate the route from your current location. The *Map* screen will display.

How do I navigate to Home?

If you have not set an address as Home, the first time you try to navigate to Home you will be prompted to search for an address using the address-entry wizard.



The My Places screen will display.

Tap Home.
 The Preview screen will display.



3. Tap \(\bigsigma\).
Your Mio will calculate the route from your current location. The Map screen will display.

How do I edit the name of a location in My Places?

The My Places screen will display.

Select a location to edit.
 The *Preview* screen will display.



Tap Rename.

The Keyboard screen will display.

4. After you have edited the name, tap **OK**. The *Preview* screen will display.

How do I delete a saved location?



The My Places screen will display.

- Select the location you would like to delete.
 The *Preview* screen will display.
- Tap Delete.
 The location is deleted. The My Places screen will display.

How do I navigate to a NavPixTM?

NavPixTM is an image or picture, normally of a location, which contains embedded GPS co-ordinates that you can navigate to.

Sample NavPix[™] images may be pre-installed on your Mio. You can search online and download NavPix[™] images from the Flickr[™] or NavPix[™] website.

To navigate to a NavPixTM location, either a GPS fix must have been available when the NavPixTM was taken, or GPS co-ordinates have been added using MioMore Desktop. See the *MioMore Desktop Manual* for more information on importing NavPixTM to your Mio.

The My Places screen will display.

 Tap the NavPixTM you want to navigate to. The NavPix Details screen will display.



3. Complete the following:

If you want to	Then
calculate the route, open the <i>Map</i> screen and start navigating	■ tap C . The <i>Map</i> screen will display.
view NavPix TM location on the map	tap Show on map . The <i>Explore Map</i> screen will display.
explore the area near the NavPix TM location	■ tap ↑ . The Explore Map screen will display.
	 tap the undock button or tap the docked menu in Slide Touch[™] mode to see the menu options.
	tap on the map to explore POIs near the location.
edit NavPix [™] name	 tap Rename. The Keyboard screen will display.
	 after you have entered a name for the favourite, tap OK. The NavPix Details screen will display.
delete the NavPix TM from My Places	■ tap

NavPixTM can be deleted from an Album on your Mio internal memory or your memory card. When a NavPixTM has been saved as a Favourite destination, you will not delete the Favourite if you subsequently remove the NavPixTM

How do I navigate to a NavPixTM in an album?

The albums contain all your pictures and displays them as thumbnails.





	Item	Description
0	Slide Show	Displays all images in the album as a full-screen slideshow.
0	Album title	The title of the album.
€	R _j	Indicates that the picture is a NavPix TM , with embedded GPS co-ordinates.
0	NavPix [™] thumbnail	A thumbnail of a NavPix TM contained in the album.
		■ To select a NavPix TM , tap the thumbnail. The NavPix Details screen will display.

How do I view a NavPixTM in full-screen?

 From the NavPix Details screen, tap the thumbnail of the NavPixTM. The NavPixTM will appear in full-screen.

OR

From the *Album detail* screen, tap **Slide Show**. The **NavPix**TM will appear in full-screen

2. Tap the screen to display the control buttons. The buttons disappear after a few seconds.



3. Complete the following:

If you want to	Then
zoom into the NavPix TM	tap (•)
zoom out of the NavPix TM	tap Q.
rotate the NavPix [™]	tap The NavPix TM will rotate 90 degrees anticlockwise each time is tapped; the NavPix TM is saved at the new angle.
view parts of the NavPix[™] not displayed on-screen	tap and hold the NavPix [™] , then drag across the screen.
return to the NavPix Details screen	tap 🛑

How do I save a NavPixTM as a favourite?

- You cannot save a NavPixTM as a favourite if GPS co-ordinates are not available.
- From the Album screen, tap a NavPixTM.
 The NavPix Details screen will display.
- 2. Tap 💟. The Save screen will display.
- 3. Complete the following:

If you want to	Then
save the NavPix TM as a Favourite	tap Save as My Place . The NavPix TM is saved and the <i>NavPix Details</i> screen will display.
save the NavPix TM as Home	tap Save as Home . The NavPix TM is saved and the <i>NavPix Details</i> screen will display.

How do I add or edit a NavPix[™] title?

A title can be added to your **NavPix**TM or an existing title can be edited. The title can be a maximum of 34 characters.

- From the My Places screen, tap a NavPixTM you want to edit. The Preview screen will display.
- 2. Tap **Rename**. The *Keyboard* screen will display.
- After you have edited the title, tap **OK**. The NavPix Details screen will display.

How do I delete NavPix[™] from an Album?

- From the Album screen, tap a NavPixTM.
 The NavPix Details screen will display.
- 2. Tap 📆.

How do I capture a location or a journey?

The capture functionality is not available on all models.

Your Mio has a capture feature which allows you to record GPS co-ordinates of a location, capture a location with a voice recording and capture a journey and save them so you can navigate back at a later time.

How do I capture the GPS co-ordinates of my location?




The Capture screen will display.



2. Tap Save.

You will hear a shutter sound to indicate that the GPS co-ordinates have been saved. The location is saved in My Places.

How do I capture a location with a voice recording?



The Capture screen will display.

2. Tap ... The Sound screen will display.



Tap Record to start recording your voice.
 Tap Stop to stop the recording.

Tap Save.

You will hear a shutter sound to indicate that the recording has been saved. The location is saved is saved in My Places.

How do I capture a journey?

- To enable capturing of journeys, you must first enable Capture Journey from
 Poute options
 → Route options
- At the beginning of the journey you would like to record, tap Clear.
 All travel that you have made (i) since midnight, (ii) the previous time you tapped Clear, or (iii) last captured a journey, will be deleted.
- 2. Travel on your journey. Your Mio will keep a record of where you travel.
- 3. At the end of your journey,
 The Capture screen will display.

 →



Tap Save, then Yes.
 The journey is saved is saved in My Places.

How do I navigate to a location I have captured?

The My Places screen will display.

- Tap the captured destination you want to travel to. The *Preview* screen will display.
- Tap \(\bigcup \).
 Your Mio will calculate the route from your current location. The Map screen will display.

How to view a journey I have captured?

The My Places screen will display.

 Tap the captured journey you want to view. The *Preview* screen will display.

How to share a journey I have captured?


You can share a saved journey via MioMore Desktop. See the *MioMore Desktop Manual* for more information on sharing a saved journey.

How do I create a trip with multiple stops?


You can use the *Planned Trips* screen to set multiple stops or waypoints for your trip. Your route will be calculated to go via each of these points in the specified order.



The Planned Trips screen will display.



Tap Create New Trip.
 The Edit screen will display.



Tap the location name.
 The Keyboard screen will display.



- 4. After you have edited the name, tap **OK**. The *Edit* screen will display.
- 5. Tap **Add**. The *Add* screen will display.




6. Tap **Find a place**. The *Search* screen will display.

Find in: United Kingdom
Find a street address
Find by keyword
Find a postcode
Find nearby

- ${f Q}$ You can also add waypoints using Home, My Places and Recent places.
- 7. Using the Find address wizard, search for a location. The *Preview* screen will display.



Tap Add as waypoint.
 The waypoint is automatically saved and the Edit screen will display.



9. Complete one or more of the following:

If you want to	Then
add another waypoint Waypoints added after a multi-stop trip has commenced will not be included in the current route.	 tap Add. The Add screen will display. return to step 4.

If you want to	Then
navigate to your selected destination	tap C . The <i>Map</i> screen will display the calculated route.
delete the trip	tap 🛅.
Have this trip demonstrated	tap Simulate . The <i>Map</i> screen will display your trip in demo mode. (See Shop Demo page 58.)

How do I delete a waypoint from my trip?



The Planned Trips screen will display.

- 2. Tap the trip to edit.
- 3. Tap a waypoint on *Edit* screen. The *Preview* screen will display.



Tap **Delete**.
 The *Edit* screen will display.

How do I change the order of the waypoints?



The Planned Trips screen will display.

- 2. Tap the trip to edit.
- 3. Tap a waypoint on *Edit* screen. The *Preview* screen will display.



Tap **Up** or **Down**.
 The *Edit* screen will display

How do I edit a planned trip title?





The Planned Trips screen will display.

- 2. Tap the trip to edit.
- 3. Tap the current trip title.
 The *Keyboard* screen will display.
- 4. After you have edited the name, tap **OK**. The *Edit* screen will display.

How do I skip a waypoint during a multi-stop trip?

- 1. Tap the map screen.
- 2. Tap . When the caution dialog box displays, tap **Yes**. The next waypoint will be skipped and the route recalculated to the following waypoint.

What is Travel Book?

Travel Book is not available on all models and is only available in selected countries.

Travel Book is a collection of city guides that provide detailed Points of Interest maps for major cities in Europe. The city guides provide information on accommodation, dining, night life, business essentials, shopping, important tourist spots and practical information such as banks, medical centres, bus stations, etc.

Travel Book information is provided by third party. Mio does not guarantee the accuracy of the data contained within this database either expressed or implied.

How do I search for a POI in a city I am visiting using Travel Book?





 Select your city from the available cities screen. The City screen will display.



Select a POI category from the list. The POI category screen will display.



3. Select a POI from the list. The *POI details* screen will display.



4. Complete the following:

If you want to	Then
calculate the route, open the <i>Map</i> screen and start navigating	■ tap C . The <i>Map</i> screen will display.
save the location as a favourite	■ tap ♥. The Save screen will display. ■ tap Save as My Place.
explore the area near the location	 tap . The Explore Map screen will display. tap the undock button or tap the docked menu in Slide TouchTM mode to see the menu options. complete one of the following: tap Streets to explore streets near your location tap Areas to explore areas around your location tap a POI category to explore POIs near your location
place a phone call to the POI	tap . This feature is not available on all models.
read more information on the selected POI	tap More information. The More details screen will display.

How do I add / remove city guides on my Mio?

You can add/remove city guides on your Mio via MioMore Desktop.

For more information on adding/removing city guides, refer to the MioMore Desktop User Manual.

How do I watch digital TV?

If an optional digital TV card is installed on your Mio, you can watch the local free-to-air digital TV programs.



WARNING DO NOT watch TV while driving. It may be illegal in your state or country for a display showing a video to be in view of the driver.

 For information on installing the optional TV card and external antenna and using the remote control, refer to the Hardware User Manual.

Watching TV programs







- When you use the TV feature for the first time, you will be prompted to scan the channels available in your area. Follow the prompts to finish the channel scan.
- 2. The screen will display the TV program when the signals are available. Tap anywhere on the screen to display on-screen controls.



Complete the following:

If you want to	Then
adjust the volume	tap 💶 and 💶.
	You can also move the slider to the desired volume level.
change the channel	tap CH+ and CH-
	You can also move the slider to change the channel.
adjust the brightness	tap ** and *-
	You can also move the slider to the desired brightness level.
view the information of the current program	tap i
change TV settings	tap 🌣 .
exit the TV mode	tap

Changing TV settings

Complete the following:

If you want to	Then
check the one-week program guide provided by	tap Electric Program Guide.
the local digital TV program providers	Select a date. The screen will show the program list of the selected channel. Tap a program to show the program information.
check the channel list	tap Channel List.
	Tap to switch to the selected channel.
show the subtitle (if supported by the local digital TV program providers)	tap Subtitle.
change the screen display	tap Aspect Ratio to change to full screen mode or 4:3 mode.
scan the channels available in your area	tap Channel Scan.
	Follow the prompts to finish the channel scan.

How do I play media?

Media is not available for all models and is only available in selected countries.

Media allows users to play stored media files installed on your Mio or on a memory card.





Playing audio files

Only mp3, wma, wav audio formats are supported for the audio feature.

If your files are on a memory card, insert the card into your Mio. You can play music files that are stored on your Mio or on a memory card by a random order, artist and albums.

How do I listen to a music file on my Mio?

There are several ways to play audio files on your Mio.

1. Complete one of the following:

If you want to	Then
play music files randomly	tap Play Random.
sort music files by an artist	tap Artists and select an artist from the Artists screen.
listen to music files in an album	tap Albums and select an album from the <i>Albums</i> screen.
play all music files	tap Songs and select a song to start with from the <i>Songs</i> screen.
play music files stores in a playlist	tap Playlists and select a playlist from the <i>Playlists</i> screen.

2. The Songs screen will display.



3. Complete one of the following:

If you want to	Then
play a music file	tap a music file from the list

If you want to	Then
listen to the previous music file	tap •
skip the current music file	tap .
pause the music file	tap II. Tap b to starting playing the audio file.
adjust the volume	tap TITCO
mute the volume	tap 📲 🕽 .
unmute the volume	tap 📲 .
set play settings	in the Play section, tap < or > to see all options:
	select Random to play music files randomly.
	select In Order to play music files in order.
set repeat settings	in the Repeat section, tap < or > to see all options:
	 select Repeat All to repeat all the music files.
	select Repeat One and the current music file will be repeated
	once.
	select Off to play the music files only once.

Playing video files



WARNING DO NOT view videos while driving. It may be illegal in your state or country for a display showing a video to be in view of the driver.

Only mp4, 3gp, m4v, asf, wmv and avi video formats are supported for the video feature.

If your files are on a memory card, insert the card into your Mio.

How do I view a video file on my Mio?

1. From the *Media* screen tap **Videos**. The *Videos* screen will display.



2. Complete one of the following:

If you want to	Then
play a video file	select a video file from the list
view the previous video file	tap •
	Tap and hold the icon for more than 1 second to rewind the video.
skip the current video file	tap .
	Tap and hold the icon for more than 1 second to fast-forward the video.

If you want to	Then
pause the video file	tap II. Tap b to start playing the video file.
adjust the volume	tap
mute the volume	tap 📲
unmute the volume	tap 📲 .
View the video file on full screen	tap .
set play settings	in the Play section, tap < or > to see all options:
	 select Random to play video files randomly.
	select In order to play video files in order.
set repeat settings	in the Repeat section, tap < or > to see all options:
	select Repeat All to repeat all video files.
	 select Repeat One and the current video file will be repeated once.
	select No Repeat to play the video files only once.

How do I view a video file on full screen?

- From the Video screen, select the video file that you would like to view at full screen. The video file will play at normal view size.
- Tap the video.
 The video file will play at full screen.



- The icons will disappear after a few seconds; tap the screen to have them reappear.
- 3. Complete one of the following:

If you want to	Then
view the previous video file	tap [f].
	Tap and hold the icon for more than 1 second to rewind the video.
skip the current video file	tap 🔰
	Tap and hold the icon for more than 1 second to fast-forward the video.
pause the video file	tap III. Tap b to start playing the video file.
adjust the volume	tap TITLE TO THE TENT TO THE T
mute the volume	tap 🖜.
unmute the volume	tap 📲

If you want to	Then	
return to the normal view	tap .	
set play settings	in the Play section, tap < or > to see all options:	
	 select Random to play video files randomly. 	
	 select In order to play video files in order. 	
set repeat settings	in the Repeat section, tap < or > to see all options:	
	select Repeat All to repeat all video files.	
	 select Repeat One and the current video file will be repeated once. 	
	 select No Repeat to play the video files only once. 	

How do I receive audio through my vehicle speakers?

FM transmitting is not available on all models and is only available in selected countries.

Your Mio can be set to transmit sound at a particular FM frequency which you can then receive through your vehicle radio. This means that you can hear map voice guidance, radio, mp3 files and video voice files clearly and loudly through your vehicle speakers.

How do I set the audio output channel of my Mio through my car's FM radio?

When you first access Audio output, the Internal speaker option is selected by default. If you select FM transmitter the most recently used FM frequency will be used.

- From the Settings screen tap Audio output. The Audio output screen will display.
- Select the FM transmitter option and then tap Setup to set the frequency. The Set Frequency screen will display.
- 3. Tap **OK** on the guidance message to continue.
- Tap Set Frequency to set a new output frequency for your Mio.
 The Set Frequency screen will display.



You need to tune the car radio to an empty channel. If driving long distances, you may need to retune to a new empty frequency.

5. Tap - or + to set a frequency.

Tap and hold -/+ to decrease/increase by 1MHz. The fine-tuning frequency unit is 0.1MHz per unit.

Tap any of the save options.
 The FM screen will display with the saved frequency.

You can only save four FM frequencies on your Mio. Tap **Apply Directly** to apply current frequency directly. **Apply Directly** option allows you to set the audio output channel automatically to FM (current frequency).

7. Tap and select the frequency you want to use.

To delete a saved frequency, you must set a new frequency and replace the frequency that you no longer require.

How do I receive current traffic information via TMC?

Traffic information is not available on all models and is only available in selected countries.

Your Mio can receive current traffic information for all main roads and motorways, enabling you to avoid potential delays on your route. Event messages and traffic icons will display as they occur. If an event message obscures your current location, the map will adjust to display both the message and your location.

How does my Mio receive traffic information?

Depending on your model, you may receive current traffic information on your Mio using the built-in TMC receiver or via the Mio traffic accessory kit. The traffic accessory kit may be sold separately.

The Traffic Message Channel (TMC) broadcasts real-time traffic and weather information via the FM Radio Data System (RDS). FM radio stations transmit TMC data on a cycle of several minutes, with hundreds of events able to be broadcast to TMC receivers.

You have to pay for TMC service on some models and in some countries.

Traffic status

Your current traffic status is indicated by the colour of the TMC icon.

To view your current traffic status, from the Main Menu, tap



The following table describes the three traffic status icons:


Traffic Status	Description
	The TMC status is grey if traffic is currently inactive due to one of the following conditions:
	 Your Mio or traffic accessory kit is connecting to the TMC service.
	 Your Mio or traffic accessory kit cannot receive TMC data. This may be due to poor radio coverage in the local vicinity.
	You are in a country that is not supported by Mio traffic.
	Tap to display the <i>Traffic Overview</i> screen.
	The TMC status is orange if one of the following conditions apply:
	 You have navigated into a country that is not supported by Mio Traffic, but there are still traffic events listed on the Event List screen.
	 You have separated your Mio from the Mio traffic accessory kit, or the Mio traffic accessory kit is not receiving power but there are still traffic events listed on the Event List screen.
	Tap to display the <i>Traffic Overview</i> screen.
•	The TMC status is green if your Mio or traffic accessory kit is active and receiving traffic events.
	Tap to display the <i>Traffic Overview</i> screen.

Your traffic status is displayed in more detail on the Traffic System Status screen.

How will I know when a Traffic Event occurs?

Incoming events are handled according to your Traffic preferences.

When travelling through an area in which you can receive traffic updates, your Mio will decode these events and display them on-screen. An icon will display at the event location on the map screens, and an audible warning is given if an event is on your route. Where an event spans a specific distance, the road will be highlighted and arrows will indicate the direction affected.



A message will display at the bottom of the screen with the road name, the section of road affected and the type of event that has occurred. The message remains on screen for 8 seconds and is added to the *Event List*.

Traffic Overview screen

Depending on your Mio model, traffic information may not be available, may require a subscription, or may require the Traffic Accessory Kit (may be sold separately).

The Traffic Overview screen displays a general overview of the traffic situation on your route, including all events in the immediate vicinity.




	Item	Description
0	State	Indicates the number of events on your route.
0	Event icon	Displays icon to indicate type of event.
€	Current position	Your current position is marked with .
4	•	Your current traffic status is indicated by the colour of the TMC icon.
6	+	To zoom in or out, tap and hold or or

How do I view a list of all events on my route?

Your Mio creates a list of events as they are received, which is displayed on the *Event List* screen. This screen can only be viewed if the TMC icon is green or orange.

From the *Traffic Overview* screen, tap and undock the menu.



	Item	Description	
0	(+)	Tap to return to the previous screen.	
0	Sort	Display the Set sort type screen. Select your traffic event sorting option from the list.	
€	Event description	Displays details of the Event, including: Name of road and direction in which Event is taking place. Location of where Event begins and ends. indicates an Event from a location, to a location. indicates an Event between locations. Type of Event.	
4	Event icon	Displays an icon to indicate type of event.	

How do I view traffic details?

There are several ways to view details of an event received by your Mio.

Choose one of the following:

Traffic Status	Description
From any of the map screens used to view your route	 Tap the Event message when it appears on the map screen. The Event Details screen will display.
From the Traffic Overview screen	Tap and undock the menu. The Event List screen will display. Select and tap the event you want to view.
	The Event Details screen will display. OR
	Tap and hold the traffic icon, which displays at the location of the event. The Event Details screen will display.



	Item	Description
0	+	Tap to return to the previous screen.
9	Event icon and description	Displays details of the Event, including: Name of road and direction in which Event is taking place. Location of where Event begins and ends. indicates an Event from a location, to a location. indicates an Event between locations. Type of Event.
€	Detour information	Displays details of detour recommendation, if any.
4	Avoid	Tap to initiate a new route to avoid the event. Only available if a detour or re-route is available. The Unavoid Area button is displayed when a re-route has been calculated.

How do I know if a detour is recommended?

When a Traffic or Clearance event occurs on your route, a detour will often be recommended. The detour event message will display in the status bar on map screens.



② Detours are only recommended for Traffic or Clearance Events on a calculated route.

How do I avoid an event on my route?

From the Traffic Overview screen, tap and undock the menu.

- From the Event List screen, tap the event. The Event Details screen will display.
- If a detour has been calculated to avoid an event on your route, Avoid is available; tap to accept the new route 2. and avoid the event. The Map screen will display.

How do I cancel a detour around an event on my route?

If you have chosen to avoid an event and a new route has been calculated, you can cancel the detour around the event and return to your original route.

- From the Event List screen, tap the Event you want to un-avoid.
 The Event Details screen will display.
- 2. Re-route information displays at the bottom of the screen.
- If a re-route has been calculated, Unavoid is available; tap to accept the new route.
 The Map screen will display.

Traffic messages

The Event Details screen displays detour status information.

Detour Not Available messages

If a detour is not available, one of the following messages will display:

Message	Description	
This Event is not locatable	A consider leasting for the French appart he identified	
This clearance is not locatable	A specific location for the Event cannot be identified.	
This Event does not affect your route	The Event is not on the current leg of your journey, or	
This clearance does not affect your route	is behind your current position.	
You are avoiding this Event		
You have accepted this clearance	The Event is not on the current leg of your journey.	
You are too distant to re-route	The Event is currently too distant to affect your	
You are too distant to accept this clearance	journey.	
Detour not found		
Clearance route not found	A detour / re-route could not be calculated.	

Detour Recommended messages

If a detour is recommended, one of the following messages will display:

Message	Description
Finding detour	Your Mio is calculating a new route. During calculation, the % complete will display.
Recalculating route	Exiting this screen before the new route is calculated will cancel the operation.
Detour distance Clearance change	A detour has been calculated. The difference between the distance of your current route and the proposed route is displayed.

Traffic preferences

You can view your current traffic system status and change options by customising the traffic preferences.

TMC service

1. From the *Traffic Events* screen, tap **Traffic service**. The *Traffic service* screen will display.



The TMC service screen displays the frequency of the radio station currently used to receive traffic event information. A bar shows the strength of the traffic signal being received; the more green bars the stronger the signal.

2. Complete the following:

If you want to	Then
change your preferred radio station	select your preferred radio station from the list.

Traffic Event Notification

- From the Event List screen tap Preferences.
 The Preferences screen will display.
- 2. Complete the following:

If you want to	Then
turn on/ off traffic event notification	select the Notify me about nearby traffic events button to receive traffic event notification.
	clear the Notify me about nearby traffic events button to turn off traffic event notification.
	Event icons will still display on the Map screen.
be notified about events that affect your current route	select the Only notify me about events on my route button.
be notified only when a detour is recommended	select the Only notify me if a detour is recommended button.

Your preferences are automatically saved.

Select event sorting type

- From the *Traffic events* screen tap the **Sort** field. The *Set sort type* screen will display.
- 2. Complete the following:

If you want to	Then
sort events by distance	select the Distance option.
sort events by road name	select the Road name option.

If you want to	Then
sort events by age	select the Age option.
view all traffic events	select the Show all events option.
view traffic events that appear only on your route	select the Only show events on my events option.

Your preferences are automatically saved.

Walking mode

Walking mode is not available on all models.

Walking mode allows you to navigate to your destination using roads and paths appropriate for a pedestrian. including non-vehicle segments.

When in Walking mode, you will not be routed onto motorways and their associated slip roads. If your destination is more than 10 kilometres (6.3 miles) away, a warning message is displayed indicating that the route is a long way to walk.

(i)Some aspects of walking mode are not available on all models, but the function itself is.

Navigation along paths and non-vehicle segments that require 2D city maps is not available on all models.

How can I set my navigation mode to walking?

- 1. Plan a route from the Find or Explore screen.
- 2. In the Mode section, tap < or > to select Walking.

Your route will be calculated and the *Map* screen will display using the walking icon:



What can I customise?

There are various customisation options available to enhance your navigation experience.





Volume



Complete the following:

If you want to	Then
increase or decrease the volume	 tap to move the Volume slider to the right to increase the volume.
	 tap to move the Volume slider to the left to decrease the volume.

Your preferences are automatically saved.

Safety options

You can enhance your navigation experience by modifying aspects of your route and route calculation.



Complete the following:

If you want to	Then
enable/disable a visual warning if the screen is accessed in a moving vehicle	tap Warn me not to operate my Mio while driving, to turn it On or Off.
enable/disable speed limit alerts, which warn you of the speed limit on any given road	tap Speed limit warnings, to turn it On or Off.
	When Speed limit warnings is set to On , the Set manual speed alert and Speed alert type , options will display.

Your preferences are automatically saved.

Route options



Complete the following:

If you want to	Then
set route type options for your route	Tap Route type. The Route type screen will display. Select your route type preference from the list.
	Shortest – The route with the shortest physical length
	Easiest – The simplest route with the least number of turns and favours motorways where appropriate
	Economical – The route with least number of stops, turns and urban areas which should save on fuel usage.
	Fastest – The route that should be the fastest when navigating
	Selecting Shortest route type over Fastest route type can cause a much longer journey time.
set types of road options for your route	tap Types of road. The Types of road screen will display. select your road preference from the list.
	Avoiding ferry routes may prevent you from navigating between certain countries, even when a bridge or tunnel exists.
set your map screen preference	tap the Map option to select between a 3D or 2D view of the <i>Map</i> screen.
set the number of turns displayed on your turn list	tap Displayed turns. The Displayed turns screen will display. select your turn preference from the list.
display junction views on your route	tap the Junction views options to turn it On or Off.
	This feature is not available on all models.
Set how you want to notified of safety cameras	tap My Places alerts. The My Places alerts screen will display. select an option and then select your preference from the list.
record mileage for your route to generate expense reports	tap the Mileage recorder option to turn it On or Off. This feature is not available on all models. See the MioMore Desktop Manual for more information on exporting mileage reports.
record a GPS log of your trip	tap the GPS logging option to turn it On or Off.
record your journey	tap the Capture Journey option to turn it On or Off.

Your preferences are automatically saved.

Map display




Complete the following:

If you want to	Then
enable/disable automatic zooming	tap the Auto-zoom map when navigating option to turn it On or Off.
during navigation	If selected, the Map screens will automatically zoom in or out, depending on your speed, to allow optimal viewing of your route.
display North at the top of the 2D Map screen	tap the Keep North at top of 2D map screen option to turn it On or Off .
	If set to Off , the direction you are travelling in will display at the top of the 2D Map screen.
display "no entry" icons on "no entry" roads on the <i>Map</i> screens	tap the Show no-entry road signs option to turn it On or Off. When turned on, the map display performance can slow down due to the number of no entry roads in some major cities.
Change the map colour scheme	tap the Map scheme , then select a colour scheme from the list.

Your preferences are automatically saved.

Screen brightness



Complete the following:

If you want to	Then
change the screen brightness	 tap to move the Screen Brightness slider towards right to increase screen brightness.
	 tap to move the Screen Brightness slider towards left to decrease screen brightness.
	Warning: Your Mio can heat up when the Brightness scale is set high, therefore, use lower brightness whenever acceptable.
set the screen contrast to automatically adjust	select the Automatic day/night option.
improve screen contrast in light or dark condition	select either Day or the Night option to manually adjust screen contrast.

Your preferences are automatically saved.

Language



Complete the following:

If you want to	Then
change the on-screen language	tap your preferred language, then tap Yes.
	The voice scheme will also change to the default scheme for the selected language.

Your preferences are automatically saved.

Voice



Complete the following:

If you want to	Then
change the voice scheme	select your preferred voice scheme from the list.
	Only voice schemes that are compatible with the chosen language are displayed.

Your preferences are automatically saved.

Power management



The **Battery Status** bar shows the percentage of power left in the Mio battery. The words **External power** will display when the battery is charging from an external power source. Otherwise it will show **Internal battery** when not connected to an external power source.

To charge the battery, refer to the Hardware User Manual.

Units



Complete the following:

If you want to	Then
change the time format	tap Time format and then select your preferred time format from the <i>Units</i> screen.
change the distance units	tap Distance Units and then select your preferred distance unit type from the <i>Units</i> screen.
change the date format	tap Date Format and then select your preferred date format type from the <i>Units</i> screen.

Your preferences are automatically saved.

Touch audio



The touch audio option allows you to hear a tone when you tap the touch screen.

Complete the following:

If you want to	Then
hear which letter you have tapped when you tap the touch screen	tap the Audio option to turn it On or Off.
hear a tone when you use the on-screen keyboard for text input	tap the Speak keyboard letters option to turn it On or Off.

Your preferences are automatically saved.

List scrolling



Complete the following:

If you want to	Then
enable the Slide Touch [™] interface and not use arrows to navigate on a screen	tap the List Scrolling option to select Slide Touch.
disable the Slide Touch TM interface and use the scroll tabs	tap List scrolling option to select Buttons.

Your preferences are automatically saved.

Audio output

This feature is not available on all models.

Audio output allows you to change the audio output of your Mio.



Complete the following:

If you want to	Then
Receive audio output through your Mio	Select the Internal Speaker option.
Receive audio output through the FM radio in your car	Select FM transmitter and then select your FM frequency. For more information, see "How do I receive audio through my vehicle speakers?" on page 53.

Your preferences are automatically saved.

Delete saved information



Complete the following:

If you want to	Then
delete My Places	tap Delete My Places.
delete recent locations	tap Delete recent locations.
clear all settings; for example, for use in a rental car	complete all of the above.

When the warning dialog box displays, tap Yes.

Reset GPS

Occasionally, the GPS fix may need to be reset. This may occur if the receiver has been transported a long distance since last being used; for example, to a different country, and is still trying to establish the previous position.

Complete the following:

If you want to	Then	
reset the GPS	 tap Reset GPS. 	
	 When the warning dialog box displays, tap Yes. 	

Restore factory defaults

The restore factory defaults option allows you to restore default factory settings.

Complete the following:

If you want to	Then
restore factory default settings	tap Restore Factory Defaults. Your Mio will restart.
	The Restore Factory Defaults option does not delete recent locations or saved My Places destinations.

Your preferences are automatically saved.

Shop demo

Complete the following:

If you want to	Then
enable a shop demonstration of Mio Spirit to be played	tap Shop demo . Tap Yes and select a demonstration country. Tap OK . Your Mio will restart.
	When your Mio is in Shop demo mode, you will see the navigation demonstration of the pre-defined route without having to set a destination.
	You cannot operate your Mio properly in Shop demo mode.
stop a shop demonstration of Mio Spirit in playback	tap Shop demo . Tap Yes , then OK . Your Mio will restart.

Screen saver

Complete the following:

If you want to	Then
enable the screen saver feature on your Mio	tap Screen saver . When your Mio is idle for 10/30/60 minutes, the screen saver will display.
	The screen saver will only display if your Mio is connected to a power supply. To stop the screensaver playing, simply tap the screen.
Disable the screen saver feature on your Mio	tap Screen saver . Tap Off .

Your preferences are automatically saved.

About

Tap **About** to display copyright and trademark information.

Point of Interest categories

Icon	Description	Icon	Description
+	Airport	*	Amusement park
₩	Art centre		ATM/Cash dispenser
\$	Bank	YU	Bar/Pub
#	Beach	1	Breakdown service/Car repair facility
o i	Bowling centre	4	Business facility or company
4	Business office	1	Bus station
A	Camping ground	88 244	Car dealer/Automobile dealer
***	Casino	•	Cemetery
*	Church	₩_	Cinema
á	City hall	•	City, town or village
	Coffee shop	x+	College/University
R ₀ #	Community centre	91	Commuter railway station
(iii	Courthouse	Ħ÷	Dentist
84	Doctor	! -(Embassy
	Exhibition centre		Ferry terminal
<u> </u>	Fire Brigade	1	Golf course
r i	Government office	M	Grocery store
T.	Guest house	x+	Higher education
Ĥ	Hospital/Polyclinic	Ħ	Hotel
L	Ice skating	\int \tag{\tau}	Important tourist attraction
i	Information/Tourist information office	î	Library
Ţ	Marina/Yacht basin	+	Medical
*	Monument	*	Motorcycle dealer

Icon	Description	Icon	Description
A •	Motoring organisation office	M	Mountain pass
	Museum	131	Music centre
2	Natural attraction	Υſ	Nightlife
P+R	Park and ride	P	Parking
P	Parking garage	Ţ	Park/Recreation area
B	Performance art/Theater		Petrol station
0.0	Pharmacy	*	Place of worship
ä	Police station	Σ	Post office
∳ I∳	Public restroom/Toilet facilities		Public sport airport
×	Railway crossing)(R	Rental car agency
MT.	Rest area	41	Restaurant
•	Road accident black spot	*	Scenic/Panoramic views
abc abc	School	<u></u>	School zone
	Shop	A	Shopping
*/	Ski resort/Ski lift station	0	Speed check
8	Sport centre	8	Sports hall
8	Sports complex	0	Stadium
9	Tennis court	B	Travel agency
	Transport ferry	₩+	Veterinarian
Ą	Winery	Tit	Z00

Branded Points of Interest

Branded Points of Interest are available on some maps. These include well known restaurants, accommodation providers, tourist attractions, Petrol stations, etc. The icon will usually display the company logo.

Point of Interest categories by subscription

Icon	Description
S II	Safety Cameras
· II	Safety Camera (Mobile)
S II	Safety Camera (Average)
	Red Light Camera

My Places categories

Icon	Description
22	Album
A	Home
	Picture
*	Saved locations
#	Captured locations
3	Captured journey
•	Captured sound recording

Traffic and other TMC Events

Each TMC Event is sorted in to one of nine categories. When an Event is received, one of the following icons will display:

Event	Avoided Event	Message Type	Event Description
A		Danger	There is a dangerous situation on the route; for example, people are on the road.
	P	Traffic	Any event that will cause a delay on a route.
	€	Weather	Weather conditions are adversely affecting a route; for example, there is ice on the road.
\triangle	4	Warnings	There is a situation of which you should be aware on the route, but it is not serious enough to be considered a dangerous situation; for example, a minor accident has taken place.
<u>oî</u>		Forecast	An event is expected to occur on a route.
M	A	Restrictions	There is a restricted flow of traffic on a route; for example, a lane has been closed on a motorway.
Ø		Clearance	A traffic event that has now been cleared.
î	A	Information	All other events.
		Roadworks	Roadworks are taking place on a route.

If a Traffic or Clearance event has a recommended detour, the following icons will display:

Event	Avoided Event	Message Type	Event Description
	F	Traffic Detour	A Traffic Event, for which a detour is recommended.
		Clearance Re-route	A Clearance Event, for which a re-route is recommended.

⁽²⁾ Avoided Event icons will only display on the Map screen, at the event location.

Appendices

For more information

User Manuals

The latest User Manuals can be downloaded from our website: www.mio.com

Register with MioClub

To report a faulty product or speak to a member of our Technical Support team, register your Mio on MioClub to obtain the Technical Support phone numbers for your region.

Speed Limit

Mio products are designed to be used as an aid to safer driving. Mio does not condone speeding or any other failure to comply with your local traffic laws. It is your responsibility to drive within the posted speed limit at all times and to drive in a careful manner. Mio accepts NO liability whatsoever for you receiving any speeding fines or points on your license through using this device. Mio does not guarantee the accuracy of the data contained within this database either expressed or implied. In the event you receive a fine or any other penalty for speeding or contravention of any traffic law, or are involved in an accident, Mio is not responsible for any damages of any type. In some countries the data information regarding speed limits may conflict with local law and/or regulations. It is your responsibility to make sure that your use of the data is in compliance with local laws and/or regulations. Usage is at your own risk.

Safety Camera POIs

Mio products are designed to be used as an aid to safer driving. You can receive messages to alert you to locations of safety cameras, which will enable you to monitor your speed through these areas. Mio does not warrant that all types and locations of safety camera data are available, as cameras may be removed, relocated or new cameras installed. Mio does not condone speeding or any other failure to comply with your local traffic laws. It is your responsibility to drive within the posted speed limit at all times and to drive in a careful manner. Mio accepts NO liability whatsoever for you receiving any speeding fines or points on your license through using this device. Mio does not guarantee the accuracy of the data contained within this database either expressed or implied. In the event you receive a fine or any other penalty for speeding or contravention of any traffic law, or are involved in an accident, Mio is not responsible for any damages of any type. In some countries the data information regarding safety or speed cameras may conflict with local law and/or regulations. It is your responsibility to make sure that your use of the data is in compliance with local laws and/or regulations. Usage is at your own risk.

FM Transmitter

Products with FM Transmitter feature may be operated in the following countries: Andorra, Austria, Belgium, Denmark, Finland, Germany, Ireland, Liechtenstein, Luxembourg, Monaco, Netherlands, Norway, Portugal, San Marino, Spain, Sweden, Switzerland, Great Britain and Vatican City.

The FM Transmitter feature is not allowed to be used by law in France, Andorra, San Marino, and Vatican City. Please turn of the FM Transmitter in those areas.

Disclaimer

Mio operates a policy of ongoing development. Mio reserves the right to make changes and improvements to any of the products described in this document without prior notice. Mio does not warrant that this document is error-free. The screenshots and other presentations shown in this manual may differ from the actual screens and presentations generated by the actual product. All such differences are minor and the actual product will deliver the described functionality as presented in this User Manual in all material respects.

Copyright

© 2009 MiTAC International Corporation. Mio is a registered trademark of MiTAC International Corporation and is used under licence by Mio Technology Ltd. All rights reserved.

The software contains proprietary information of MiTAC International Corporation; it is provided under a licence agreement containing restrictions on use and disclosure and is also protected by copyright law. Reverse engineering of the software is prohibited.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Mio.

Back-On-Track, Drive-Away, MioMore Desktop, Mio Spirit, NavPix, Slide Touch and Turn-by-Turn are either registered trademarks or trademarks of MiTAC International Corporation and are used under licence by Mio Technology Ltd. All rights reserved.

MicroSD and the MicroSD logo are trademarks of SD Card Association.

All other trademarks and registrations are the property of their respective owners.

Revision: R03 (8/2009)



Moov V Series MioMore Desktop Manual

Contents

Welcome	4
What is MioMore Desktop?	5
How do I install MioMore Desktop onto my computer?	6
MioMore Desktop Menu	8
My Subscriptions	10
How do I purchase a subscription?	10
How do I activate my subscription?	10
How do I update subscriptions on my Mio?	11
My Maps	12
How do I download and install free map updates?	12
How do I install maps onto my Mio?	13
How do I remove maps from my Mio?	
Custom POIs	
How do I install custom Points of Interest?	
How do I delete a Custom Politis of Interest?	10
Photo Album	
Toolbar	
How do I transfer pictures from Photo Album to my Mio?	
How can I view and edit pictures or albums on my computer?	20
What else can I do with pictures and albums on my computer?	20
Photo Album preferences	
Image Search	
How do I download NavPix [™] from the internet?	22
How do I import NavPix [™] to Photo Album?	22
Application Gallery	
How do I rearrange Main Menu applications on my Mio Main Menu? How do I remove an application from my Mio?	23
How do I add an application to my Mio?	23
My Places	
How do I sort My Place locations?	
How do I edit a location name or notes in My Places?	24
How do I share a location from My Places?	
How do I play a captured sound file? How do I upload a Na∪Pix[™] from My Places to Flickr™?	25
How do I delete a location from My Places?	
My Mio	
Voice transfer	
How do I install a voice file?	
How do I remove a voice file?	
Mileage Reporter	
How do I import my trip data?	
How do I delete travel logs from my Mio?	
Mileage Reporter preferences	28
Backup and Restore	
How do I backup my Mio? How do I restore a backup to my Mio?	
How do I delete a backup?	
Language	29
Recover keys	20

Connect	3′
How do I search for a POI using Connect?	31
My Media	33
Toolbar	34
How do I import a music file to my MioMore Desktop library?	
How do I transfer a music file from MioMore Desktop to my Mio?	34
How do I remove a music file from my MioMore Desktop playlist?	35
How do I remove a music file from my Mio playlist?	35
How do I permanently delete a music file from my Mio playlist?	35
What else I can do with My Media?	35
Appendices	37
For more information	37
Compliance	38
Speed Limit	38
Safety Camera POIs	
Disclaimer	38
Copyright	39

Welcome

Thank you for purchasing this MioMore Desktop software. Please read this manual carefully before using MioMore Desktop for the first time. Keep this manual in a safe place and use as your first point of reference.

Important information for using the manual

It is important to understand the terms and typographical conventions used in this manual.

Formatting

The following kinds of formatting in the text identify special information:

Convention	Type of Information	
Bold	Mio components or items displayed on screen, including buttons, headings, field names and options.	
Italics	Indicates the name of a screen.	

Icons

The following icons are used throughout this manual:

Icon	Description
(1)	Note
(Тір
<u>^</u>	Warning

Terms

The following terms are used throughout this manual to describe user actions.

Term	Description	
Click	Use the left mouse button to click a button or area on the screen.	
Select	Click an item in a list or click a command from a menu.	

What is MioMore Desktop?

MioMore Desktop is a suite of tools you can use to access greater functionality and product information via your computer.


MioMore Desktop allows you to:

- obtain software updates
- manage maps
- search online for local POIs
- manage custom POIs
- manage safety camera subscriptions
- report trip mileage
- transfer pictures to your Mio using Photo Album
- browse the Mio website for special offers.

Can I use MioMore Desktop with my computer?

Ensure your computer has the following minimum system requirements before installing MioMore Desktop:

- IBM compatible PC
- Microsoft[®] Windows[®] XP SP2 or Vista x32
- Internet Explorer 6 or higher
- DVD drive
- USB port
- Internet connection for activation.



How do I install a map for the first time?

The most common task performed using MioMore Desktop is the installation of a new map to your Mio internal memory or memory card. Complete the following procedures:

Step	Action	
1	Install MioMore Desktop on your computer.	
2	Check for software updates for Mio Spirit on your Mio.	
3	Install one or more maps on your Mio.	

How do I install MioMore Desktop onto my computer?

Before you begin: Ensure that your computer meets the minimum system requirements for MioMore Desktop, especially:

i. Ensure that Internet Explorer 6 or higher is installed on you computer before you install MioMore Desktop, even if it is not your default browser.

ii. Windows XP users, ensure that Windows XP Service Pack 2 or higher has been applied before you install MinMore Deskton

CAUTION: When your Mio is turned on and connected to a computer, it is recognized as an external mass-storage device. Do NOT delete any files that are pre-installed on your Mio. Deleting the files can cause your Mio to crash

- 1. Close all programs on your computer.
- Insert the MioMore Desktop Application Installer DVD into your computer DVD drive.
 The MioMore Desktop installer will start.

If your computer does not automatically launch the DVD, start the installation manually: $Start \rightarrow Run$.

Type D:\Install.exe where "D" is the letter assigned to your DVD drive, then click OK.



- 3. Select your preferred language for MioMore Desktop.
- 4. Click Install Software, then Install MioMore Desktop 2.
- 5. Follow the screen prompts to install MioMore Desktop:
 - Review and accept the Licence Agreement for MioMore Desktop when prompted.
 - Select a destination folder for MioMore Desktop when prompted.
 - When the installation is complete, click Finish. MioMore Desktop will open.
- 6. If prompted to connect your Mio to your computer, complete the following:
 - Plug the large end of the USB cable directly into a USB port on your computer (not a USB hub) and plug
 the small end into the USB Socket (**) on the bottom of your Mio.
 - Where possible, plug the USB cable into a USB port at the back of your computer.
 - Slide the Power switch to the ON position, to turn on your Mio.
 The following screen will display on your Mio:



From now on, you can access MioMore Desktop via: Start → All Programs → Mio → MioMore Desktop 2

7. If prompted to update your Mio software, follow the on-screen prompts.

You are now ready to use MioMore Desktop to install maps to your Mio.

MioMore Desktop Menu

Depending on your Mio model, certain MioMore Desktop Menu options may not be available.



	Component	Description	
0	Mio Online	Display the Mio website, Mio Store and other online features.	
0	My Subscriptions	Information on your current subscriptions, including safety camera subscriptions.	
€	My Maps	Install and manage maps.	
4	Custom POIs	Application that allows you to import custom POIs.	
6	Photo Album	Import and edit NavPix [™] images.	
6	Image Search	Search online and download NavPix TM which can be added to My Places or Mio.	
		This feature is powered by Flickr™.	
0	Application Gallery	Customise and rearrange applications available on the <i>Main Menu</i> screen of your Mio.	
8	MY PLACES	View and modify all places including addresses, Points of Interest, NavPix TM , and others added using MioMore Desktop and stored on your Mio.	
9	MY MIO	and others added using MioMore Desktop and stored on your Mio. A collection of applications that allow you to transfer data to and from your Mio, including: Voice transfer Activation Mileage reporter Backup and restore Langauge Recover keys Options	

	Component	Description
0	CONNECT	Search for and add live POIs to My Places.
0	MY MEDIA	Application used to transfer media files from your computer to your Mio.

General Preferences

My Mio → Options → General

Complete one of the following:


If you want to	Then
keep MioMore Desktop updated	select the Auto check for updates checkbox.
	When you select this option, every time you open MioMore Desktop, any available service packs and bug fixes will be downloaded from the Mio server and applied to your Mio.
	Updating software is different from upgrading software. To upgrade MioMore Desktop, you must first purchase a new version of MioMore Desktop from a retailer, then install it on your Mio.
change the units of measurement that MioMore Desktop uses	select or clear the Use metric units check box to change between imperial and metric units select or clear the Use decimal degrees check box to change between decimal degrees and latitude/longitude co-ordinates.

My Subscriptions

Subscription information is not available on all models and is only available in selected countries.

Your Mio contains pre-loaded subscriptions, such as safety camera and travel book information.

MioMore Desktop → My Subscriptions



For the latest subscription updates, visit; www.mio.com



Safety Camera alerts can be set to enable a warning sound or visual warning when on your route.

How do I purchase a subscription?

- 1. Select a type of subscription. A list of regions will display.
- 2. Select a region. A list of available subscriptions will display.
- Select a subscription or offer, then click Purchase an activation key from the Mio store. 3. The Mio Store website will open.
- Follow the prompts to purchase your subscription.

A product key will be sent to you via email when you have subscribed. You will need to use this product key to activate your subscription.

How do I activate my subscription?

MioMore Desktop → My Mio → Activation

- Enter your product key. 1.
- 2. Follow the prompts to activate your subscription.

How do I update subscriptions on my Mio?

The My Mio section will display a list of subscriptions already installed on your Mio:


Icon	Description	
Red	Expired subscriptions.	
	right click to purchase a new subscription.	
Yellow	Available subscriptions.	
	right click to update and purchase new subscription.	
Green	Active subscriptions.	
	No updates are available for these subscriptions.	

My Maps

My Maps allows you to install new maps, remove maps from your Mio and purchase new maps.

MioMore Desktop → My Maps

Click View Installed Maps.



	Component	Description	
0	Map Source	A list of maps on the DVD or available for purchase via the Mio Store website.	
0	My Mio	A list of maps installed on your Mio.	
€	Continent	A drop down list of continents that have maps available for your Mio.	
4	Zoom In / Zoom Out	Click to zoom in or out of the globe.	
6	Globe	A map of the world or selected continent indicating the maps: on the current DVD, installed on your Mio or memory card, or available from Mio.	

How do I download and install free map updates?

Occasionally Mio will offer you free map updates. If a free map update is available and your Mio is connected to your computer, a message will display when you first start MioMore Desktop.

The message can be disabled from displaying by selecting **Suppress Free Map Offer messages** from the message box or from: $My\ Mio \rightarrow Options \rightarrow My\ Maps$

How do I download a map update immediately?

- Select the map updates that you would like to download, then click **Download**.
 Your default web browser will open and prompt you to save the map update files.
- 4. Navigate to your Loadable Maps Location and save the files.

The default Loadable Maps Location is the *My Maps* folder in your *Documents* folder. You can change the location from: $My Mio \rightarrow Options \rightarrow My Maps$

How do I download a map update at a later time?

- 5. Click **Close** to close the *Free Map Updates* window.
- When you are ready to download the map update, click My Maps.
 A list of available map updates will be displayed under Free to download in the Available Downloads section.
- Select the map update that you would like to download, then click Yes.
 Your default web browser will open and prompt you to save the map update file.
- 8. Navigate to your Loadable Maps Location and save the files.

The default Loadable Maps Location is the My Maps folder in your Documents folder. You can change the location from: My Mio → Options → My Maps

How do I install a map update that I have downloaded?

1. Click Mv Maps.

A list of downloaded map updates will be displayed in the Loadable Maps section.

- Click Open next to the map update that you would like to install.
 The globe will display. The free maps that you downloaded are yellow.
- Click the map you want to install to your Mio.
 The map will change colour to a brighter vellow to indicate it has been selected.
 - To deselect a map, click the map again.
 - You may need to install multiple maps to cover the required geographical area.
- Select the destination media for the selected map, then click Transfer Now.
 The selected map will be installed and change colour to green.
- 5. To use your Mio, disconnect the USB cable.



WARNING: Do not disconnect the USB cable from the Mio USB Socket until the Globe has refreshed, and the installed map or maps have changed colour to green.

How do I install maps onto my Mio?

Your Mio comes with one or more pre-activated maps.

You can install maps from the DVD that came with your Mio or one that you have purchased separately to a memory card or your Mio internal memory; however you may need to purchase a Map Product Key to activate maps on the DVD that came with your Mio.

- Open MioMore Desktop, if it is not already open: Start → All Programs → Mio → MioMore Desktop
- 2. Click Mv Maps.

The My Maps application will display.

- 3. Insert Map DVD into your computer DVD drive.
 - The maps already installed on your Mio are green.
 - The maps that are unlocked and ready to be installed to your Mio are yellow.
 - The maps that require activation before being installed to your Mio are red.
 - The maps that are available for purchase from Mio are blue.
 - If your computer opens Windows Explorer when the DVD is inserted, close the Windows Explorer window.

4. Complete the following:

If the map to be installed is	Then
yellow	go to step 7.
red	the map needs to be activated via the Internet before it can be installed; continue to step 5.

- 5. If you connect to the Internet via a dial-up connection, connect to the Internet now.
- 6. Follow the prompts to activate your Map Product Key, including:
 - Enter the Map Product Key when prompted.
 - Your computer will connect to the Internet and activate your Map Product Key.
 - When activation has completed, the map will change colour to yellow; continue to step 7.
- 7. Click the map you want to install to your Mio.

The map will change colour to a brighter yellow to indicate it has been selected.

- To deselect a map, click the map again.
- You may need to install multiple maps to cover the required geographical area.
- 8. Complete the following:

If you want to	Then
install a yellow map	go back to step 7.
install a red map	the map needs to be activated via the Internet before it can be installed; go back to step 5.
install the selected maps to your Mio	continue to step 9.

- Select the destination media (Mio internal memory) for the selected maps, then click Transfer Now.
 The selected maps will be installed and change colour to green.
- 10. To use your Mio, disconnect the USB cable. You may need to manually reset your Mio.



WARNING: Do not disconnect the USB cable from the Mio **USB Socket** until the **Globe** has refreshed, and the installed map or maps have changed colour to green.

How do I remove maps from my Mio?

1. Click My Maps.

The My Maps application will display.

- 2. From the My Mio panel, select the check box next to the map you want to remove.
- 3. Click Remove Maps to remove the selected maps.
- 4. Confirm that you want to remove the selected map when prompted.

The map is removed from your Mio.

You can reinstall these maps at any time via MioMore Desktop.

My Maps Preferences

My Mio → Options → My Maps

Complete one of the following:


If you want to	Then
change the location of where downloaded maps and map updates will be saved	 click Change. select a location for your maps. click Save or OK. The warning message will display and you will be prompted to confirm your action. Your maps are moved to the new location.
prevent offer messages from displaying	select the Suppress Free Map Offer messages check box.

Custom POIs

Depending on your Mio model, some Custom POIs features may not be available.

The Custom POIs (Points of Interest) application allows you to create or import your own POI files. These are called custom POIs. Unlike preinstalled POIs, custom POIs can be removed from your Mio and can have audio as well as visual alerts associated with them.

MioMore Desktop → Custom POIs



How do I install custom Points of Interest?

Various POI files are available for download free or by subscription from third-party websites ¹. Ensure that downloaded files are in .csv (Comma Separated Values) format.

- In the Add new POIs section, click Browse to select a source file.
 The Open dialog box will open.
- 2. Select the file from your local or network drive, then click Open.
- 3. From the POI Category section:

 If you want to...
 Then...

 use an existing custom POI category
 select the Existing category option, then select a type from the drop down list.

 create a new custom POI category
 select the New category option, then type a name for the POI category.

¹ Mio is not responsible for the content or accuracy of the information or the reliability or availability of these websites. The use of information regarding safety camera locations may be subject to local laws in the country of use. You are responsible for checking that you can use the information in your country or in the country where the information will be used.

4. Set Alert setting as required:

If you want to	Then
enable a visual warning when a POI of this category is in close proximity	select the Visual alert check box.
select an icon to display on the map screens for POIs of this category	Click Browse to select the icon file from your local or network drive. When you have located the icon file, select it and click Open .
	The icon file must be a bitmap (.bmp) graphic with a minimum size of 6x6 pixels and a maximum size of 32x32 pixels.
	If you do not select a custom icon, a default icon will display.
select the distance from a POI of this	select the distance from the Distance box.
category at which the visual warning should display or the warning chime should sound	To change the units used to measure distance for this POI category, from the tools menu click on options and from the general option select Use metric units check box.
enable a warning sound when a POI of this category is in close proximity	select the Audio alert check box.
select a custom sound alert file to play when a POI of this category is in close proximity	Either select a sound file from the list, or Click Add to select a sound file (.WAV format) from your local or network drive. When you have located the file, select it and click Open.
	If you do not select a custom sound file, a default sound alert will play.

5. Click Add to device to add the POI to your Mio.

② Each file corresponds to a POI category; for example, Hotels.csv will be listed in your Mio as the Hotels category.

How do I delete a Custom POI file/category from my Mio?


- In the Installed POIs section, click **Delete** next to the file name. The file is removed from the list, but is not yet deleted.
- Accept the warning message.
 The selected file/category is deleted.

Photo Album

Depending on your Mio model, certain Photo Album features may not be available.


Photo Album is a MioMore Desktop application which allows you to copy, delete or move pictures or albums between the $NavPix^{TM}$ library on your Mio and the $NavPix^{TM}$ library on your computer.

MioMore Desktop → Photo Album



	Component	Description
0	Desktop albums	Displays a list of all albums stored in the NavPix TM library on your computer.
		 Click an album to display its contents in the Album display area. Click View all NavPixTM to display all pictures stored in the NavPixTM library on your computer.
0	My Mio albums	Displays a list of albums stored on the Mio internal memory and on the memory card if one is inserted.
		Click an album to display its contents in the Album display area.
€	Selected picture	When a thumbnail is selected it displays with a blue border.
4	Album display area	Displays thumbnails of pictures in the selected album.
6	Search	Type to search for a NavPix TM by name.
6	Toolbar	When a picture is selected, the icons which can be used will be active.

Toolbar



The following options are available on the toolbar:

	Button	Description
0	Create new album	Click to create a new album in the NavPix TM library you are viewing.
9	Add to My Places	Click to transfer NavPix TM to My Places.
€	Transfer to your Mio or Transfer to your computer	If you are viewing NavPix™ in the NavPix™ library on your computer, this will display as Transfer to your Mio. Click to transfer the selected NavPix™ to your Mio. If you are viewing NavPix™ in the Mio library this will display as Transfer to your computer. Click to transfer the selected photo(s) to the NavPix™ library on your computer.
4	Import NavPix TM	Imports NavPix TM from your computer to the NavPix TM library on your computer.
9	Export to disk	Click to save NavPix TM to your computer or a network drive.
6	View details	Click to view the selected NavPix TM and edit NavPix TM details, including: NavPix TM name latitude longitude description.
0	Rotate left	Rotates the selected NavPix TM 90° to the left.
8	Rotate right	Rotates the selected NavPix TM 90° to the right.
0	Delete NavPix [™]	Click to delete the selected NavPix TM .

How do I transfer pictures from Photo Album to my Mio?

You can transfer pictures from your computer to your Mio. You can import any JPEG (.jpg) into Photo Album, add or edit GPS information, and then copy the picture to your Mio.

- From the Toolbar section, select Import NavPixTM.
 The Open dialog box will display.
- Select a NavPixTM from a folder on your computer and click Open. Thumbnails of the NavPixTM will display in the Album display area.

You can also drag and drop a **NavPix**TM from a folder on your computer to an Album on your MioMore Desktop.

 Either click and drag the required NavPixTM to an album in the Mio albums section, or click the Transfer to your Mio icon on the toolbar.

If you have transferred a **NavPix**TM with GPS coordinates you can then navigate to where the picture was taken.

How can I view and edit pictures or albums on my computer?

If you want to	Then
rotate a picture to left	select the picture from the Album display area.
,	click Rotate left on the toolbar.
rotate a picture to right	 select the picture from the Album display area.
l como a promo a rigin	click Rotate Right on the toolbar.
view the picture details	select the picture from the Album display area.
•	 right-click and select View Details, or click View Details on the toolbar.
edit GPS information	 select the picture from the Album display area.
	 double click on the picture or click View Details on the toolbar.
	The following information will display: Name
	Latitude and Longitude
	Description
	Edit the details you want to modify.
	■ Click OK to save the changes.
delete a picture	select the picture from the Album display area.
acioto a pictare	 right click and select Delete or click Delete on the toolbar.

What else can I do with pictures and albums on my computer?

From the **NavPix**TM library on your computer, you can:

- add a picture to another album
- remove pictures from an album
- add a NavPixTM to My Places
- view and edit details of a selected picture
- upload pictures to Flickr™
- export to disk
- export pictures to Google Earth™
- search for pictures
- view all pictures in the library

If you want to	Then
add a picture to another album	 in the Desktop albums section, select the album containing the NavPix[™] you want to include in another album
	 select the NavPixTM then drag it to the other album.
	The selected NavPix TM is included in the new album, but is not moved, i.e., one instance of the NavPix TM in the library may be included in multiple albums.
remove a picture from an album	 in the Desktop albums section, select the album containing the NavPix[™] you want to remove
	 select the NavPixTM, right click and select Remove from album.
	Click the Delete icon on the toolbar if you want to delete the NavPix TM from all albums.
add a NavPixTM to My Places	 in the Desktop albums section, select the album containing the NavPix[™] you want to add to My Places.
	■ select the NavPix TM , right click and select Upload to My Places.
view and edit picture details	 select the picture then click the View Details icon on the toolbar.
	 edit the fields as required.

If you want to	Then
upload picture to the Flickr website	in the Desktop albums section, select the album containing the NavPix [™] you want to upload to the Flickr website.
	■ select the NavPix TM , right click and select Upload to Flickr .
	You need a Flickr account to upload NavPix TM . To create a Flickr account visit <u>www.flickr.com</u> .
save a picture to your	 select the picture from the Album display area.
computer	right click and select Export to disk or click Export to disk on the toolbar.
	 navigate to a folder on your computer where you want to save the NavPix™.
export to Google Earth™ (only NavPix [™] with GPS	in the Desktop albums section, select the album containing the picture you want to export to Google Earth.
coordinates can be exported	 select the NavPixTM, right click and select Export to Google Earth.
to Google Earth)	 navigate to a folder on your computer to save the file and then open it in Google Earth.
	You need to install the Google Earth software on your computer to be able to view the file you have created. You can download Google Earth from earth.google.com .
search for other NavPix TM	right-click on the desired NavPix TM and select Search for NavPix TM near this.
view all pictures in the library	click View all pictures at the bottom of the Desktop album section.

Photo Album preferences

 $\textit{My Mio} \rightarrow \textit{Options} \rightarrow \textit{Photo Album}$


Complete one of the following:

If you want to	Then
change your NavPix TM location on your computer	 click Change. select a location for your NavPixTM library. click Save or OK. The warning message will display and you will be prompted to confirm your action. Your NavPixTM library is moved to the new location.
receive a warning message before deleting an image from your device	select Warn me when permanently deleting a NavPix [™] from my Mio check box.
receive a warning message before deleting an image from your NavPix TM library	select Warn me when permanently deleting a NavPix [™] from my library check box.
create a new folder every time you import new photos	select the Import photos to a new album checkbox.
view NavPix TM when on a route	select the Show NavPix[™] on map checkbox.

Image Search

Image Search is a MioMore Desktop application powered by Flickr™ allowing you to download photos and import them to Photo Album. You can then upload the photo to the Flickr website, transfer photos to your Mio, export pictures to Google Earth or search for other NavPix[™] near the longitude and latitude of your NavPix[™].

MioMore Desktop → Image Search



How do I download NavPix[™] from the internet?

- 1. In the **Description** field enter a search description for the image you are looking for.
- 2. Select one of the Sort by options.
- Click Search.
 Thumbnails of the NavPixTM will display in the NavPixTM display area.

You can narrow your search by selecting the **Advanced search** check box and then selecting a city from the drop down list or by entering latitude and longitude details.

How do I import NavPixTM to Photo Album?

- 1. Select a picture or group of pictures you want to add to your Photo Album.
- Click Import to Photo Album.
 A new album is created in the **Desktop** album section of Photo Album.

How do I import NavPixTM to My Places?

- 1. Select a picture or group of pictures you want to add to your My Places.
- Click Add to My Places.
 The selected image is added to My Places.

Application Gallery

Application Gallery is a MioMore Desktop application that allows you to add, remove and rearrange applications on the *Main Menu* screen of your Mio.

MioMore Desktop → Application Gallery



How do I rearrange Main Menu applications on my Mio Main Menu?

- 1. Select any application from the **Device Main Menu** section.
- 2. Drag the application to the position that you would like it to appear on your Mio.
- 3. Click **Save to Device**. The order of the *Main Menu* screen is saved on your Mio.
- Click Reset to Default Settings to restore the Main Menu screen to the factory default order.

How do I remove an application from my Mio?

The following applications cannot be removed from your Mio:

- 1. Select any application from the **Device Main Menu** section.
- 2. Drag and drop the application to the **Available Settings** section.
- Click Save to Device.
 The application is removed from the Main Menu screen on your Mio and is no longer accessible.

How do I add an application to my Mio?

- 1. Select any application from the Available Settings section.
- 2. Drag and drop the application to the Device Main Menu section.
- Click Save to Device.
 The application is added to the Main Menu screen on your Mio.

My Places

My Places is a MioMore Desktop application that allows you to use Google Maps™ to view all places that you have saved on your Mio.

(i)


Make sure you have an active Internet connection for this feature.

My Places includes saved addresses, captured journeys and sound, Points of Interest, **NavPix**TM, and other locations. You can select, modify and delete places. You can also add locations from Connect, Photo Album and Image Search to My Places.

(i)

You can install a maximum of 99 locations on your Mio via My Places.

MioMore Desktop → My Places



How do I sort My Place locations?

You can sort My Place locations by type and name:

If you want to	Then
sort My Place locations by type	click Type on the My Places panel.
sort My Place locations by name	click Name on the My Places panel.

How do I edit a location name or notes in My Places?

- 1. From the My Places panel select the location you want to edit.
- Click the location icon on the Google map. The location summary pop-up will display.
- 3. Complete one of the following:

If you want to	Then	
edit the location name	 click the location name. 	
	 enter a new name or edit the existing name. The location name is changed in both MioMore Desktop and your Mio. 	

If you want to	Then	
edit the location notes	• click Edit notes.	
	 enter notes. The location notes is changed in both MioMore Desktop and your Mio. 	

How do I share a location from My Places?

- 1. From the My Places panel select a location you want to edit.
- Click the location icon on the Google map. The location summary pop-up will display.
- Click ☑.
 An email will open ready to send to your friends.

Your friend will receive the email with links to either save the image or to save the location in My Places in MioMore Desktop.

- If the location is a NavPixTM, your friend will receive the image as an attachment to the email.
- If the location is a captured journey, your friend will receive the journey as a .KMZ file attached to the email. Your friend will need to have Google Earth installed on the computer to view the KMZ file.
- If the location is a captured voice recording, your friend will receive the voice recording as a .WAV file attached
 to the email.

How do I play a captured sound file?

- 1. From the My Places panel select a captured sound that you want to listen to.
- Click the location icon on the Google map. The location summary pop-up will display.
- 3. Click ____.
 The captured sound file will play.

How do I upload a Na∨Pix[™] from My Places to Flickr™?

- 1. From the My Places panel select a location you want to edit.
- 2. Click the location icon on the Google map. The location summary pop-up will display.
- Click , then follow the prompts to upload a NavPix[™] to Flickr.
- **②** You need a Flickr account to upload a NavPix[™]. To create a Flickr account, visit www.flickr.com.

How do I delete a location from My Places?

- 1. From the My Places panel select a location you want to edit.
- Click the location icon on the Google map. The location summary pop-up will display.
- 3. Click **III**, then click **Yes** to delete the location.
- 4. The location is deleted from My Places.
- You can delete all locations in My Places by clicking on the My Places panel.

My Mio

Voice transfer

My Mio → Voice Transfer



Voice Transfer is a MioMore Desktop application that allows you to install or remove voice files.

Voice files take up space on your Mio's internal memory. If you do not use a voice file, you can remove it to free up space. You can later reinstall it to your Mio if required.

How do I install a voice file?

In the Available voice files section, select the voice file you would like to install, then click Install selected voices.

How do I remove a voice file?


In the Available voice files section, select the voice file you would like to remove, then click **Remove selected voices**.

Mileage Reporter

Mileage Reporter is not available for all models.

Mileage Reporter is a MioMore Desktop feature that allows you to create expense reports (.csv format) based on the mileage and estimated fuel usage recorded by your Mio.

My Mio → Mileage Reporter



	Element	Description
0	Timeframe	specifies the time for which the mileage report will be created.
		 select Show All to include all recorded mileage.
0	Report panel	Displays your trip log data.
€	Fuel	 Select to include the amount of fuel (estimate) used for the mileage recorded. If selected, specify the number of miles travelled per gallon, or miles/kilometers travelled per litre.
4	Report data buttons	Import report data from your Mio, clear all report data from your Mio or export data to a report (.csv).

How do I import my trip data?

- 1. Select Show All in the Timeframe section.
- 2. Select the Calculate fuel at check box, then enter the fuel consumption.
- 3. Click **Load from your Mio**. The *Transfer Log* progress bar will display.

All your trip logs can now be viewed in the Report panel section.

How do I export a mileage report?

- 1. Select a trip log from the **Report panel** section.
- 2. Click **Export report**. The *Open* dialog box will open.
- Select the file from your local or network drive, enter a name for your mileage report, then click Save.
 The mileage report is saved in .csv format.

How do I delete travel logs from my Mio?

- 1. Select a trip log from the **Report panel** section.
- 2. Click Clear from your Mio.
- 3. Click Yes to delete all travel logs.

Mileage Reporter preferences

My Mio → Options → Mileage Reporter

If you want to	Then
receive a warning when mileage logs are deleted from your Mio	select the Warn me when deleting all log files from my Mio check box.
calculate fuel economy preference by distance per volume	select the Distance per volume option.
calculate fuel economy preference by volume per distance	select the Volume per distance option.

Backup and Restore

You can save backups of data from your Mio, and later restore it if required.

My Mio → Backup and Restore



How do I backup my Mio?

- 1. Click Create new backup.
- 2. Select the data you would like to backup.
 - ☑ IMPORTANT: NavPixTM, sound and video files will not be backed up.
- Click OK.
 The backup will be saved to your computer. The backup will be listed on the Backup & Restore window.

How do I restore a backup to my Mio?

- 1. Select the backup from the list that you would like to restore.
- 2. Click **Restore**, then click **OK**. The backup will be restored to your Mio.

How do I delete a backup?

- 1. Select the backup from the list that you would like to delete.
- Click **Delete**, then click **OK**. The backup will be deleted.

Language

You can change the language for MioMore Desktop.



Simply select your preferred language.

Recover keys

(1) Make sure you have an active Internet connection for this feature.

In case you lose the license files for your Mio, you can recover them using this feature.

(1) Use this feature before you re-install the maps.

My Mio → Recover keys

Follow the prompts to complete the process.

Connect


Connect is not available for all models.

Connect is a MioMore Desktop application that allows you to search and install local POIs information from your computer to your Mio. POI locations will be shown in My Places.

Before you begin, ensure your Mio is correctly plugged into your computer: Plug the large end of the USB cable directly into a USB port on your computer (not a USB hub): plug the small end into — on the bottom of your Mio.

Make sure you have an active Internet connection for this feature.

MioMore Desktop → Connect



How do I search for a POI using Connect?

You can either search using the last known location on your Mio, or search for a new location by completing the following:

- 1. From the country drop down box, select a **Country**.
- 2. From the **Region/State** drop down box select a region or state if required.
- 3. In the Place name box, enter the first few letters of a city and then select your preference.
- 4. Click **Continue**. The *Available Services* page will display.
- 5. Select your preferred search service. The selected services page will display.
 - Depending on the country you are navigating, the available search services may vary.
- 6. Enter your search criteria, then click **Search**. The *Select search method* page will display.
 - For some countries you are required to accept the terms of use.
- Select your preferred search method, then click Search. A list of search results will display.

- 8. Click next to the POI you want to install to your Mio. The POI will be added to My Places.
- 9. Repeat step 8 to install more POIs to your Mio.

My Media

My Media is not available for all models.

My Media is a MioMore Desktop application allowing you to import music (.wav, .mp3, .wma) and video files from your computer to your Mio.

Before you begin, ensure your Mio is correctly plugged into your computer: Plug the large end of the USB cable directly into a USB port on your computer (not a USB hub); plug the small end into on the side of your Mio.

MioMore Desktop → My Media



	Element	Description
0	My Library	Displays a list of music files stored in the library on your computer.
		Click a field to display its contents in the Music display area.
0	My Mio	Displays a list of folders containing playlists stored on the Mio internal memory and memory card.
		Click a folder to display its contents in the Music display area.
6	Music display area	Displays music file from the selected folder
4	Toolbar	When a music file is selected, the icons that can be used will be available.

Toolbar



The following options are available on the toolbar:

	Button	Description
0	Import media to library	Imports the selected music files from your computer to the music library in MioMore Desktop.
2	Transfer to your Mio or Transfer to your computer	If you are viewing the music library in MioMore Desktop on your computer, this will display as Transfer to your Mio . Click to transfer the selected music files to your Mio. If you are viewing the music library on your Mio, this will display as Transfer to your computer . Click to transfer the selected music files to your computer.
6	Remove marked from list	Deletes the selected music files from the music library in MioMore Desktop on your computer.
4	Delete	Deletes the selected music files from the music library on your Mio.
6	Mark all	Selects all music files.
6	Invert selection	Reverse the selected and unselected music files.

How do I import a music file to my MioMore Desktop library?

- From the Toolbar section select Import media to library. The Open dialog box will display.
- 2. Navigate and select a music file you want to transfer.
- Click Open.
 The selected music file is imported and can be viewed in the display area.
- 4. Repeat steps 1-3 to transfer more music files.

How do I transfer a music file from MioMore Desktop to my Mio?

- 1. From the display area select a music file by selecting the checkbox next to it.
- 2. Click **Transfer to your Mio**.
 The Select location window will display.
- Select Mio or the MicroSD card as the destination for the file.
 The selected music file is transferred to your Mio.
- 4. Repeat step 1, 2 and 3 to transfer additional music files to your Mio.

You can also drag and drop the music file to your Mio or the memory card. You can save the music files either on your Mio's internal memory or the memory card if one is inserted.

How do I remove a music file from my MioMore Desktop playlist?

- 1. From the display area select a music file by selecting the checkbox next to it.
- Click Remove marked from list.
 The selected file is removed from your MioMore Desktop playlist.
 - You can select multiple files to remove them from the playlist.
- 3. Repeat steps 1 and 2 to remove additional music files to your Mio.
- Removing music files from the playlist will not delete the music files from your computer.

How do I remove a music file from my Mio playlist?

- From the My Mio section select Albums.
 Music files on your Mio are displayed in the display area.
- Select a music file you want to remove and then click Remove marked from list in the toolbar section. The selected music file is removed from the play list.
- 3. Repeat the process to remove additional music files from the playlist.
- You can select multiple files to remove them from the playlist. Removing music files from the playlist will not delete the music flies from your Mio.

How do I permanently delete a music file from my Mio playlist?

- From the My Mio section select Albums.
 Music files on your Mio are displayed in the display area.
- Select a music file you want to delete, right click and select **Delete**.
 The selected music file is permanently deleted from the play list as well as your Mio.
- 3. Repeat steps 1 and 2 to delete additional music files from your Mio.

What else I can do with My Media?

From the My Media section you can:

- sort music files by ratings, date, artist, album, etc
- preview a music file
- add your ratings to the music files

If you want to	Then
sort media files	from My Library , expand a field and select your field preference.
	You can sort music files by the following fields:
	■ Album name
	 Artist
	 Year of release
	■ Rating
	■ Genre
	■ Date Added

If you want to	Then
preview a media file	from the Music display area , select a music file you want to preview.
	to play the music file
	to pause the music file
	to stop the music file
	to forward the music file
	to rewind the music file
rate a music file	 from Music display area, select a music file you want to rate.
	 right click and select Rating to rate the file.
	You can rate music files as:
	A Bad
	AA OK
	AAA Good
	AAAA Very good
	AAAAA Excellent

Appendices

For more information

User Manuals

The latest User Manuals can be downloaded from our website: www.mio.com

Register your Mio with MioClub

If you have a faulty product or you would like to speak to a member of our Technical Support team, register your Mio on MioClub to obtain the Technical Support phone numbers for your Mio and your region.

Compliance

The software is based in part on the work of the Independent JPEG Group.

The software application uses a modified version of the Minimal XML Library, Flickr Library and Python Library. The libraries and thier use are covered by the GNU Lesser General Public License (www.gnu.org/licenses/lqpl.html).

The modified source code is available from the following URLs:

- Minimal XML Library: http://download.mio.com/opensource/gnu/mxml.zip
- Flickr Library: http://download.mio.com/opensource/gnu/FlickrNet.zip
- Python Library: http://download.mio.com/opensource/gnu/python25.zip

Speed Limit

Mio products are designed to be used as an aid to safer driving. Mio does not condone speeding or any other failure to comply with your local traffic laws. It is your responsibility to drive within the posted speed limit at all times and to drive in a careful manner. Mio accepts NO liability whatsoever for you receiving any speeding fines or points on your license through using this device. Mio does not guarantee the accuracy of the data contained within this database either expressed or implied. In the event you receive a fine or any other penalty for speeding or contravention of any traffic law, or are involved in an accident, Mio is not responsible for any damages of any type. In some countries the data information regarding speed limits may conflict with local law and/or regulations. It is your responsibility to make sure that your use of the data is in compliance with local laws and/or regulations. Usage is at your own risk.

Safety Camera POIs

Mio products are designed to be used as an aid to safer driving. You can receive messages to alert you to locations of safety cameras, which will enable you to monitor your speed through these areas. Mio does not warrant that all types and locations of safety camera data are available, as cameras may be removed, relocated or new cameras installed. Mio does not condone speeding or any other failure to comply with your local traffic laws. It is your responsibility to drive within the posted speed limit at all times and to drive in a careful manner. Mio accepts NO liability whatsoever for you receiving any speeding fines or points on your license through using this device. Mio does not guarantee the accuracy of the data contained within this database either expressed or implied. In the event you receive a fine or any other penalty for speeding or contravention of any traffic law, or are involved in an accident, Mio is not responsible for any damages of any type. In some countries the data information regarding safety or speed cameras may conflict with local law and/or regulations. It is your responsibility to make sure that your use of the data is in compliance with local laws and/or regulations. Usage is at your own risk.

Disclaimer

Mio operates a policy of ongoing development. Mio reserves the right to make changes and improvements to any of the products described in this document without prior notice. Mio does not warrant that this document is error-free. The screenshots and other presentations shown in this manual may differ from the actual screens and presentations generated by the actual product. All such differences are minor and the actual product will deliver the described functionality as presented in this User Manual in all material respects.

Copyright

© 2009 MiTAC International Corporation. Mio is a registered trademark of MiTAC International Corporation and is used under licence by Mio Technology NZ Ltd. All rights reserved.

The software contains proprietary information of MiTAC International Corporation; it is provided under a licence agreement containing restrictions on use and disclosure and is also protected by copyright law. Reverse engineering of the software is prohibited.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Mio.

Back-On-Track, Drive-Away, MioMore Desktop, Mio Spirit, NavPix, Slide Touch and Turn-by-Turn are either registered trademarks or trademarks of MiTAC International Corporation and are used under licence by Mio Technology NZ Ltd. All rights reserved.

MicroSD and the MicroSD logo are trademarks of SD Card Association.

This product uses the Flickr API but is not endorsed or certified by Flickr.

All other trademarks and registrations are the property of their respective owners.

Revision: R01 (6/2009)