



Product specifications

and parameters



**LOW BATTERY** 

Low battery warning When power is getting low , the cap will display a reminder.

## **WARRANTY CARD**



Customer Service Hotline: 4006 - 585 - 580 Customer Service Email: info@moikit.com Service Time: Monday to Friday 9: 00 - 18:00

Warranty Certificate of Moikit Products

2. The warranty can be claimed through showing of this Warranty Certificate along with

① The product was purchased from an unauthorized online store / reseller.
② The malfunction which is caused by unauthorized disassembling or modifying,
③ The damage or malfunction which is caused by dropping during use or transport.
④The damage or malfunction which is caused by improper use or use not in accordance


with the user manual.


§ The damage or malfunction is caused by improper maintenance or storage.

§ The product which has been repaired by any unauthorized maintenance locations.

4. When sending the product in for repair ,  $\,$  please include this card in the package.













No record for the current drinking









residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to

– Consult the dealer or an experienced radio/TV technician for help.

which the receiver is connected.

CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

## ENVIRONMENTALLY FRIENDLY DISPOSAL



Old electrical appliances must not be disposed of together with the residual waste,but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free.The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort,you contribute to recycle valueble raw materials and the treatment of toxic substances.



For more information, see the WeChat account "MoikitLife" or scan the QR code with your smart phone

