




SUPERSTAR™
HOTSHOT™





© Monster, LLC. 2016. All Rights Reserved

ENGLISH




ENGLISH

- 1 Microphone
- 2 LED indicator
- 3 NFC sensor
- 4 3.5mm audio line-in
- 5 On / off / pairing
- 6 Charging port


LED Indicator		
	Blue	Power on
	Blue (flashing)	Pairing
	Purple / Red (flashing)	Charging
	LED off	Power off

- * Please key in “0000” if passcode is required when pairing.
- * The speaker will automatically turn off after 15 minutes when there is no Bluetooth connection.
- * For optimum performance with your iOS Device, please ensure that your device is running iOS 4.1 or above.
- * Please fully charge the speaker before use.


Pairing with Bluetooth enabled device - Pairing by Near Field Communication (NFC)



Switch on the speaker and NFC feature on the device.




Tap your device on the NFC sensor for pairing.




After pairing, you can start playing music from your device.


Pairing with Bluetooth enabled device - Pairing by setting



Switch on the speaker and Bluetooth feature on the device.




Slide and hold the button to  position. Search "SuperStar HotShot" and select.



After pairing, you can start playing music from your device.


Pairing with other devices

Pair with 3.5mm audio line-in.



Answer / end call

Answer / end call by pressing your device.



* Please read these safety instructions carefully to ensure your personal and property safety.

Precautions 

- Do not use this product where contact with moisture, liquids, humidity or rain is possible to avoid electric shock and operating damage.
- Avoid exposing this product to direct sunlight, stove tops or any other heat sources to prevent operating damage.
- Do not cover the ventilation openings to prevent overheating.
- Do not drop, disassemble, deform, modify or insert any objects into this product as operating damage will result.
- Do not attempt to repair, modify or disassemble the product yourself. This product does not contain any user-serviceable components.
- Do not clean the product with alcohol, ammonia based cleaners, abrasive cleaners or wet cloth. Only clean with a soft dry cloth.
- Do not place this product on its side, slanted surfaces as well as the edge of high surfaces, like shelves, during music play to prevent accidental falling.
- Do not bring your product in to contact with any sharp objects as this may cause scratches and operating damage.
- Do not attempt to replace the product battery, it is built-in and is not user changeable.
- Observe all signs and displays that require an electrical device or RF radio product to be switch off in designated areas.
- Turn off your product prior to boarding an aircraft. Do not use the product inside an aircraft unless allowed by your airline.
- Dispose of the product and the product's battery in accordance with local laws and regulations.
- Do not dispose of the battery with regular household waste.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates use and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

FCC Notice

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1 This device may not cause harmful interference, and

2 This device must accept any interference received, including interference that may cause undesired operation.

FCC Caution

• Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Industry Canada (IC) Compliance Notice

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance

FCC ID: RJE178874, IC: 5153A-178874

To locate the FCC and IC identification numbers, please look on the underside of the SuperStar™ HotShot™.
Model number 178874

The crossed-out wheellie bin symbol means that the product must be disposed of separately in the European Union. These products must not be disposed of with unsorted household waste.

SIMPLIFIED EU DECLARATION OF CONFORMITY




The simplified EU declaration of conformity referred to in Article 10(9) shall be provided as follows: Hereby, Monster LLC declares that the radio equipment type "Monster HotShot" is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:
www.monsterproducts.com/support/compliance



Information to consumers in application of EU WEEE Directive 96/2002

This product is subject to European Union regulations that promote the re-use and recycling of used electrical and electronic equipment. This product required the extraction and use of natural resources and may contain hazardous substances. The symbol  above, on the product or on its packaging, indicates that this product must not be disposed of with your other household waste.

Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service, or the store from which you purchased the product. For more information about Monster products, please visit us at: www.MonsterProducts.com.

FORMAL WARRANTY CLAIM

HOW TO MAKE A CLAIM. In the event of a Product Defect, You must follow these instructions: (1) Call Monster within two (2) months after You discover a Product Defect (or should have discovered it, if such Product Defect was obvious); (2) Give a detailed explanation of how the damage occurred; (3) Obtain a Return Authorization Number; (4) Return the Product, shipping prepaid by You (to be refunded if You are entitled to a remedy under the Scope of this Limited Warranty), to Monster for verification of damage, along with a copy of Your original sales receipt or proof of purchase (invoice or packing slip) for such Product, the completed claim form, and printed Return Authorization Number on the outside of the return package (the claim form will include instructions for return).

TELEPHONE NUMBERS. If You bought the Product in the United States (1-877-800-8989), Latin America (Mexico 011-882-800-8989), or Asia Pacific (China 400-820-8973), contact Monster, LLC via postal service at 455 Valley Drive, Brisbane, CA 94005 (**PLEASE NOTE THAT MONSTER DOES NOT ACCEPT PRODUCTS SHIPPED TO THIS ADDRESS – FOLLOW INSTRUCTIONS IN “HOW TO MAKE A CLAIM” ABOVE**).

If You bought the Product in Australia, contact Monster's agent, Convoy International Pty Ltd (02 9700 0111), Unit 7, 1801 Botany Rd, Banksmeadow, NSW 2019 Australia. If You bought the Product anywhere else, contact Monster Technology International Ltd., Ballymaley Business Park, Gort Road, Ennis, Co. Clare, Ireland. You can use one of the following telephone numbers:

United States	1-877-800-8989	Greece	00800-353-12008
Canada	866-348-4171	Italy	800-871-479
Mexico	011-882-800-8989	Netherlands	0800-0228919
China	400-820-8973	Norway	800-10906
Ireland	353 65 68 69 354	Russia	810-800-20051353
Austria	0800296482	Spain	900-982-909
Belgium	0800-79201	Sweden	020-792650
Denmark	8088-2128	Switzerland	0800834659
Finland	800-112768	Czech Republic	800-142471
France	0800-918201	United Kingdom	0800-0569520
Germany	0800-1819388		

FURTHER PROCEEDINGS. Monster will determine whether a Product Defect existed. Monster may, at its discretion, direct You to obtain a repair estimate at a service center. If a repair estimate is required, You will be instructed on how to properly submit the estimate and the resulting invoice to Monster for payment. Any fees for repairs may be negotiated by Monster.

TIMING. If You bring a Formal Warranty Claim and fully comply with all terms and conditions of this Limited Warranty, Monster will use its best efforts to provide You with a remedy within thirty (30) days after receipt of Your Formal Warranty Claim (if You reside in the United States - forty-five (45) days if You reside elsewhere), unless obstacles outside Monster's control delay the process.

* Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

©2016 Monster, LLC

FCC 20cm




This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement.

IC 20cm

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.

FRANÇAIS



FRANÇAIS


- 1 Microphone
- 2 Indicateur LED
- 3 Capteur NFC

- 4 Prise audio 3.5mm
- 5 Allumer / éteindre / pairage
- 6 Port de chargement


Indicateur LED		
●	Bleu	Allumer
☀	Bleu (clignotant)	Pairage
☀	Violet / Rouge (clignotant)	Charge
○	Voyant DEL éteint	Éteindre

- * Veuillez taper "0000" si un code d'accès est requis au moment du pairage.
- * Lorsqu'il n'est pas connecté à un appareil, le haut-parleur se met automatiquement hors tension après 15 minutes.
- * Pour une performance optimale avec votre appareil iOS, veuillez vous assurer que votre appareil est doté d'iOS 4.1 ou d'une version ultérieure.
- * Vous devez charger la pile complètement avant d'utiliser le.


Connectez avec un appareil compatible Bluetooth - Pairage de communication en champ proche (NFC)



Allumez le haut-parleur et la fonction de communication NFC sur l'appareil.




Pour le pairage, tapez légèrement sur le capteur de communication NFC de votre appareil.




Une fois le pairage complété, vous pouvez commencer à faire jouer de la musique à partir de votre appareil.


Connectez avec un appareil compatible Bluetooth - Pairage par réglage



Allumez le haut-parleur et la fonction Bluetooth sur l'appareil.




Desliza y sostén el interruptor en la posición . Cherchez " SuperStar HotShot" et sélectionnez.



Une fois le pairage complété, vous pouvez commencer à faire jouer de la musique à partir de votre appareil.


Connectez avec un autre appareils

Pairage par prise audio 3.5mm.



Répondre à et terminer un appel

Répondez à et terminez un appel en appuyant sur votre appareil.



* Veuillez lire attentivement ces consignes de sécurité pour assurer votre sécurité et celle de vos biens.

Précautions

- Ne pas utiliser cet appareil sous la pluie, dans un environnement très humide ou lorsqu'il est en contact avec un liquide, pour éviter l'électrocution.
- Éviter d'exposer l'appareil directement au soleil, près d'une cuisinière, ou de toute autre source de chaleur.
- Ne pas couvrir les sorties d'air pour éviter une surchauffe.
- Ne pas laisser tomber, démonter, déformer ou insérer un quelconque objet dans l'appareil.
- Ne pas tenter de réparer, modifier ou démonter vous-même l'appareil, il ne contient aucun composant dont l'entretien peut être effectué par l'utilisateur.
- Ne pas nettoyer l'appareil avec de l'alcool, de l'ammoniac, des nettoyeurs abrasifs ou un chiffon humide. Utiliser un chiffon sec et doux pour le nettoyer.
- Ne pas placer l'appareil sur une surface inclinée ou le bord d'une surface élevée lors de l'écoute musicale pour éviter qu'il tombe.
- Ne pas mettre l'appareil en contact avec des objets pointus pour éviter les égratignures et les dommages.
- Ne pas tenter de remplacer la batterie de l'appareil, elle est intégrée et n'est pas modifiable.
- Observer tous les panneaux et les affichages concernant les dispositifs électriques et les appareils à fréquence radio (RF) pour les éteindre dans les zones désignées. Éteindre votre appareil avant d'embarquer dans un avion.
- Ne pas utiliser l'appareil dans un avion sauf si cela est autorisé par la compagnie aérienne.
- Se débarrasser de l'appareil et de sa batterie selon les règlements locaux.
- Ne pas jeter la batterie avec le reste des ordures ménagères.

Déclaration de FCC

Le présent équipement a été testé et approuvé comme étant conforme aux limites définies pour les dispositifs numériques de classe B, selon la section 15 des règlements FCC. Ces limites sont destinées à assurer une protection raisonnable contre les interférences nuisibles dans une installation résidentielle. Cet équipement produit, utilise et peut émettre de l'énergie radio électrique et, s'il n'est pas installé et utilisé conformément aux présentes instructions, peut causer des interférences nuisibles aux communications radio. Cependant, il n'existe aucune garantie contre ces interférences dans le cas où l'installation n'est pas conforme. Si cet appareil cause des interférences nuisibles à la réception des signaux de radio ou de télévision, ce qui peut être déterminé en allumant et en éteignant l'appareil, l'utilisateur peut tenter de corriger ces interférences par l'un des moyens suivants:

- Reorient or relocate the receiving antenna.
- Augmenter l'espacement entre l'équipement et le récepteur.
- Relier l'équipement dans une sortie sur un circuit qui est différent de ce que le récepteur est relié.
- Consulter le fournisseur ou un technicien radio / TV expérimenté, afin d'obtenir une assistance.

Avis de la FCC

Ce dispositif est conforme à la section 15 des réglementations de la FCC. Son fonctionnement est soumis aux deux conditions suivantes :

1 Cet appareil ne doit pas causer d'interférences nuisibles, et

2 Cet appareil doit accepter toute interférence reçue y compris du type pouvant créer un fonctionnement indésirable.

Avertissement de la FCC

- Tout changement ou modification, non expressément approuvé par la partie responsable de la conformité, peut annuler l'autorisation de l'utilisateur à utiliser cet appareil.
- Cet appareil et sa ou ses antennes n'ont pas à être co-localisées ou opérant en conjonction avec tout autre antenne ou transmetteur.

Industrie Canada (IC) Avis de Conformité

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil ne doit pas produire de brouillage;

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

FCC ID: RJE178874, IC: 5153A-178874

To locate the FCC and IC identification numbers, please look on the underside of the SuperStar™ HotShot™.

Model number 178874

The crossed-out wheelee bin symbol means that the product must be disposed of separately in the European Union. These products must not be disposed of with unsorted household waste.

DÉCLARATION DE CONFORMITÉ SIMPLIFIÉE POUR L'UE



La déclaration de conformité simplifiée pour l'Union européenne, mentionnée à l'article 10(9), doit se lire comme suit : Par la présente, Monster LLC déclare que l'équipement radio de type « Monster HotShot » est conforme à la directive 2014/53/UE.

Le texte intégral de la déclaration de conformité pour l'UE est disponible à l'adresse Internet suivante :
www.monsterproducts.com/support/compliance



Information aux consommateurs concernant l'application de la directive 96/2002 de l'UE sur les DEEE

Ce produit est assujéti aux règlements de l'Union européenne qui encouragent la réutilisation et le recyclage de l'équipement électrique et électronique usagé. Ce produit nécessite l'extraction et l'utilisation de ressources naturelles et peut contenir des substances dangereuses. Le symbole ci-dessus, apposé sur le produit ou sur son emballage, indique que vous ne devez pas jeter

 ce produit avec vos autres déchets ménagers. Il est de votre devoir de mettre au rebut votre équipement usagé en l'apportant dans un point de collecte désigné pour le recyclage des déchets d'équipements électrique et électronique. La collecte et le recyclage séparés de vos déchets d'équipement au moment de la mise au rebut contribueront à la conservation des ressources naturelles et assureront un recyclage adéquat permettant de protéger la santé humaine et l'environnement. Pour obtenir de l'information sur les endroits où vous pouvez déposer vos déchets d'équipement à des fins de recyclage, veuillez communiquer avec le bureau municipal de votre région, votre service d'élimination des déchets ménagers ou le magasin où vous avez acheté le produit. Pour obtenir de plus amples renseignements sur les produits Monster, veuillez visiter notre site au www.MonsterProducts.com.

RÉCLAMATION FORMELLE SOUS GARANTIE

COMMENT EFFECTUER UNE RECLAMATION. En cas de constat d'un Défaut du Produit, Vous devez suivre ces instructions : (1) Appelez Monster dans les deux (2) mois suivant la date à laquelle Vous avez constaté un tel Défaut du Produit (ou auriez dû le constater, si un tel Défaut du Produit était évident) ; (2) Fournissez une explication détaillée de la manière dont le dommage s'est produit ; (3) Obtenez un Numéro d'Autorisation de Retour ; (4) Retournez le Produit, en port prépayé (qui Vous sera remboursé si Vous avez droit à un recours en vertu du champ d'application de la présente Garantie Limitée), à Monster pour vérification du dommage, accompagné d'une copie de l'original de Votre ticket de caisse ou preuve d'achat (facture ou emballage) concernant ledit Produit, du formulaire de réclamation dûment rempli et du Numéro d'Autorisation de Retour imprimé à l'extérieur du colis de retour (le formulaire de réclamation contiendra des instructions pour le retour).

NUMEROS DE TELEPHONE. Si Vous avez acheté le Produit aux États-Unis (1-877-800-8989), en Amérique latine (Mexique, 011-882-800-8989) ou dans la région Asie-Pacifique (Chine, 400-820-8973), contactez Monster, LLC par voie postale, à l'adresse : 455 Valley Drive, Brisbane, CA 94005 (**VEUILLEZ NOTER QUE MONSTER N'ACCEPTÉ AUCUN PRODUIT EXPÉDIÉ À LA PRÉSENTE ADRESSE – VEUILLEZ SUIVRE LES INSTRUCTIONS MENTIONNÉES DANS LA SECTION « COMMENT EFFECTUER UNE RÉCLAMATION » CI-DESSUS**).

Si Vous avez acheté le Produit en Australie, contactez le représentant de Monster : Convoy International Pty Ltd (02 9700 0111), Unit 7, 1801 Botany Rd, Banksmeadow, NSW 2019 Australie. Si Vous avez acheté le Produit dans une autre région du monde, contactez Monster Technology International Ltd., Ballymaley Business Park, Gort Road, Ennis, Co. Clare, Irlande. Vous pouvez utiliser l'un des numéros de téléphone suivants :

États-Unis	1-877-800-8989	Allemagne	0800-1819388
Canada	866-348-4171	Grèce	00800-353-12008
Mexique	011-882-800-8989	Italie	800-871-479
Chine	400-820-8973	Pays-Bas	0800-0228919
Irlande	353 65 68 69 354	Norvège	800-10906
Autriche	0800296482	Russie	810-800-20051353
Belgique	0800-79201	Espagne	900-982-909
République tchèque	800-142471	Suède	020-792650
Danemark	8088-2128	Suisse	0800834659
Finlande	800-112768	Royaume-Uni	0800-0569520
France	0800-918201		

AUTRES PROCEDURES. Monster déterminera la réalité d'un Défaut du Produit. Monster peut, à sa seule discrétion, Vous orienter vers un centre d'assistance afin d'obtenir un devis de réparation. Si un devis de réparation est nécessaire, Vous serez informé de la façon de transmettre ce devis ainsi que la facture correspondante à Monster pour paiement. Tous les frais de réparation peuvent être négociés par Monster.

CALENDRIER. Si Vous fournissez une Réclamation Formelle sous Garantie et respectez toutes les conditions d'utilisation de la présente Garantie Limitée, Monster mettra en œuvre tous les moyens à sa disposition pour Vous fournir un recours dans les trente (30) jours suivant la réception de Votre Réclamation Formelle sous Garantie (durée applicable si Vous résidez aux États-Unis – quarante-cinq (45) jours si Vous résidez dans une autre région du monde), à moins que des obstacles hors du contrôle de Monster retardent le processus.

* Nos articles sont livrés avec des garanties qui ne peuvent être exclues en vertu de la Loi australienne de protection des consommateurs. Vous avez droit à remplacement ou à remboursement en cas de dysfonctionnement majeur, et à indemnisation pour tout autre perte ou dommage raisonnablement prévisible. Vous disposez également du droit à réparation ou à remplacement des articles, si la qualité desdits articles est inacceptable et que le dysfonctionnement n'est pas considéré comme majeur.

©2016 Monster, LLC