# QUICK GUIDE

Keyboard & Mouse RF Combo

Shortcut keys

Scroller

Left-click button

Right-click button

Connect button

1. Package Contents:

a. Keyboard.　b. Mouse.　c. Receiver Box.
d. Software.　e. Batteries.

a.

b.

c.　d.　e.

Software

AAx2　AAx2

System Requirements

To use the mouse software and the hot keys on your multimedia keyboard,
you need the following:

- Windows XP/ME/2000/98SE/NT 4.0 or later
- PS/2 mouse and keyboard ports
- Sound Blaster compatible sound card (for CD/VCD/DVD, and MPEG operation)
- CD-ROM drive (for software installation and CD/VCD operation)

1

2. Install the Batteries:

a. Mouse.　b. Receiver. c. Keyboard

a.

unlock

AAx2

PS/2 keyboard
connector (purple)

PS/2 mouse
connector (green)

c.

AAx2

Mouse/Keyboard
connect button

b.

2

3. Notice ⚠ Important

1. Place the RF receiver in a good location.

Place the receiver
at least 8 inches(20cm)
from electrical devices
such as the computer or monitor.

2. Place the keyboard and the mouse in the
proper location for your computer.

8 in (20 cm)

3

4. Installation:

a. Turn off the computer. Connect
   the receiver cable to the PC
   via PS/2 ports.

keyboard PS/2 (purple)
mouse PS/2 (green)

b. Place receiver away from
   electronic devices.

8 in (20 cm)

4

5. ID Select ⚠ Important

(A) ID connect for keyboard
    Press ID select switch on Receiver and then Keyboard
    within 10second.

(B) ID connect for mouse
    Press ID select switch on Receiver and then Mouse
    within 10second.

(A)　Connect switches

receiver
connect button

(B)

receiver
connect button

Connect
switches

Note! Repeat this Step when connecting the Wireless RF
Keyboard & Mouse for the first time and after replacing
the batteries.

5

6. Installing Device Drivers

1. After you have installed and connected Desktop Wireless,
   insert the Installation CD into the CD-ROM drive.
   The CD supports Windows Autoplay and starts running
   automatically. If not, access the CD from Windows Explorer,
   and then click the relevant CD-ROM drive. Double click the
   Setup.exe file.

2. Select the driver and applications that you want to install,
   and then click the ***OK*** button.

3. Follow the onscreen instructions to complete the installation.

7. Troubleshooting

Wireless RF Keyboard & Mouse not detected

If the keyboard and mouse don't respond to activity,
follow these steps:

1. Ensure that the receiver cable is properly connected to the
   PS/2 mouse and keyboard ports . Ensure that the purple
   connector is connected to the keyboard port, and the green
   connector is connected to the mouse port.

2. Ensure that the batteries have been installed correctly .

3. Ensure that there are no IRQ or I/O address conflicts.
   Refer to your op-erating system user's manual for
   information on resolving IRQ and I/O address conflicts.

6

7