


**Galaxy 5000 mAh Wireless
Powerbank with 3-in-1 Cable**
Instruction Manual
M617Q



Features:

1. USB Output
2. Type C Input/Output
3. 2in1 Dual Compatible Adapter (for Apple iOS and Android Devices)
4. Type C Adapter
5. Built-in USB Cable
6. ON/OFF Button
7. LED indicator
8. Wireless Charging Suction Pad

What's included:

- 1 x 5000 mAh Wireless Power Bank
- 1 x Instruction Manual

Tech Specifications

- 5000mAh poly-li battery
- Input power: 5V/2A
- Type C Output power: 5V/2A
- USB Output power: 5V/2A

LED Indicators:

- ON/OFF Button: Press once to view the remaining power capacity.

Instructions:

1. Charging the power bank:
 - a. Charge the power bank fully before initial usage.
 - b. Insert USB cable into AC wall adapter or computer USB port to charge the device, LED indicator will flash BLUE when charging and will stop once fully charged.
2. Charging a mobile device:
 - a. To charge a mobile device, push out integrated tip, and insert into the desired device. Device will begin to charge automatically.
3. Charging Mobile phones and other electronic devices with wireless output:
 - a. Place wireless charging enable device on Wireless Charging Pad. Press on/off button once, then LED indicators show green color. The device will begin to charge. LED indicator will turn RED when charging.
 - * *Note: In order to charge devices, use only the accessory cable or the cable included with your own device by the manufacturer.*

SAFETY PRECAUTIONS:

WARNING—When using this product, basic precautions should always be followed, including the following:

1. Read all the instructions before using the product.
2. Charge the power bank fully before initial use. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
3. To reduce the risk of injury, close

supervision is necessary when the product is used near children.

4. Do not expose the device to moisture.
5. Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.
6. Do not use the device if damaged or modified.
7. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
8. Do not disassemble the device. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury.
9. Do not expose the device to fire or excessive temperature. Exposure to fire or temperatures above 212°F may cause explosion.
10. Have servicing performed by a qualified repair person using only identical replacement parts.
11. This will ensure that the safety of the product is maintained.

WIRELESS CHARGING ENABLED DEVICES:

iPhone 8/8Plus/X/Samsung Galaxy S8/S8+/S7/S7 Edge/S6/S6 Edge, Nokia Lumia 1020/920/928, HTC 8X, HTC Droid DNA, HTC RZound, HTC Incredibly 4G LTE, Moto Droid Turbo, Motorola Moto 360 Smart Watch, Moto Droid Maxx, Droid Mini, Google Nexus 6/4/5/7 (2013), LG D1L, LG LTE2, LG G2 (Verizon), Blackberry Z30 (Verizon)

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.