

**Temporary Confidentiality Requested****Exhibit 8: Draft User's Manual -- 47 CFR 2.1033(b)(3)**

The attached User's Manual is the final production-intended version of the generic Motorola International English User Manual. This guide will be adapted to carrier-specific versions, but the key information herein will be retained. Translations into other languages will also be done to support the needs of other markets. Minor revisions may be made to these manuals, prior to and subsequent to, placing this product onto the market. Selected portions of the User Guide can be found as indicated below:

<b>8.1 Safety and Regulatory Section:</b>	<b>Page 26<sup>1</sup></b>
<b>8.2 Specific Absorption Rate (SAR) Data:</b>	<b>Page 29<sup>1</sup></b>
<b>8.3 Part 15B Declaration of Conformity:</b>	<b>Page 31<sup>1</sup></b>
<b>8.4 Guidance for use with Hearing Aids:</b>	<b>Page 12, 35<sup>1</sup></b>

---

<sup>1</sup> See *P56LM1\_Ex\_08 (User Guide – 2 of 2).pdf* for these sections.

# MOTOROLA i786 Motorola International English Generic User Guide 8/25/10

## **Dummy Page - To be discarded before printing**

Use this template with A6MotoLandscapeProduct1 StructApps.

See the Reference Pages for template user instructions.

**Please note:**

This draft documents features as they were available and functioning at the time of production.

This draft uses an A6-size template.

# Congratulations

## MOTOROLA i786

The MOTOROLA **i786** brings the convenience of push-to-talk calls together with a sleek slider design in an affordable package.

- **Private Calls.** Stay in touch with your family, friends, and colleagues with the simple touch of a button.
- **My Phone, My Way.** It's your phone—make it that way. Customize your home screen with personal pictures, and change wallpapers and ringtones.

## More information

**On your computer**—Go to [www.motorola.com/support/](http://www.motorola.com/support/).





DRAFT - MOTOROLA CONFIDENTIAL  
& PROPRIETARY INFORMATION

**Caution:** Before assembling, charging or using your phone for the first time, please read the important legal and safety information packaged with your phone.

# Your phone

the important keys & connectors



**Note:** Your phone might look a little different.

# Contents

Menu map	3
Let's go	5
Basics	6
Calls	11
Push-to-Talk	15
SDG calls	21
MOTOTalk™	24
Talkgroups	28
Text entry	29
Contacts	30
Messaging	30
Personalize	35
Web	38
Multimedia	39
Camera	48
Bluetooth™ wireless	51
Tools	54
Security	56
Safety, Regulatory & Legal	58

DRAFT - MOTOROLA CONFIDENTIAL  
8/8/2008

# Menu map

## main menu

### Recent Calls

### Contacts

- [New Contact]
- [New SDG List]
- [New Msg Group]

### Messages

- [Create Message]
- Voice Mail
- Inbox
- Drafts
- Outbox
- Fax Mail
- Net alert
- Sent Items

### Web

- Net

### Multimedia

- Media Center
- My Images
- My Music
- My Videos
- Camera
- Camcorder
- Ring Tones
- VoiceRecord

### Push To Talk

- Call Alert
- PT Manager
- Quick PTT
- PTT Options
- MOTOTalk

### Games and Apps

- Buy More
- Alarm Clock Plus
- My Images
- My Music
- My Videos
- Java System
- Memory Card

### Tools

- My Info
- Profiles
- Alarm Clock Plus
- Bluetooth
- GPS
- Datebook
- Call Timers
- Memo

### Settings

- (see **Settings** menu)

This is the standard main menu layout.  
Your phone's menu may be different.

## settings menu

### Display/Info

- Wallpaper
- Text Size
- Theme
- Home Icons
- Backlight
- Clock
- Menu View
- Large Dialing
- Language

### Phone Calls

- Set Line
- Any Key Ans
- Auto Redial
- Call Waiting
- Auto Ans
- Flip Activation
- Busy Text Response
- Minute Beep
- Call Duration
- TTY
- Hearing Aid
- Notifications
- DTMF Dialing
- Call Forward
- Prepend

### Personalize

- Reorder Menu
- Shortcuts
- Carousel
- Up Key
- Down Key
- Left Softkey
- Right Softkey
- Power Up

### Volume

- Ringers/Alerts
- Speaker
- Earpiece
- Multimedia
- Keypad

### Voice Playback

- Speak Text
- Speak Caller
- Voice
- Multimedia Volume

### Memory Card

- Remove Card
- Store Media
- Format Card
- Help

## settings menu (con't.)

### Security

- Phone Lock
- Keypad Lock
- SIM PIN
- GPS PIN
- Change Passwords

### Advanced

- Alert Timeout
- Headset/Spkr
- Connectivity
- Reset Defaults
- Return to Home
- Transmitters
- Phone Only

### Connections

- Bluetooth
- USB

# Let's go


let's get you up and running

## Assemble & charge


1 Remove cover




2 SIM in




3 MicroSD in



4 Battery in



5 Cover on



6 Charge up



**Caution:** Please read "Battery Use & Safety" on page 58.

## Battery indicators

indicator



Blue, three bars, 100% to 90% capacity.



Green, two bars, 65% capacity.



Yellow, one bar, 10% capacity.



Red, flashing bar, 5% capacity.



Charging.

## Turn it on & off

To turn on your phone, press and hold End/Power  for a few seconds or until the display turns on.



**Note:** If you press End/Power  for more than four seconds, the phone will turn on in Transmitters Off mode. See "Transmitters" on page 9.

To turn off your phone, press and hold End/Power  for a few seconds.

## Enable security

You will need to enable security the first time you power on your phone or within 10 days of first activation of your phone.

- 1 Press **Ok**.
- 2 You are prompted to enable security. Press **Yes** and follow the on-screen instructions.
- 3 Press End/Power  to return to the home screen.

DRAFT - MOTOROLA CONFIDENTIAL  
PROPRIETARY INFORMATION

## Basics

### About this guide

This guide shows how to locate a menu feature as follows:


**Find it:** Menu  >  **Settings** > **Phone Calls**

This means that, from the home screen:

- 1 Press the Menu key  to open the main menu.
- 2 Press the Navigation Key to scroll to the  **Settings** menu option and press the OK key  to select it.
- 3 Press the Navigation Keys to scroll to **Phone Calls**, and press the OK key  to select it.

## Home screen

Your phone shows the *home screen* when you are not on a call or using the menu.



**Note:** Your home screen might look different from the one shown, depending on your service provider.

*Soft key labels* in the home screen show the current soft key functions.

Indicators at the top of your phone's display provide important status information, such as incoming calls, missed messages, and other conditions. Here are the indicators you may see:

### indicator



**Signal Strength**—Shows the strength of the network connection.

### indicator



**Active Phone Line**—Shows if phone line one or two is active.



**Speaker On**—Sounds associated with PTT calls, SDG calls, and Talkgroup calls are set to come through the speaker.



**Speaker Off**—Sounds associated with PTT calls, SDG calls, and Talkgroup calls are set to come through the earpiece.



**Ringer Off**—Phone is set not to ring.



**Vibrate All**—Phone is set to vibrate for all incoming calls, messages, and notifications.



**No Service**—Phone is in area with no service coverage.



**New Message**—Phone has a new text message.



**Packet Data**—Phone is ready to transfer packet data.

## indicator

-  **Battery Level**—Shows battery charge level. The more bars, the greater the charge.
-  **Bluetooth On**—Bluetooth power is **On**.
-  **New Voicemail Message**—Phone has a new voicemail message.

## Carousel menu

Get quick access to your favorite applications, right on your home screen.

### Open applications

- 1 Press the Navigation Key left or right until you highlight the desired application.
- 2 Press to  launch the application.

**Note:** Availability of the Carousel menu feature is dependent on your service provider.

### Choose applications

You can customize the Carousel with your most often used applications.

- 1 Press Menu  >  **Settings** > **Personalize** > **Carousel**.

2 Highlight the position on the Carousel menu you would like the application to occupy and press .

3 Highlight an application and press  to select it.


### Auto hide

To set the Carousel menu to hide when not in use, press Menu  >  **Settings** > **Personalize** > **Carousel** > **Auto Hide**.

### Adjust volume

Press the volume keys up or down to:

- change the earpiece volume during calls
- change the ringer volume from the home screen
- turn off a call alert before answering the call



**Tip:** You can quickly set your ringer to **Vibrate All** by holding down the volume key while on the home screen.

## Navigation key

Press the Navigation Key up, down, left, or right to scroll to items in the display. When you highlight the desired item, press  to select it.



## Transmitters

Consult airline staff about the use of the Transmitters Off feature during a flight. Turn off your phone whenever instructed to do so by airline staff.

Transmitters Off turns off your phone's calling and Bluetooth features in situations where wireless phone use is prohibited. You can use the phone's other non-calling features when the transmitters are turned off.

**Find it:** Menu  >  **Settings** > **Advanced** > **Transmitters** > **Off**

## Features for the hearing impaired

Use your phone with a hearing aid

**Note: Your phone has a hearing aid rating of M\_.**


For more information, see "Hearing Aid Compatibility with Mobile Phones" on page 67.

For best results, use the optimization and phone setting. They generally apply as well for users with cochlear implants.

## Optimize your phone position and orientation

While on a phone call slide your phone up and down, then left and right until best microphone coupling is obtained. You also may need to adjust your hearing aid (HA) volume setting.


If your HA has a telecoil, activate its switch, then also rotate the phone as illustrated to align the telecoils.



**Note:** Some automatically switched hearing aids may need an auxiliary switching magnet.

If you are unsure whether your HA is telecoil equipped or needs an auxiliary magnet, please refer to your HA

user guide or contact a hearing aid professional or supplier.



### Choose your hearing aid setting

**Find it:** Menu > **Settings** > **Phone Calls** > **Hearing Aid**

The **Microphone** option optimizes your phone for microphone coupling. The **Telecoil** option meets the US federal requirements for telecoil coupling. The factory default setting for this feature is **Off**.

## TTY

### features

#### turn on TTY feature

Press Menu > **Settings** > **Phone Calls** > **TTY** > **Use TTY** > **On**.

#### choose TTY mode

Press Menu > **Settings** > **Phone Calls** > **TTY** > **Type** > **TTY, VCO** or **HCO**.

#### change the TTY baud rate

Press Menu > **Settings** > **Phone Calls** > **TTY** > **Baud** > **45.45** or **50.00**.

#### change TTY mode during a call

While in a TTY call, press Menu > **In Call Setup** > **TTY** > **Type** > **TTY, VCO** or **HCO**.

# Calls

*it's good to talk*

## Make & answer calls

Enter a number, then press Talk .



To answer a call, press Talk .

To end a call, press End/Power .

## Any key answer

To answer phone calls by pressing any key on the keypad, press Menu  >  **Settings** > **Phone Calls** > **Any Key Ans** > **On**.

## Call waiting

To accept the second call and put the active call on hold, press Yes.

To accept the second call and end the active call, press Talk .

## Three-way calls

To start a conference call, call the first number. After they answer, press Menu  > **3 Way**. Enter the second number. When the next number answers, press Menu  > **Join**.

**Note:** You can't make any other phone calls during a three-way call, even if one party hangs up.

## Redial

To redial your last outgoing call, press and hold Talk  or, if your last call was a PTT call, press the PTT Button.

## Unanswered calls

If you receive a phone call and press End/Power  before it goes to voice mail, you can send an automatic text message to the other caller.

**Find it:** Menu  >  **Settings** > **Phone Calls** > **Busy Text Response**

options	
<b>Off</b>	Turn feature off.
<b>Soft Key</b>	Press Send Msg to send text message.
<b>Automatic</b>	Send message automatically without being prompted.

## Call forward

Call forwarding sends calls to the phone numbers you specify. You can forward all calls to one number, or forward missed calls to different numbers depending on the reason you missed the call. You can forward phone lines one and two independently.

**Find it:** Menu  >  **Settings** > **Call Forward**

To forward all calls select **All Calls**, then select **To** and enter the phone number you want all you call forwarded to.

You can also specify a forwarding number for each type of missed call by selecting **Detailed** and choosing from the following options:

options	
<b>If Busy</b>	When your phone is on a call or transferring data.
<b>If No Answer</b>	When you don't answer on the first four rings.
<b>If Unreachable</b>	When your phone is out of coverage or powered off.

## Speed dial

Each phone number stored in **Contacts** is assigned a specific speed dial number, which you can use to call that number.

- 1 From the home screen, use the keypad to enter the speed dial number assigned to the phone number you want to call.
- 2 Press .
- 3 Press **Talk** .

## Turbo dial

The first nine entries in your contacts are set for turbo dial. They can be called by pressing and holding the speed dial number (1 through 9).

## Voice names

You can place calls by speaking commands to your phone if you have previously assigned a voice name to your contacts.

### Assign voice names to contacts

- 1 Press Menu  >  **Contacts** > **[New Contact]**.
- 2 Assign a name, phone number and select **[Options]**.
- 3 Select **Voice Name** and follow the prompt to record the voice name.

4 Press **Back** and then **Save**.

### Place a call using voice name

Press and hold the Speaker key ( until you are prompted to say the voice name. The phone will automatically place the call.

### Handsfree

**Note:** Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.

During a call:

- To use the speakerphone, press Menu ( > **Speaker** or press Speaker (.
- To connect a Bluetooth™ device, press Menu ( > **Use Bluetooth**.

### Recent calls

**Find it:** Menu ( > ( Recent Calls

**Tip:** When you're in the home screen, you can press Talk ( to go to **Recent Calls**.

The **Recent Calls** list contains information associated with calls you have made and received, and call alerts you have received.

**Tip:** When a **Recent Calls** entry is associated with a **Contact** containing a mobile phone number, you can

compose a message to the caller by pressing **Create**. You can also edit the **Contact** by highlighting it and pressing Menu ( > **Edit**.

The **Recent Calls** list also contains Push to Send items associated with PTT calls you have made or received, such as:

- contact information
- My Info
- short text messages
- pictures sent or received
- **Datebook** events

The **Recent Calls** list displays up to 20 of the most recent calls and call alerts.

- 1 Press Menu ( > ( Recent Calls.
- 2 Scroll through the list.
- 3 To view more details, press (.

### Store an item to contacts from recent calls

Phone calls, Private calls, My Info, **Contacts** or Location entries received from other phones can be stored to **Contacts** from the **Recent Calls** list.

- 1 Scroll to the item you want to store.

- 2 Press **Save**, and select **[New Contact]** to store the information as a new entry, or select an existing entry and update the information.
- 3 Press **Done** to save your changes.

## Your phone number

**Find it:** Menu  >  **Tools** > **My Info**

## Emergency calls

**Note:** Your service provider programs one or more emergency phone numbers (such as 911 or 112) that you can call under any circumstances, even when your phone is locked. Emergency numbers vary by country. Your pre-programmed emergency numbers may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

- 1 Enter the emergency number.
- 2 Press Talk  to call the emergency number.

**Note:** Emergency calls cannot be placed while the keypad is locked, or if your phone is displaying a No Service message on the screen. To unlock the keypad, press Menu  > .

**Note:** Your mobile device can use AGPS satellite signals to help emergency services find you (see "GPS & AGPS" on page 64).

## International calls

If your phone service includes international dialing, press and hold 0 to insert your local international access code (indicated by +). Then, press the keypad keys to dial the country code and phone number.

## Cool down

In very limited circumstances, such as where your phone has been exposed to extreme heat, "Cool Down" message screens will appear. To avoid possible damage to your battery and phone, you should follow these instructions until the phone is within its recommended temperature range. When your phone is in "Cool Down" mode, only emergency calls can be made.

## Push-to-Talk

one or more, talk to them all


### Private calls

Private calls are push-to-talk calls between two people.

#### Make and answer private calls

To **make** a private call:

- Enter the recipient's PTT number.
- Press Menu  > **Contacts**, and select a contact that has a PTT number.



To **talk**, press and hold the PTT Button. To **listen**, release the PTT Button.

To **answer** a private call, press the PTT Button after the caller has stopped talking.

To **end** a private call, press End/Power  or do nothing. The call will end after a few seconds.

#### Set push-to-talk speaker

You can listen to push-to-talk calls through your phone's speaker or earpiece. Press Speaker  to turn the speaker on or off.

## One touch PTT

You can customize the PTT Button for quick access to push-to-talk functions from the home screen.

**Find it:** Menu  >  **Push To Talk > PT Manager > Configure > One Touch PTT**

options	
<b>Off</b>	Turn off <b>One Touch PTT</b> .
<b>Quick PTT</b>	Go to <b>Quick PTT</b> . See "Quick PTT" on page 16.
<b>Last Call</b>	Call the most recent Private ID or SDG list on the <b>Recent Calls</b> list.
<b>PTT Contacts</b>	Launch the <b>PTT Contacts</b> list from the home screen by pressing the PTT Button.
<b>Assigned No.</b>	Call a Private ID you assigned. Enter the number using your keypad, or press <b>Search</b> and select from <b>Contacts, Recent Calls, or Memo</b> .
<b>PT Manager</b>	Go to the <b>PT Manager</b> . See "PT manager" on page 16.