INSTANT MESSAGES

To send and receive instant messages, you can use an instant messaging app or your browser.

- To download and use an instant messaging app, touch Market > Apps > Communication, then choose an app for your provider. Once you download the app, you'll see it in your "APP MENU" on page 10.
- If you don't see an app for your IM provider, you can use your web browser. Touch > Touch srowser, then enter your provider's website. Once you're there, follow the link to sign in.

Note: To browse instant messaging apps from your PC, go to www.android.com/market.

TEXT ENTRY

keys when you need them


DEVICE KEYPAD

You can type using the phone's keypad.



TOUCHSCREEN KEYPAD

You can open a touchscreen keypad by touching a text field. To close the keypad, touch Back (5).



MULTI-TOUCH

To change the sounds, corrections, and other settings for your touchscreen keypad, touch Menu 🚼 > Settings > Language & keyboard > Input method > Multi-touch keyboard.

TYPING TIPS

То	
Enter a capital letter	Touch Shift 全.
Cut, Copy or Paste text you selected	Touch and hold the text box to open the editing menu.
Delete a character (hold to delete more)	Touch Delete ☐.
Enter symbols	Press Alternate ALT + Symbols SYM.
Start a new line	Touch 🚽

To change your text entry settings and see the dictionary of terms you've used, from the home screen touch Menu 📳 > Settings > Language & keyboard.

TEXT ENTRY SETTINGS

When you use the touchscreen keypad, your phone suggests words from your dictionary and chosen language. Your phone also automatically enters apostrophes in some words, like "dont."

Find it: From the home screen, touch Menu 🔡 > Settings > Language & keyboard

- To edit your dictionary, touch **User dictionary**.
- To change the language and the style for your touchscreen keypad, touch Select locale.
- To change built-in keypad settings, like Auto-correct errors or Auto-cap, touch Device keyboard.
- To change the sounds, corrections, automatic correction settings, and other settings for your touchscreen keypad, touch Multi-touch keyboard.

WEB

surf the web with your phone

QUICK START: BROWSER

Find it: | > | Browser



Note: If you can't connect, contact your service provider.

CONNECT

Your phone uses the mobile phone network (over the air) to automatically connect to the web.

Note: Your service provider may charge to surf the web or download data.

To use a wireless network, from the home screen touch Menu 📳 > Settings > Wireless & networks. Touch Wi-Fi to turn it on, then touch Wi-Fi settings to search for nearby wireless networks. Touch a network to connect. There's more in "Wi-Fi" on page 33.

WEB TOUCH TIPS

ZOOM & MAGNIFY

In web pages, use double-touch to zoom in/out. You can also use pinch-to-zoom, see " ${\bf PINCH-TO-ZOOM}$ " on page 7.

SELECT LINKS

When you touch a link, your phone outlines it. If you touch and hold the link, your phone shows options, like **Open in n**

source/android.com/ - Options

Android Community - Tracking the Android
Platform

shows options, like $\mbox{\bf Open in new window}$ or $\mbox{\bf Bookmark link}.$

BROWSER OPTIONS

Touch Menu 🔠 to see browser options:

Options	73
New window	Add a new browser window.

Options	
Bookmarks	Show your bookmarks. Touch Add to add the current page to your bookmarks.
Windows	View the browser windows that are currently open.
Refresh 😕	Reloads the current page.
Forward	Navigate to a previously viewed page.
More	Shows browser options, like Find on page, Select text, Page info, Share page, Downloads, and Settings.

DOWNLOAD APPS

Warning: Apps downloaded from the web can be from unknown sources. To protect your phone and personal data, only download apps from sources you trust, like "ANDROID MARKET"" on page 30.

Note: All apps downloaded are stored in your phone memory.

To download apps:

- 1 If you want to download apps from any web page, from the home screen touch Menu > Settings > Applications > Unknown sources.
- 2 To open the browser, touch **a** > **Browser**.
- 3 Find the app you want to download, and touch the download link.

MANAGE YOUR DOWNLOADS

To view files or applications you have downloaded, touch Some South Sout

To clear your download history, touch Menu 🔡 > Clear list. To cancel, touch Menu 🔡 > Cancel all downloads.

DATA SAVER

Use less data by automatically turning off photo downloads, lowering image sizes, and more.

Find it: Menu 🔐 > Settings > Battery & data manager > Data delivery

LOCATION

toss away your maps

GOOGLE MAPS™

Find it: 🔳 > 🚮 Maps



Google Maps offers powerful, user-friendly mapping technology and local business information—including business locations, contact information, and driving directions.

For help, just touch Menu 🔛 > More > Help.

GOOGLE MAPS NAVIGATION

Navigation is an Internet-connected GPS navigation system with voice guidance.

Find it: 🔳 > 🛕 Navigation

Follow the prompts to speak or type your destination. For more, go to www.google.com/mobile/navigation.

GOOGLE LATITUDE™

JOIN LATITUDE

See where your friends and family are on Google Maps™. Plan to meet up, check that your parents got home safely, or just stay in touch.

Don't worry, your location is not shared unless you agree to it. You need to join Google Latitude™, and then invite your friends to view your location or accept their invitations. When using Google Maps (in any mode except in Street View), touch Menu 📆 > Latitude or touch 🔳 > ② Latitude. Read the privacy policy and, if you agree with it, choose to continue.

ADD & REMOVE FRIENDS

Find it: 🔳 > 🚇 Latitude

To add friends:

1 Touch Menu 🔠 > Add friends.

2 Touch Select from Contacts or Add via email address, then touch a contact and Add friends.

If your friends already use Latitude, they'll receive a notification. If they have not yet joined Latitude, they'll receive an invitation to join Latitude with their Google™ account.

To remove friends:

- 1 Touch a friend in your list.
- 2 Touch X.

SHARE LOCATION

When you receive a request to share location details you can choose to:

- Accept and share back: see your friend's location, and your friend can see yours.
- Accept, but hide my location: see your friend's location, but your friend can't see yours.
- Don't accept: location information is not shared between you and your friend.

HIDE YOUR LOCATION

To hide your location from a friend, touch your contact name, then touch **Edit privacy settings** > **Do not update your location**.

TURN OFF LATITUDE

Touch Menu 📆 > Settings > Sign out off Latitude.



YOUTUBE™

go and create your own classic

Note: This feature is not available in all areas. Check with your service provider.

QUICK START: YOUTUBE

Post that great video you've taken and see how many hits you get.

Find it: 🔳 > 🙇 YouTube



YouTube user-generated content website lets you share videos with YouTube users everywhere. You don't need a YouTube account to browse and view videos.

Note: If you don't have a YouTube account, visit http://www.youtube.com to find out more. To create an account or sign in, go to "YOUR ACCOUNT" on page 29.

WATCH VIDEOS

See popular video categories, like Most viewed, Most discussed, and Most recent. Touch a category, then touch the video to start playing it. To see more video categories, touch Menu 📳 > Browse.

SEARCH FOR VIDEOS

Find it: Menu 😬 > Search

Enter text, then touch Search Q.

SHARE VIDEOS

Find it: Menu 🔠 > Share

Send someone a link to a video that you are watching.

YOUR ACCOUNT

LOG IN OR CREATE ACCOUNT

Find it: Menu 🔠 > My Channel

1 To create your YouTube™ account, touch "Don't have a YouTube account? Touch here to create one".

If you already have a YouTube account, enter your user name and password, and touch **Sign in**.

2 For a new account, enter a user name, and complete the fields, then touch I accept.

UPLOAD VIDEOS

Find it: Menu 🔡 > Upload

- 1 Touch the video you want to upload. You can change the video title, description, set the access, and add tags.
- 2 Touch Upload

APPS & UPDATES

get the app you want

ANDROID MARKET™

Note: You'll need to set up a Gmail™ account (see "GMAIL™" on page 21) in order to buy and download apps from the Android Market.

Find it: <a> > <a> Market

Get all the fun games and cool apps you want! Android Market provides you with access to software developers everywhere, so you can find the app you want. If you need help or have questions about Android Market, touch Menu 🔠 > Help.

BROWSE & INSTALL APPS

Tip: Choose your apps and updates carefully, from trusted sites like Market, as some may impact your phone's performance—see "CHOOSE CAREFULLY" on page 30.

Note: When installing an app, make sure you read the alerts that tell you what information the app will access. If you don't want the app to have access to this information, cancel the installation.

CHOOSE CAREFULLY

Apps are great. There's something for everyone. Play, communicate, work, or have fun. But remember, choose your apps carefully. Here are a few tips:

- To help prevent spyware, phishing, or viruses from affecting your phone or privacy, use apps from trusted sites, like i Market.
- In Market, check the apps' ratings and comments before installing.
- If you doubt the safety of an app, don't install it.
- Like all apps, downloaded apps will use up memory, data, battery, and processing power—some more than others. After installing an app, if you're not happy with how much memory, data, battery or processing power it's using, uninstall it. You can always install it again later.
- Just like web browsing, you may want to monitor childrens' access to apps to help prevent exposure to inappropriate content.
- Certain apps may not provide completely accurate information. Take care, especially when it comes to personal health.

MANAGE & RESTORE APPS

To manage your apps, from the home screen touch Menu 🔛 > Settings > Manage Apps.

Touch the app to open the details screen—from here you can review, uninstall, and more.

To reinstall any downloaded items, from the home screen touch **Market** > **My apps**. All previously installed apps are listed and available for download.

UPDATE YOUR PHONE

Stay up to date with the latest software for your phone. You can check, download, and install updates using your phone or your computer:

Using your phone:

You may get an automatic notification of an available update on your phone. Follow the instructions to download and install.

To manually check for updates, touch Menu 📳 > Settings > About phone > System updates.

Your phone downloads any updates over your mobile network. Remember, these updates can be quite large (25MB or more) and may not be available in all countries. If you don't have an unlimited data plan, or mobile network updates are not available in your country, you can update using a computer.

Using your computer:

On your computer, go to www.motorola.com/pro+ and check the "Software" link. If an update is available, simply follow the installation instructions.

BLUETOOTH™ WIRELESS

lose the wires and go wireless

QUICK START: BLUETOOTH WIRELESS

Find it: From the home screen, touch Menu 📆 > Settings > Wireless & networks > Bluetooth settings



TURN BLUETOOTH POWER ON OR OFF

Find it: From the home screen, touch Menu 🔡 > Settings > Wireless & networks > Bluetooth

Note: Your phone's Bluetooth features and Bluetooth Class 1 power levels are not allowed for outdoor

operation in France. To avoid unlawful interference with radio signals, do not use the Bluetooth features in France unless you are indoors.

CONNECT NEW DEVICES

Note: This feature requires an optional accessory.

To connect with a new device, you need to pair with it. You only need to do this once for each device—to connect again, just turn on the device.

- 1 Make sure the device you are pairing with is in discoverable mode.
 - **Note:** Refer to the guide that came with the device for details.
- 2 From the home screen, touch Menu S > Settings > Wireless & networks > Bluetooth settings.
- **3** Touch **Bluetooth** to turn on and scan. If Bluetooth power is already on, touch **Scan for devices**.
- 4 Touch a device to connect.
- 5 If necessary, touch OK, or enter the device passkey (like 0000) to connect to the device. When the device is connected, the Bluetooth indicator (3) appears in the status bar.

Note: Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.

RECONNECT DEVICES

To automatically reconnect your phone with a paired device, simply turn on the device.

To manually reconnect your phone with a paired device, touch the device name in the **Bluetooth devices** list.

DISCONNECT DEVICES

To automatically disconnect your phone from a paired device, simply turn off the device.

To manually disconnect your phone from a paired device, touch the device name in the devices list, then touch Menu (B) > **Disconnect**.

EDIT PROPERTIES

From the home screen, touch Menu 🔠 > Settings > Wireless & networks > Bluetooth settings > Device name. Enter a name and touch OK.