

To...

Control whether some apps **rotate** the screen when you rotate your phone

Touch Menu  > **Settings** > **Display** > **Auto-rotate screen**.

Turn on or off **animations** that make your menus look smoother

Touch Menu  > **Settings** > **Display** > **Animation**.


Delete a shortcut or widget

Touch and hold the shortcut or widget until you feel a vibration, then drag it to the trash can.

Calibrate the **sensors** used by some games or navigation apps

Touch Menu  > **Settings** > **Display** > **G-Sensor Calibration** (movement) or **E-Compass Calibration** (direction).

LANGUAGE & REGION

To set your menu language and region, touch Menu  > **Settings** > **Language & keyboard** > **Select language**


CALLS

it's good to talk

Dial numbers, see recent calls, combine calls, or set up forwarding, restrictions, and more.

QUICK START: CALLS

From the home screen, touch  **Phone**.



Call.


Hang up.







Start a conference call.

Use a connected Bluetooth™ device.



Open a list, then touch an entry to call.

Send a text message.




- To **make** a call, touch  **Phone**, enter a number, then touch .
- To **answer** a call, open the flip or drag  to the right.
- **During** a call, touch Home  or Back  to hide the active call display (to reopen it, touch  **Phone**).


Note: Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.

- To use the **speakerphone** during a call, touch **Speaker**.
- To **enter numbers** during a call, touch **Dial Pad**.
- To **mute** or **unmute** a call, touch **Mute**.
- To **end** a call, close the flip or touch .
- To **ignore** an incoming call, drag  to the left.

Tip: For quick access to contacts, see “**FAVORITES**” on page 20.

RECENT CALLS

To show recent calls, touch  **Phone** > **Call log**.

- To call, text, open, or save an entry, touch and hold it.
- To clear the list, touch Menu  > **Clear call log**.

CONFERENCE CALLS


To start a conference call, call the first number. After they answer, touch **Add call** and call the next number.

When the next number answers, touch **Merge calls**. To remove individual callers, touch **Manage**.

CALL WAITING


If you are on a call and a new call arrives:

- With call waiting on, touch **Answer** to answer the new call and put the old call on hold. Then, touch **Swap** to switch between calls, or **Merge calls** to combine them.
- With call waiting off, the new call goes straight to your voicemail.

To turn on call waiting, touch Menu  > **Settings** > **Call settings** > **Additional settings** > **Call waiting**.

EMERGENCY CALLS

Note: Your service provider programs one or more emergency phone numbers that you can call under any circumstances, even when your phone is locked. Emergency numbers vary by country. Your pre-programmed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

- 1 Open the phone, then touch  **Phone** (if your phone is locked, touch **Emergency Call**).
- 2 Enter the emergency number.
- 3 Touch **Call** to call the emergency number.

Note: Your phone can use location based services (GPS and AGPS) to help emergency services find you. See “GPS & AGPS” in your legal and safety information.

COOL DOWN

In very limited circumstances, such as where your phone has been exposed to extreme heat, you may see “Cool Down” messages. To avoid possible damage to your battery and phone, you should follow these instructions until the phone is within its recommended temperature range. When your phone is in “Cool Down” mode, only emergency calls can be made.

Dec.29th, 2011


CONTACTS

contacts like you've never had before

Keep each friend's email, phone number, and even address all in your **Contacts** for quick access.


QUICK START: CONTACTS


From the home screen, touch  **Phone** > **Contacts**




Switch to the dialer, recent calls, or favorites.



Drag or flick to scroll.









Touch  to search, create, and more.


- To **create** a contact, touch  **Phone** > **Contacts** > Menu  > **New contact**, choose where you want to

store the contact, then enter details (to close the display keyboard, touch Back ).

Contacts shows the contacts from your Google™ account, which you can open from any computer at contacts.google.com (or open your contacts within mail.google.com). To stop synchronizing with your account, touch  **Phone** > **Contacts** > Menu  > **Accounts**, touch your Google account, then uncheck **Sync Contacts**.

- To **call**, **text**, or **email** a contact, touch  **Phone** > **Contacts**, touch the contact, then touch  (call),  (text), or  (email).
- To **edit** or **delete** a contact, touch  **Phone** > **Contacts**, touch the contact, then touch Menu .

FAVORITES



For quick access to a favorite contact, open the contact, then touch the star next to their name. To show your favorites, touch  **Phone** and touch **Favorites** at the top.

To add a shortcut to your favorites, touch and hold a blank spot on your home screen, then touch **Folders** > **Starred contacts**. You can also add a shortcut for an individual contact: Touch and hold a blank spot on your home screen, then choose **Shortcuts** > **Contacts**.

STORAGE & TRANSFER

When you create a new contact, your phone asks if you want to store it in your Google™ account, phone memory, or SIM card. Contacts in all three places appear in your **Contacts** list, but if you change phones:

- Contacts in your Google™ account can download when you log into your Google account on a new Android™ device. You can open these contacts from any computer at contacts.google.com.
- Contacts on your SIM card can load to a new device when you insert your SIM card.
- Contacts in your phone memory stay in your old phone, unless you export them.


To import or export contacts between your phone memory and a SIM or memory card, touch  **Phone** > **Contacts**, then touch Menu  > **Import/Export**.


MESSAGING

sometimes it's best to text or email...

Send and receive text with photos or other attachments, in quick text messages or full emails.


QUICK START: TEXT MESSAGING

From the home screen, touch  **Messaging**.






Drag or flick to scroll.





Touch  to change settings and more.

Tip: To see more messages, flick or drag up.



- To **create** a text message, touch  **Messaging** > **New message**. For options like attaching files, touch Menu .

- To **open** text messages, touch  **Messaging**, then touch the sender's name.

When you see  in the status bar at the top of your screen, flick down the status bar and touch the new message to open it.

- To **respond** to a text message, just open it and enter your response in the text box at the bottom.
- To **forward**, **copy**, and more, touch  **Messaging**, touch the sender's name, then touch and hold the message.

ATTACHMENTS

To send a file in a text message, touch  **Messaging** > **New message**, then touch Menu  > **Attach**.






When you open a message with an attachment, touch **Download** to download it. Touch the downloaded attachment to open it, then touch it again to save it, share it, and more.




Tip: To send and receive large attachments faster, use "**WI-FI NETWORKS**" on page 47.


EMAIL

- To **set up Google** or **Corporate** (Microsoft™ Exchange server) accounts, touch Menu  > **Settings** >


Accounts & sync > Add account. For details, contact the account provider.


To set up standard email accounts (not Gmail™ or Microsoft™ Exchange), touch  >  **Email** and follow the wizard. To add more standard accounts, open  **Email** and touch Menu  > **Accounts** > Menu  > **Add account**. For details, contact the account provider.

- To **open** email, touch  >  **Email** or  **Gmail**. Touch a message to open it.



Tip: Touch Menu  for options like **Refresh** or **Search**.


- To **create** an email, touch  >  **Email** or  **Gmail**, then touch Menu  > **Compose**.

Tip: Touch Menu  for options, like **Attach** or **Add Cc/Bcc**.

Gmail synchronizes with your Google™ account mail, which you can open from any computer at mail.google.com. To stop synchronizing with your account, touch Menu  > **Settings** > **Accounts & sync**, touch your Google account, then uncheck **Sync Gmail**.

VOICEMAIL

When you have a new voicemail,  shows in the status bar at the top of your screen. To hear voicemails, touch  **Phone** then touch and hold **1**.

If you need to change your voicemail number, in the home screen touch Menu  > **Settings** > **Call settings** > **Voicemail settings**. For your voicemail number or other details, contact your service provider.



TEXT ENTRY

keys when you need them


When you enter text, like in a message or search, you have keyboard options.

QUICK START: TEXT ENTRY

To **change the keyboard**, touch and hold a blank spot in a text box. A menu opens, where you can choose **Input method** > **Multi-touch keyboard** or **Swype**.

Note: **Swype** is not available in all regions. Your keyboard might change depending on what you're entering.

Swype lets you drag your finger over the letters of a word, in one continuous motion.



To enter a word, just trace a path through the letters.
To capitalize, go above the keypad.
For double letters, circle the letter.


- To **move the cursor**, touch and hold a word you entered. This opens a magnifier where you can drag the cursor.

- To **copy and paste**, double-tap a word to highlight it (if needed, drag the ends of the highlight). Then touch and hold a blank spot for the copy and paste menu.
- To add a word to **your dictionary**, double-tap the word to highlight it. Then touch and hold a blank spot to open the menu where you can add the word.
- To enter the small **number or symbol** at the top of a key, touch and hold the key.

To enter several numbers or symbols, touch **SYM**.

- If Swype doesn't know a word, touch individual letters to enter it. Swype remembers, so next time you can just drag over the letters.

Multi-touch keyboard lets you enter letters by touching them one at a time.





Touch and hold an empty spot to open a menu.

Symbols/Numbers

TEXT ENTRY DICTIONARY

Your phone's dictionary stores special words or names to recognize when you enter them.

To open your dictionary, from the home screen touch Menu  > **Settings** > **Language & keyboard** > **User dictionary**.

- To **add** a word, touch Menu  > **Add**.
- To **edit** or **delete** a word, touch and hold it.

Dec.29th, 2011