- To copy and paste, double-tap a word to highlight it (if needed, drag the ends of the highlight). Then touch and hold a blank spot for the copy and paste menu.
- To add a word to your dictionary, double-tap the word to highlight it. Then touch and hold a blank spot to open the menu where you can add the word.
- To enter the small **number or symbol** at the top of a key, touch and hold the key.

To enter several numbers or symbols, touch SYM.

If Swype doesn't know a word, touch individual letters to enter it. Swype remembers, so next time you can just drag over the letters.

Multi-touch keyboard lets you enter letters by touching them one at a time.



Touch and hold an empty spot to open a

Symbols/Numbers

TEXT ENTRY DICTIONARY

Your phone's dictionary stores special words or names to recognize when you enter them.

To open your dictionary, from the home screen touch Menu > Settings > Language & keyboard > User dictionary.

- To add a word, touch Menu > Add.
- To edit or delete a word, touch and hold it.


SCHEDULE

helping you stay in control

Your **Calendar** events can synchronize with your Google[™] account, and the **Clock** can wake you up!

QUICK START: SCHEDULE

From the home screen, touch \bigcirc > 31 Calendar.



Calendar synchronizes with your Google account calendar, which you can open from any computer at

calendar.google.com (or open your calendar within mail.google.com). To stop synchronizing with your account, touch Menu Settings > Accounts & sync, touch your Google account, then uncheck Sync Calendar.

 To edit or delete an event, touch 31 Calendar, touch the event to open it, then touch Menu > Edit event or Delete event.

ALARM CLOCK

TRUCTED :: MO

To set an alarm (like to wake up), touch \bigcirc > \bigvee Clock, then touch the \bigcirc alarm.

- To turn an alarm on or off, touch on next to it.
- To add an alarm, touch Add alarm, then enter alarm details.
- To change an alarm, touch the time.
- To set a snooze period, in the Alarm Clock list touch Menu > Settings > Snooze duration.

When an alarm sounds, touch **Dismiss** to turn it off or **Snooze** to delay it. To cancel a snoozed alarm, drag down the status bar bar and touch the alarm name.

DATE & TIME

TRACTED ::

To set the date, time, time zone, and formats, touch Menu > Settings > Date & time.

WEB

surf the web with your phone

Open **Browser** or just touch Search Q to find a page, then bookmark it, send it, or just explore.

QUICK START: WEB

From the home screen, touch > Browser



To enter a website address in the browser or you home screen, just touch Search Q ANOTOROTOM :: MOTOROLA COM

- To zoom in or out, pinch two fingers together or apart.
- To send the website address in a message, touch Menu > More > Share page.



Note: Your phone automatically uses your mobile phone network to connect to the web. Your service provider may charge to surf the web or download data. If you can't connect, contact your service provider.

Tip: You can connect to the web with "wi-FI NETWORKS" on page 25.

DOWNLOADS

To download files in your browser, touch a file link or touch and hold a picture to choose Save image.

To show the files you downloaded, touch <a> >

Downloads. Touch and hold an item to open it, see details, or remove it from the list.

You can download "APPS" on page 6.

LOCATION


where you are, and where you're going

Open **Maps** or just touch Search \boxed{Q} to find an address, then get directions, check in, or save the location.

TRUCTED :: Mr

QUICK START: LOCATION

From the home screen, touch \bigcirc > \bigcirc Maps.



Google MapsTM offers powerful, user-friendly mapping technology and local business information—including business locations, contact information, and driving directions.

 To find an address, enter it in the search box at the top. The map moves to show the address. **Tip:** You can touch and hold a spot on the map to show the nearest address.

- To find stores, restaurants, and other places near you, touch at the top.
- To get directions, find an address on the map, touch it, then touch .
- To save an address for later, touch it, then touch the star by its name to add it to your Starred Places.
- For help, touch Menu > More > Help.

GOOGLE MAPS™ NAVIGATION

Google Maps Navigation is an Internet-connected GPS navigation system with voice guidance.

To open navigation, touch \bigcirc > \bigwedge Navigation. Follow the prompts to speak or type your destination.

For more, go to www.google.com/mobile/navigation.

GOOGLE LATITUDE™

Google LatitudeTM lets you see where your friends and family are on Google MapsTM. Plan to meet up, check that they got home safely, or just stay in touch. Don't worry, your location is not shared unless you agree to it. After you join Google Latitude, you can invite your friends to view your location, or accept their invitations.

Touch **O** > **Maps** and then:

- To join Google Latitude, touch Menu => Join Latitude. Read the privacy policy and, if you agree with it, choose to continue.
- To add friends, touch Menu > Latitude > Menu > Add friends.

Touch Select from Contacts or Add via email address, then touch a contact and Add friends. Your friend will receive an email notice.

- To remove friends, touch Menu > Latitude to show your friends list. Touch a name, then touch Remove.
- To share your location when you receive a request, you can choose Accept and share back (show your location and see theirs), Accept, but hide my location (hide your location, but see theirs), or Don't accept (hide both locations).
- To hide your location, touch Menu => Latitude to show your friends list. Touch your contact name, then touch Menu => Settings > Do not detect your location.
- To sign out, touch Menu > Latitude to show your friends list. Touch Menu > Settings > Sign out of Latitude.

PHOTOS & VIDEOS

see it, capture it, share it!

Capture photos and videos to send them to friends or save them for later.

QUICK START: PHOTOS & VIDEOS

From any screen, press the Camera Key on the right side of the phone to open the camera.



- To take a photo, open the camera, then press the Camera Key.
- To record a video, open the camera, touch the screen, then touch Camera/Video to switch to the camcorder. Press the Camera Key to start and stop recording.
- To open photos and videos, touch > My gallery, then touch Menu for options like Share.