
CONTACTS

contacts like you've never had before

Keep each friend's email, phone number, and even address all in your **Contacts** for quick access.

QUICK START: CONTACTS

From the home screen, touch !! Phone > Contacts



To create a contact, touch !!! Phone > Contacts >
 Menu = > New contact, choose where you want to

store the contact, then enter details (to close the display keyboard, touch Back 🕥).

Contacts shows the contacts from your Google™ account, which you can open from any computer at contacts google.com (or open your contacts within mail.google.com). To stop synchronizing with your account, touch ¶ Phone > Contacts > Menu => Accounts, touch your Google account, then uncheck Sync Contacts.

- To call, text, or email a contact, touch ! Phone > Contacts, touch the contact, then touch (call), (text), or (email).
 - To edit or delete a contact, touch Phone
 Contacts, touch the contact, then touch Menu =

FAVORITES

For quick access to a favorite contact, open the contact, then touch the star next to their name. To show your favorites, touch **Q Phone** and touch **Favorites** at the top.

To add a shortcut to your favorites, touch and hold a blank spot on your home screen, then touch **Folders** > **Starred contacts**. You can also add a shortcut for an individual contact: Touch and hold a blank spot on your home screen, then choose **Shortcuts** > **Contact**.

When you create a new contact, your phone asks if you want to store it in your Google™ account, phone memory, or SIM card. Contacts in all three places appear in your **Contacts** list, but if you change phones:

- Contacts in your Google™ account can download when you log into your Google account on a new Android™ device. You can open these contacts from any computer at <u>contacts.google.com</u>.
- Contacts on your SIM card can load to a new device when you insert your SIM card.
- Contacts in your phone memory stay in your old phone, unless you export them.

To import or export contacts between your phone memory and a SIM or memory card, touch Phone > Contacts, then touch Menu > Import/Export.


MESSAGING

sometimes it's best to text or email...

Send and receive text with photos or other attachments, in quick text messages or full emails.

QUICK START: TEXT MESSAGING

From the home screen, touch Messaging.



Tip: To see more messages, flick or drag up.

To create a text message, touch Messaging >
 New message. For options like attaching files, touch
 Menu =.

- To open text messages, touch Messaging, then touch the sender's name.
 - When you see in the status bar at the top of your screen, flick down the status bar and touch the new message to open it.
- To respond to a text message, just open it and enter your response in the text box at the bottom.
- To forward, copy, and more, touch Messaging, touch the sender's name, then touch and hold the message.

ATTACHMENTS

To send a file in a text message, touch **Messaging** > **New message**, then touch Menu **Message** > **Attach**.

When you open a message with an attachment, touch **Download** to download it. Touch the downloaded attachment to open it, then touch it again to save it, share it, and more.

Tip: To send and receive large attachments faster, use "**wi-Fi NETWORKS**" on page 50.

EMAIL

 To set up Google or Corporate (MicrosoftTM Exchange server) accounts, touch Menu = > **Settings** > **Accounts & sync** > **Add account**. For details, contact the account provider.

To open email, touch S > @ Email or M Gmail.
 Touch a message to open it.

Tip: Touch Menu for options like **Refresh** or **Search**.

To create an email, touch > Email or Gmail then touch Menu > Compose.

Tip: Touch Menu for options, like Attach or Add Cc/Bcc.

Gmail synchronizes with your Google™ account mail, which you can open from any computer at mail.google.com. To stop synchronizing with your account, touch Menu => Settings > Accounts & sync, touch your Google account, then uncheck Sync Gmail.

VOICEMAIL

When you have a new voicemail, ∞ shows in the status bar at the top of your screen. To hear voicemails, touch \square Dialer then touch and hold 1.

If you need to change your voicemail number, in the home screen touch Menu => Settings > Call settings > Voicemail service. For your voicemail number or other details, contact your service provider.



TEXT ENTRY

keys when you need them

When you enter text, like in a message or search, you have keyboard options.

QUICK START: TEXT ENTRY

To change the keyboard, touch and hold a blank spot in a text box. A menu opens, where you can choose **Input** Method > Multi-touch keyboard or Swype.

Note: Swype is not available in all regions. Your keyboard might change depending on what you're entering.

Swype lets you drag your finger over the letters of a word, in one continuous motion.



To enter a word, just trace a path through the letters. To capitalize, go above the keypad. For double letters, circle the letter.

 To move the cursor, touch and hold a word you entered. This opens a magnifier where you can drag the cursor.

- To copy and paste, double-tap a word to highlight it (if needed, drag the ends of the highlight). Then touch and hold a blank spot for the copy and paste menu.
- To add a word to your dictionary, double-tap the word to highlight it. Then touch and hold a blank spot to open the menu where you can add the word.
- To enter the small number or symbol at the top of a key, touch and hold the key.

To enter several numbers or symbols, touch SYM.

 If Swype doesn't know a word, touch individual letters to enter it. Swype remembers, so next time you can just drag over the letters.

Multi-touch keyboard lets you enter letters by touching them one at a time.



Symbols/Numbers

TEXT ENTRY DICTIONARY

Your phone's dictionary stores special words or names to recognize when you enter them.

To open your dictionary, from the home screen touch Menu => Settings > Language & keyboard > User dictionary.

- To add a word, touch Menu = > Add.
- · To edit or delete a word, touch and hold it.




SCHEDULE

helping you stay in control

Your **Calendar** events can synchronize with your $Google^{TM}$ account, and the **Clock** can wake you up!

QUICK START: SCHEDULE

From the home screen, touch o > 31 Calendar



Calendar synchronizes with your Google account calendar, which you can open from any computer at <u>calendar.google.com</u> (or open your calendar within

mail.google.com). To stop synchronizing with your account, touch Menu S > Settings > Accounts & sync, touch your Google account, then uncheck Sync Calendar.

To edit or delete an event, touch > 31 Calendar, touch the event to open it, then touch Menu > Edit event or Delete event.

ALARM CLOCK

- To turn an alarm on or off, touch 🐧 next to it.
- To add an alarm, touch Add alarm, then enter alarm details.
- To change an alarm, touch the time.
- To set a snooze period, in the Alarm Clock list touch Menu = > Settings > Snooze duration.

When an alarm sounds, touch **Dismiss** to turn it off or **Snooze** to delay it. To cancel a snoozed alarm, drag down the status bar bar and touch the alarm name.

DATE & TIME

To set the date, time, time zone, and formats, touch Menu > Settings > Date & time.

WEB

surf the web with your phone

Open **Browser** or just touch Search \bigcirc to find a page, then bookmark it, send it, or just explore.

QUICK START: WEB

From the home screen, touch 🔯 > 🔃 Browser



 To enter a website address in the browser or your home screen, just touch Search \(\overline{\Q} \).

- To zoom in or out, pinch two fingers together or apart.
- To send the website address in a message, touch Menu > More > Share page.



Note: Your phone automatically uses your mobile phone network to connect to the web. Your service provider may charge to surf the web or download data. If you can't connect, contact your service provider.

Tip: You can connect to the web with "**wi-FINETWORKS**" on page 50.

DOWNLOADS

To download files in your browser, touch a file link or touch and hold a picture to choose **Save image**.

To show the files you downloaded, touch \bigcirc >

♣ Downloads. Touch and hold an item to open it, see details, or remove it from the list.

You can download "APPS" on page 12.


LOCATION

where you are, and where you're going

Open Maps or just touch Search (Q) to find an address, then get directions, check in, or save the location.

OUICK START: LOCATION

From the home screen, touch > Maps.



Google Maps™ offers powerful, user-friendly mapping technology and local business information—including business locations, contact information, and driving directions.

 To find an addres, enter it in the search box at the top. The map moves to show the address.

Tip: You can touch and hold a spot on the map to show the nearest address.

- To get directions, find an address on the map, touch it, then touch .
- To save an address for later, touch it, then touch the star by its name to add it to your Starred Places.
- For help, touch Menu > More > Help.

GOOGLE MAPS™ NAVIGATION

Google Maps Navigation is an Internet-connected GPS navigation system with voice guidance.

To open navigation, touch **O** > **A** Navigation. Follow the prompts to speak or type your destination.

For more, go to www.google.com/mobile/navigation.

GOOGLE LATITUDE™

Google Latitude[™] lets you see where your friends and family are on Google Maps[™]. Plan to meet up, check that they got home safely, or just stay in touch. Don't worry, your location is not shared unless you agree to it. After you join Google Latitude, you can invite your friends to view your location, or accept their invitations.

Touch **O** > **Maps** and then:

- To join Google Latitude, touch Menu > Join Latitude. Read the privacy policy and, if you agree with it, choose to continue.
- To add friends, touch Menu > Latitude > Menu > Add friends.
 - Touch **Select from Contacts** or **Add via email add ress**, then touch a contact and **Add friends**. Your friend will receive an email notice.
- To remove friends, touch Menu => Latitude to show your friends list. Touch a name, then touch Remove.
- To share your location when you receive a request, you can choose Accept and share back (show your location and see theirs), Accept, but hide my location (hide your location, but see theirs), or Don't accept (hide both locations).
- To hide your location, touch Menu > Latitude to show your friends list. Touch your contact name, then touch Menu > Settings > Do not detect your location.