

APPLICANT: MOTOROLA, INC.

FCC ID: IHDT56KV1

INSTRUCTION MANUAL

A preliminary draft copy of the Users Manual follows:

congratulations

Morrison brings all your conversations, friends, and favorite stuff into focus, so you spend less time managing your life and more time living it.

- **Everybody in.** Synchs all your friends' contact info the first time you pick it up, and continues updating your device, so you don't have to.
- **Cut to the chatter.** Streams any message, from anywhere, right to Morrison—no apps, no menus.
- **Social secretary.** Lets you do just about anything—upload, download, post—on Facebook, MySpace and Twitter.
- **Relax, already.** Backs it all up too.
- **Google too.** Download thousands of cool apps from Google—search (of course), map, chat, play and surf to your heart's content.

Caution: Before using your phone for the first time, please read "Legal & Safety" on page 49.

more information

You always have help. You can tap the **Help Center** in your app tray, or visit www.motorola.com/support.

about this guide

symbols in this guide



These features might not be available. For details, contact your service provider.




These features require an optional accessory.




your phone

the important keys & connectors



When you open or turn your phone, the screen adjusts for you.



contents


your phone	3
let's go	6
touchscreen & keys	10
home screen	13
app tray	18
social networking	19
calls	21
contacts	24
messaging	27
tips & tricks	29
personalize	30
photos	32
videos	33
music	35
Web	36
Google Maps™	39
YouTube™	41
apps for almost everything	43
Bluetooth™ wireless	45
Wi-Fi	48
Legal & Safety	49

let's go


let's get you up and running

assemble & charge

1 cover off



2 SIM in




3 battery in



4 microSD in (already installed)



5 cover on




6 charge up



Caution: Please see "Battery Use & Safety" on page 49.

turn it on & off

To turn on your phone, press  (on the right side).



To turn off your phone, press and hold , then tap **Power off** in the menu that opens.

register & import contacts


The first time you turn on Morrison and register, MOTOBLUR will sync your contacts—from your SIM card, email, and social network accounts—into one list. From then on, MOTOBLUR will keep your contacts updated. When somebody gets a new number or updates their status, you'll know it.

Note: MOTOBLUR registration is secure, and should only take a few minutes (depending on how many email or social networking accounts you want to add). For more, see “your MOTOBLUR account” on page 19.



- 1** The first time you turn on Morrison, select your language (tap **Next**), then read the Welcome (tap **Next**).
- 2** To create your MOTOBLUR account, choose **Register a new account** and enter the info.

If you already created a MOTOBLUR account, choose **Use an existing account** and enter your info.


- 3 After you register, you can add your **Facebook**, **MySpace**, **Twitter**, or other accounts. Your phone downloads your friends and contacts when you sign in.



Note: If you don't have social networking accounts, visit Facebook, MySpace, or Twitter Web sites to find out more. To add accounts anytime, see "add accounts" on page 20.

- 4 When you finish signing in, your phone shows your home screen. To import the contacts from your SIM card, tap  **Contacts**, then press  > **Settings** > **Import from SIM card**. Tap **OK** to confirm.

Wi-Fi connect

If you want to use a wireless computer network for even faster Internet access, press  > **Settings** > **Wireless controls** > **Wi-Fi settings**. Tap **Wi-Fi** to search for and connect to wireless networks. For more, see "Wi-Fi" on page 48.

cool content & more

Browse and download thousands of the coolest apps on the planet from Google, so you can search (of course),

map, chat and play to your heart's content. On top of that, you get a full HTML browser too, so you can surf in style.

Download new apps with “Android market” on page 43. Your phone comes with a microSD memory card installed—you can load it up with photos, videos, or music from your computer.

security

Everything you do on Morrison is backed-up on MOTOBLUR, so quit worrying. Even if you lose your device, MOTOBLUR can help you find it, lock it, or wipe it. And when you get your next MOTOBLUR product, your stored info makes it a snap to set up with just a username and password.


touchscreen & keys

a few essentials

touch tips

Try these actions to touch and move things in the touchscreen:

tap

To choose an icon or option, *tap* it. For example, from your home screen, you can tap  **Contacts**.



tap & hold

To open special options, *tap and hold* an icon or other item. For example, in the home screen, tap and hold a chip to show the options **Setup**, **Move**, and **Delete**.



drag

To move an icon or a list item, you can *drag* it. For example, in the home screen, tap and hold a chip to show its options, then tap **Move**. Drag the chip to a new spot, then tap **Done**.

flick


To quickly scroll through lists, or pull things up, down, left, or right, *flick* (drag quickly) across the touchscreen.

In the home screen, quickly flick the main panel left or right to open other panels.





Flick the icons from the bottom of the touchscreen upward to open the full menu.

Panel Map

When you flick panels left or right, this bar shows which one you're on.



sleep & wake up

To save your battery, prevent accidental taps, or when you want to wipe smudges off your touchscreen, put the touchscreen to sleep by pressing . To wake up the touchscreen, just press , , or , or open the phone.



adjust volume


Press the volume keys to change the ring volume (in the home screen), or the earpiece volume (during a call).




home screen

quick access to the things you need most

home screen quick start

The *home screen* gives you all your latest information in one place. It's what you see when you turn on the phone or press  from a menu. It's basically like this:



The screenshot shows an iPhone home screen with various widgets and icons. Blue callout boxes with lines pointing to specific elements are used to identify features:

- Status Indicators:** Points to the top status bar showing signal strength, Wi-Fi, and the time 1:22 AM.
- Your Online Status:** Points to the Facebook status update at the top.
- Notifications:** Points to the notification bar at the top of the widget area.
- Chips:** Points to the 'Messages' widget.
- Shortcuts:** Points to the dock at the bottom of the screen.

Status Indicators

Your Online Status

Tap to change your status.

Notifications

Flick this bar down to see details about new notifications.

Chips

Tap to open, or tap & hold to move or set up.

Shortcuts

Tap to open. Flick up to open the app tray.


MOTOBLUR integrates all your communications—from Gmail to Facebook, Twitter to MySpace—pulling together the threads you’re following, the people you’re friending and every story, link or video you’re sharing into a single stream that you view any way you choose.

Tip: Customize your home screen in “personalize” on page 30.

chips


In your home screen, *chips* show you news and message updates.

Tip: Flick the home screen left or right to open other *panels* (pages of chips).


To open a chip, tap it. To add or move chips, press  > **Manage**. There are chips for **Happenings**, **Messages**, **Weather**, and **News**.

happenings chip

The **Happenings** chip shows the latest update from your social networks. Tap the chip to open a list of updates. Tap an update for details, or flick it left to see other updates.



Tap the Happenings chip, then tap an update to see details.




set up or delete the happenings chip


Tap and hold this chip, then tap **Setup** or **Delete**. To add social networks in **Setup**, see “add accounts” on page 20.

messages chip

The **Messages** chip shows your latest email, message, or IM. Tap the chip to open the message, then flick left to open older messages.



Tap the Messages chip, then flick messages left.



set up or delete the messages chip

Tap and hold this chip, then tap **Setup** or **Delete**. To add email accounts in **Setup**, see “add accounts” on page 20.

news chips

News chips show you the latest unread headline, and can have different names (like **Sports** or **Entertainment**). Tap a chip for the full story.



set up or delete news chips

Tap and hold a chip, then tap **Setup** or **Delete**. In **Setup**, you can change the chip's name or add more RSS feeds for this chip. When you open the news chip, flick left to see other headlines all the chip's feeds.

weather chips

Tap a weather chip for the daily forecast. Then, tap the chip again for the detailed forecast.




set up or delete weather chips

Tap and hold a chip, then tap **Setup** or **Delete**. In **Setup**, you can change the location or add more locations for this chip. When you open the weather chip, flick left to see other locations you added.

status & notifications

At the top of the screen, icons tell you about messages and phone status. For details, flick down the icon bar.





- | | | | |
|--|---------------------------|--|---------------------------|
| | E-mail | | Ring is silent |
| | Text or picture message | | Ring is on vibrate |
| | Message error | | Phone muted |
| | IM | | GPS on/working |
| | Voicemail | | Uploading/downloading |
| | Calendar event set | | Content downloaded |
| | Alarm set | | GSM/roaming/no signal |
| | Song playing | | GPRS connected/active |
| | Data syncing | | EDGE connected/active |
| | microSD card full | | 3G connected/active |
| | Undisplayed notifications | | Wi-Fi connected/available |
| | Call in progress | | Battery charge |
| | Call missed | | Battery charging |
| | Call on hold | | Wireless off |
| | Call forward on | | Bluetooth on/connected |
| | Speakerphone on | | SIM card missing |
| | | | Network signal strength |

Tip: To see today's date, tap and hold the status bar.

app tray

app tray quick start

The app tray shows you all of your applications. To open it from the home screen, press . To close it, press  again.

Tip: To find an app in the app tray, you can open your phone and type the app name.

social networking

my life, your life

your MOTOBLUR account


When you first turned on your phone, you registered for a MOTOBLUR account that manages your messages, contacts, and more (“register & import contacts” on page 7). You can log into this account from a computer upload contacts, manage the account, get help, or even locate your phone: ws-cloud1-qa1.blurdev.com/blur-services-1.0/web/

view accounts & update status

Morrison lets you do just about anything on Facebook, MySpace, and Twitter right from the full touchscreen—post photos as soon as you snap them, or blast your status across all your social networks at once. MOTOBLUR makes the connections, whether you’re posting, surfing, or squawking.

After you add a social networking account, you’ll see your status in your home screen, along with your friends’ updates (“happenings chip” on page 15).

To update your status, just tap it and enter text.

To stop seeing your status, press  > **Hide status**.

add accounts

Find it:  > **Accounts** >  > **New Account**

Tip: After you sign in, you'll have the friends and contacts from the account in your phone's **Contacts** list.

Note: If you don't have **Facebook**, **MySpace**, or other accounts, visit their Web sites to find out more.

remove accounts

Find it:  > **Accounts**


Tap an account, then tap **Delete**.

calls


it's good to talk

calls quick start
dialing options

Find it:  Dialer



in-call options



Call Timer

Mute


Tap to mute or unmute the call.

Dialer


Tap to dial a second call.

Speakerphone

Tap to turn the speakerphone on or off.

During a call, press  to choose **Hold**, **New Call**, **Use Bluetooth**, or to wake up the touchscreen if it's dark.

make & answer calls


To make a call, tap  **Dialer**, enter a number, then tap **Dial**.

To answer a call, tap **Answer**.

end calls

Tap **End call**.


Tip: If you close the call display during a call, flick down the status bar and tap **Current call** to reopen it.



emergency calls

Your service provider programs one or more emergency phone numbers, such as 911 or 112, that you can call under any circumstances, even when your phone is locked or the SIM card is not inserted.

Note: Check with your service provider, as emergency numbers vary by country. Your phone may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues. Do not solely rely on your wireless phone for essential communications, such as medical emergencies.


- 1 Tap  (if your phone is locked, tap **Emergency Call**).
- 2 Enter the emergency number.
- 3 Tap **Dial** to call the emergency number.

contacts

contacts like you've never had before

contacts quick start

Find it:  Contacts



Create Contacts

Filters

Choose the list source (like All, Favorites, or Facebook).

Contacts List

Tap to view contact information. Tap & hold to edit, delete and more.

Views

Tap a list view, or flick the display right or left, to show:

History - recently used

A-Z - list without status

Status - list with status

Tip: To search the list, just type a name.

view contacts


With Morrison, you'll know what everybody's up to and when. Every time you pick up a call, check a message or look up a friend's contact info, sure, you'll see their name and number, but you'll see their social network status and smiling face, too.

Find it:  **Contacts**



- To filter the contacts by source (like **All**, **Favorites**, or **Facebook**) tap the filter name at the top.
- To change the list view, tap **History** (recently used), **A-Z** (list without status), or **Status** (list with status) at the bottom.
- To find a contact, just type the name.

call, text, or edit contacts

Find it:  **Contacts**


- To show **Call**, **Send text message**, **Email**, **View contact**, **Delete**, or other options, tap and hold the contact.
- To edit a contact, tap it, then press  > **Edit**.

create contacts

Find it:  **Contacts** >  > **Add Person**

Open your phone to type the name and details.

Tap **+** and **-** to open and close **Phone**, **Emails**, and other lists.




To see more details, flick up.

messaging

sometimes it's good 2 text, or IM, or email ...

messaging quick start



Find it:  Messaging > Universal Inbox



Check for Messages Now
Tap the refresh icon (circular arrow) to check for new messages.

Create Message
Tap the compose icon (envelope with pencil) to create a new message, and see a list of your drafts (indicated by the number).


Message Type
Icons on the right indicate the message types.


Message Status
Icons indicate a message:
 is unread
 has attachments


Tip: To see more messages, flick or drag up.

create messages

Find it:  Messaging > 



Choose a message account. Then, enter the recipient and message. In text messages and emails, press  for options like **Insert** or **Attach Files**.

Tip: To send text messages or emails to **Contacts**, tap , tap and hold the contact, then tap **Send text message** or **Email**.



set up messaging

Find it:  **Messaging** > 

- **Manage accounts** to change your user name or password (or server settings, for email).
- **Edit Universal accounts** to choose which accounts show their messages in the **Universal Inbox**.
- **Settings** to set the notification for each account type (along with other preferences, for email).

To add email or social networking accounts, tap **Manage accounts**, then press  > **New Account**. For account details, contact the account provider.

voicemail

When you have a new voicemail,  shows at the top of your screen. To hear the voicemail, tap  **Dialer**, then tap and hold **1**.

tips & tricks

a few handy hints

To...	
go to the home screen	Press .
see recently dialed numbers	Press > Dialer > Recent .
sleep/wake your phone	Sleep—press . Wake—press , , , or open your phone.
lock/unlock screen	Lock—press > Settings > Security & location > Screen lock . Unlock—press .
switch silent mode on/off	Slide silent mode switch up/down (“your phone” on page 3).
Google search	Press .


personalize

add your personal touch

make it your home

Change your home screen to show what you want. Show chips to keep in touch with friends, or get the latest news and weather. Its up to you!

choose your chips

Choose the chips you want to show. Press  > **Add Chips**, then select the chip you want. To remove a chip, tap and hold, then tap **Delete** > **Yes**.

Tip: To open more chips, see “browse panels” on page 31.

name your chips

To name a chip, tap and hold, then tap **Setup** and enter the **Chip name**.

move your chips

To move a chip, tap and hold, then tap **Move**. Drag the chip where you want it, then tap **Done**.