

MOTO[™] WX181

Getting Started Guide

congratulations

stylish Motorola WX181 phone.

Whether you're a talker, a texter, or just love listening to the radio on the move, the

We've crammed all the main features of your phone into this handy guide—you can even take the guide with you.

how to use your new WX181, visit www.motorola.com/support.

So, let's go.

Note: Your phone may not appear exactly as the images in this manual. However, all key locations, sequences, and functions are the same.

Congratulations on your purchase of the

WX181 does it all.

If you'd like even more information about

vour phone

answer calls.

Lanyard -Torch (on back of phone). Mini USB Connector **A** = (Soft keys

Charge or connect a headset. Performs 12:30 function shown above the key. end Kev ے Call Kev Press & hold

on/off. Press Navigation <ô to end calls. Key Scroll through lists & menus. • Center Kev

to turn phone

Select a highlighted

calls —

make & answer calls



Enter a number and press ■. When your phone rings or vibrates, press -.

end calls



Press 🖜

emergency calls

To call an emergency number, enter the emergency number and press Your service provider programs emergency phone numbers, (such as 112 or 911), that


when your phone is locked. Emergency numbers vary by country. Your phone's pre-programmed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or

vou can call under any circumstances, even

messages —

send messages





Tip: Press Options > Input mode to switch text entry modes. Press * to switch capitalization modes. Press # to enter a space. Press 0 to change language.

Press ♠.

Search and scroll to a contact. Press • to select a contact.

● Press • to send.

read messages

When you receive a message you will see 1 New message! on your screen. Press (> Read to open the message. You can reply to the message by pressing Options > Reply.

tips & tricks ——

ring style

To quickly switch your ring style, press and hold # from the home screen.

keypad lock

To quickly lock your keypad, press and hold * then **0k** from the home screen. Press and hold *... then 0k to unlock.

torch on

To quickly turn on your torch, press 5 from the home screen. Press Off to turn it off.

voicemail

Press and hold 1, then pres Yes. If your voicemail number is pre-set, you will connect

recent calls

To see your dialled and received calls, press from the home screen.

radio —

listen to the radio

headset is plugged in.

store favorite stations

press • to store it.

select a stored station.

Plug a mini-USB headset into your

To tune in a station, press 🗘 left or right.

To adjust volume, press O up or down.

To turn off the radio, press Options > Turn off.

When listening to a station, press Options

Press Options > Channel list to see your stored

stations. Press keys 1 through 30 to

> Save channel > Ok. Select a channel number and

Note: The FM radio works only when the

Tools Torch

Games

FM Radio

 Sent Drafts

Organizer

main menu

 Templates Stopwatch Settings Alarm Voicemail

 Calculator Converter

C Directory Mv shortcuts C2 Call register

General

Meeting

 Outdoor Indoor

Headset

 Call settings Call control

Inbox

CB SMS

Call memory

Mv numbers

Billing

· Create SMS

This is a standard main menu layout. Your phone's menu may

Silent

be a little different.


* Network Dependent

☼ Settings Display Clock

 Kevs Dictionary

More settings





6 charge up



turn it on & off

basics



Press and hold 🕝 for a few seconds to turn the phone on/off.

menu navigation



Press the center key • to open the Main Press the navigation key

•Ô• up, down, right or

left to highlight a menu



Press the center key • to select the highlighted option. Press **Options** to display

the options menu

contacts

save contacts

interference issues.

• Enter the number on the home screen and press Save.

2 Press < Empty> and enter the contact

3 Press ♠ > Done when you're finished. Press Yes to save.

call contacts

● Press • > Directory.

2 Scroll through the list to highlight the contact's number.

personalize — set your wallpaper

Change the wallpaper to one that makes you

Find it: (♠) > ☆ Settings > Display > Wallpaper set time & date

Set the time & date shown on your home

Find it: • > Settings > Clock > Time & date set ringtone and volume

Play it loud or keep it quiet, you choose. Find it: $\langle \hat{\bullet} \rangle > \bigcap$ Profiles

Choose from the pre-programed profiles, including, General, Meeting (vibrate), Outdoor, Indoor, Headset, and Silent. Press Options to edit a profile.

tools —

create shortcuts

Choose the features you want to access with a single key press from the home screen-really useful stuff:

Find it: (♠) > **|||** Tools > My shortcuts > Add > Functions > Keys

phone lock

Lock your phone to prevent others from

Find it: (Settings > More settings > Security > Activate phone code > enter code You will need to enter the code when you

handsfree

turn the phone on.

During a call, press Handsf. to use the speakerphone.

text entry ———

entry modes

SAbc

♦ Abc

123

To change modes when you are entering text, press Options > Input mode:


To enter symbols select Insert symbols.

odes		
	Smart (predictive text) predicts the word you want, with just one keypress per letter. For example, to enter Good, press 4663. If the prediction is not correct, press • • up or down to show other options.	
	Multitap lets you press a key one or more times to cycle through the letters and numbers of that key.	

Add numbers mode enters numbers

home screen —

The home screen displays when you turn on the phone. Status indicators can appear across the top of the home screen:



Note: Your phone's home screen may be different than the one shown.

accessories & more www.motorola.com



Safety, Regulatory & Legal

Battery Use & Safety

Important: Handle and store batteries properly to avoid injury or damage. Most battery issues arise from improper handling of batteries, and particularly from the continued use of damaged batteries.

- Don't disassemble, crush, puncture, shred, or otherwise attempt to change the form of your battery.
- . Don't let the phone or battery come in contact with water. Water can get into the phone's circuits, leading to corrosion. If the phone and/or battery get wet, have them checked by your service provider or contact the distributor, even if they appear to be working
- Don't allow the battery to touch metal objects. If metal objects. such as jewelry, stay in prolonged contact with the battery contact points, the battery could become very hot.
- Don't place your battery near a heat source. Excessive heat can damage the phone or the battery. High temperatures can cause the battery to swell, leak, or malfunction. Therefore:
- Do not dry a wet or damp battery with an appliance or heat source, such as a hair dryer or microwave oven.
- · Avoid leaving your phone in your car in high temperatures.

 Do avoid dropping the battery or phone. Dropping these items, especially on a hard surface, can potentially cause damage.*

 Do contact your service provider or the distributor if your phone or battery has been damaged from dropping or high

* Note: If the product guide expressly states that your phone is designed to resist damage from exposure to certain rugged conditions, such as water immersion, rain, dust, high and low temperatures, shock, or other conditions do **not** exceed the stated limits, and ensure the stated precautions are taken. Always make sure that the battery compartment is closed and secure to avoid direct exposure of the battery to any of these conditions.

Important: Use Motorola Original products for quality assurance and **safeguards.** To aid consumers in identifying authentic Motorola batteries. from non-original or counterfeit batteries (that may not have adequate safety protection). Motorola provides holograms on its batteries. Consumers should confirm that any battery they purchase has a "Motorola Original" hologram.

Motorola recommends you always use Motorola-branded batteries and chargers. Motorola mobile devices are designed to work with Motorola batteries. If you see a message on your display such as

Invalid Battery or Unable to Charge, take the following steps: Remove the battery and inspect it to confirm that it has a

"Motorola Original" hologram: If there is no hologram, the battery is not a Motorola battery;

If there is a hologram, replace the battery and retry charging it;

If the message remains, contact a distributor.

Important: Motorola's warranty does not cover damage to the phone caused hy non-Motorola batteries and/or chargers

Warning: Use of a non-Motorola battery or charger may present a risk of fire, explosion, leakage, or other hazard.

Proper and safe battery disposal and recycling: Proper battery disposal is not only important for safety, it benefits the environment. Consumers may recycle their used batteries in many retail or service provider locations. Additional information on proper disposal and recycling may be found on the

www.motorola.com/recycling

 www.rbrc.org/call2recycle/ (in English only) Disposal: Promptly dispose of used batteries in accordance with local regulations. Contact your local recycling center or national recycling organizations for more information on how to

Warning: Never dispose of batteries in a fire because they may explode.

Battery Charging

Notes for charging your phone's battery:

- When charging your battery, keep it near room temperature. Never expose batteries to temperatures below 0°C (32°F) or above 45°C (113°F) when charging.
- New batteries are not fully charged.
- New batteries or batteries stored for a long time may take more Motorola batteries and charging systems have circuitry that protects
- The World Health Organization has stated that present scientific information does the battery from damage from overcharging. not indicate the need for any special precautions for the use of mobile devices. They note that if you want to reduce your exposure, then you can do so by limiting the

Specific Absorption Rate (IEEE) **European Union Directives Conformance Statement**

Your model wireless phone meets the governmental requirements for exposure to radio waves.

Your mobile device is a radio transmitter and receiver. It is designed and

manufactured to not exceed limits for exposure to radio frequency (RF) energy set by

the Federal Communications Commission (FCC) of the U.S. Government and by the

Canadian regulatory authorities. These limits are part of comprehensive guidelines

guidelines are based on standards that were developed by independent scientific

standards include a substantial safety margin designed for the safety of all persons,

The exposure standard for mobile devices employs a unit of measurement known as

the Specific Absorption Rate (SAR). The IEEE SAR limit set by the FCC and by the

Canadian regulatory authorities is 1.6 watts per kilogram (W/kg), averaged over one

gram of tissue. Tests for SAR are conducted using procedures accepted by the FCC

and by Industry Canada with the mobile device transmitting at its highest certified

power level in all tested frequencies. Although the SAR is determined at the highest

certified power level, the actual SAR level of the mobile device while operating can

operate at multiple power levels so as to use only the power required to reach the

network. In general, the closer you are to a wireless base station, the lower the

Before a mobile device is available for sale to the public in the U.S. and Canada, it

must be tested and certified to the FCC and Industry Canada that it does not exceed

the limit established by each government for safe exposure. The tests are performed

in positions and locations (e.g., at the ear and worn on the body) submitted to the

FCC and available for review by Industry Canada. The highest SAR value for this

mobile device when tested for use at the ear is 850/1900: 1.11 W/kg, and when

worn on the body, as described in this guide, is 850/1900: 0.72 W/kg. Body-worn

measurements can differ, depending upon available accessories and regulatory

While there may be differences between the SAR levels of various mobile devices

differences in the SAR value for later products; in all cases, products are designed to

Additional information on SAR can be found on the Cellular Telecommunications

or the Canadian Wireless Telecommunications Association (CWTA) Web site:

Specific Absorption Rate (ICNIRP)

Your model wireless phone meets international guidelines

Your mobile device is a radio transmitter and receiver. It is designed to not exceed

the limits for exposure to radio waves recommended by international guidelines.

These quidelines were developed by the independent scientific organization ICNIRP

regardless of age and health, and to account for any variations in measurements.

The guidelines use a unit of measurement known as the Specific Absorption Bate.

(SAR). The ICNIRP SAR limit for mobile devices used by the general public is 2 watts

per kilogram (W/kg), and the highest SAR value for this mobile device when tested

at the ear is 850/1900: 0.768; 900/1800: 0.839 W/kg. As mobile devices offer a

range of functions, they can be used in other positions, such as on the body as

described in this guide. In this case, the highest tested SAR value is 850/1900:

international guidelines for testing. The SAR information includes the Motorola

testing protocol, assessment procedure, and measurement uncertainty range for this

As SAR is measured utilizing the mobile device's highest transmitting power, the

actual SAR of this mobile device while operating is typically below that indicated

While there may be differences between the SAR levels of various mobile devices

differences in the SAR value for later products; in all cases, products are designed to

length of calls or using a handsfree device to keep the mobile device away from the

Additional Information can be found on the Web sites of the World Health

Organization (http://www.who.int/emf) or Motorola, Inc. (http://

and at various positions, they meet the governmental requirements for safe

exposure. Please note that improvements to this product model could cause

ensure it only uses the minimum level required to reach the network.

above. This is due to automatic changes to the power level of the mobile device to

0.497; 900/1800; 0.478 W/kg. The tests are carried out in accordance with

and include safety margins designed to assure the protection of all persons.

requirements. The SAR information includes the Motorola testing protocol,

assessment procedure, and measurement uncertainty range for this product.

and at various positions, they meet the governmental requirements for safe

exposure. Please note that improvements to this product model could cause

nower output

be within the auidelines

http://www.cwta.ca

he within the quidelines

www.motorola.com/rfhealth

& Internet Association (CTIA) Web site:

for exposure to radio waves.

httn://www.nhonefacts.net

he below the maximum value. This is because the mobile device is designed to

organizations through periodic and thorough evaluation of scientific studies. The

regardless of age or health, and to account for any variations in measurements.

and establish permitted levels of RF energy for the general population. The

Hereby, Motorola declares that this product is in compliance . The essential requirements and other relevant

provisions of Directive 1999/5/EC All other relevant EU Directives





The above gives an example of a typical Product Approval Number. You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (to R&TTE Directive) at www.motorola.com/rtte. To find your DoC, enter the Product Approval Number from your product's label in the "Search" bar on the Web

Product

Approval

Number

Software Copyright Notice

Motorola products may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in Motorola products may not be modified, reverse-engineered. distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the nurchase of Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal non-exclusive royalty-free license to use that arises by operation of law in the sale of a product.

Content Copyright

The unauthorized copying of copyrighted materials is contrary to the provisions of the Copyright Laws of the United States and other countries. This device is intended solely for copying non-copyrighted materials, materials in which you own the copyright, or materials which you are authorized or legally permitted to copy. If you are uncertain about your right to copy any material, please contact your legal

Safety & General Information

This section contains important information on the safe and efficient operation of your mobile device. Read this information before using your mobile device.

Exposure to Radio Frequency (RF) Energy

Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate with your mobile device, the system handling your call controls the power level at which your mobile device

Your mobile device is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

Operational Precautions

For optimal mobile device performance, and to be sure that human exposure to RF energy does not exceed the guidelines set forth in the relevant standards, always follow these instructions and precautions

Product Operation

When placing or receiving a phone call, hold your mobile device just like you would a landline phone.

If you wear the mobile device on your body, always place the mobile device in a Motorola-supplied or approved clip, holder, holster, case, or body harness. If you do not use a body-worn accessory supplied or approved by Motorola, keep the mobile device and its antenna at least 2.5 centimeters (1 inch) from your body when

Using accessories not supplied or approved by Motorola may cause your mobile device to exceed RF energy exposure guidelines. For a list of Motorola-supplied or approved accessories, visit our Web site at: www.motorola.com.

RF Energy Interference/Compatibility

Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances, your mobile device may cause interference with other devices.

Follow Instructions to Avoid Interference Problems

Turn off your mobile device in any location where posted notices instruct you to do

In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight.

Implantable Medical Devices

If you have an implantable medical device, such as a pacemaker or defibrillator. consult your physician before using this mobile device.

- Persons with implantable medical devices should observe the following precautions: ALWAYS keep the mobile device more than 20 centimeters (8 inches) from the implantable medical device when the mobile device is turned ON.
- DO NOT carry the mobile device in the breast pocket.
- Use the ear opposite the implantable medical device to minimize the potential for interference.
- Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place.

Read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using your mobile device with your implantable medical device, consult your healthcare provider.

Driving Precautions

Using a mobile device while driving may cause distraction. End a call if you can't concentrate on driving. Input information about your destination and route prior to your drive. Do not input data or engage in text messaging while driving. Keep your eyes on the road while driving. Listen to the audible turn-by-turn directions, if

Also, using a mobile device or accessory may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products. Responsible driving practices can be found at www.motorola.com/ callsmart (in English only).

Operational Warnings

Obey all posted signs when using mobile devices in public areas.

Potentially Explosive Atmospheres

Definition

Areas with potentially explosive atmospheres are often, but not always, posted and can include fueling areas, such as below decks on boats, fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain dust, or metal powders.

When you are in such an area, turn off your mobile device, and do not remove, install, or charge batteries. In such areas, sparks can occur and cause an explosion

Symbol Key Symbol

Your battery, charger, or mobile device may contain symbols, defined as follows:

\triangle	Important safety information follows.
8	Do not dispose of your battery or mobile device in a fire.
	Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
Z	Do not throw your battery or mobile device in the trash.
Ť	Do not let your battery, charger, or mobile device get wet.
	Listening at full volume to music or voice through a headset may damage your hearing.

Batteries & Chargers

Caution: Improper treatment or use of batteries may present a danger of fire, explosion, leakage, or other hazard. For more information, see "Battery Use &

Keep Your Mobile Device & Its Accessories Away From Small Children

These products are not toys and may be hazardous to small children. For example: A choking hazard may exist for small, detachable parts.

 Improper use could result in loud sounds, possibly causing hearing injury. Improperly handled batteries could overheat and cause a burn.

Glass Parts

Some parts of your mobile device may be made of glass. This glass could break if the product is dropped on a hard surface or receives a substantial impact. If class breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by a distributor.

Seizures/Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when playing video games. These may occur even if a person has never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such

occurrences, please consult with your physician before playing video games or enabling a flashing-lights feature (if available) on your mobile device. Discontinue use and consult a physician if any of the following symptoms occur: convulsion, eve or muscle twitching, loss of awareness, involuntary movements, or disorientation. It is always a good idea to hold the screen away from your eyes. leave the lights on in the room, take a 15-minute break every hour, and stop use if you are tired

Caution About High Volume Usage

Warning: Exposure to loud noise from any source for extended periods of time may affect your hearing. The louder the volume sound level, the less time is required before your hearing could be affected. To protect your hearing:

- Limit the amount of time you use headsets or headphones at high volume
- Avoid turning up the volume to block out noisy surroundings.

 Turn the volume down if you can't hear people speaking near you. If you experience hearing discomfort, including the sensation of pressure or fullness in your ears, ringing in your ears, or muffled speech, you should stop listening to the device through your headset or headphones and have your hearing checked. For more information about hearing, see our Web site at

direct.motorola.com/hellomoto/nss/AcousticSafety.asp (in

Repetitive Motion

When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. If you continue to have discomfort during or after such use, stop use and see a physician.

FCC Notice to Users

The following statement applies to all products that have received FCC approval. Applicable products bear the FCC logo, and/or an FCC ID in the format FCC-ID:xxxxxx on the product label.

Motorola has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment See 47 CFR Sec. 15 21

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(3).

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures

Reprient or relocate the receiving antenna

extreme heat or cold

the receiver is connected.

- Increase the separation between the equipment and the receiver. Connect the equipment to an outlet on a circuit different from that to which
- . Consult the dealer or an experienced radio/TV technician for help.

Use & Care



To care for your Motorola phone, please keep it away from: liquids of any kind

Don't expose your phone to water, rain, extreme humidity, sweat, or other moisture. If it does get wet, don't try to accelerate drying with the use of an oven or dryer, as this may damage the phone.



Avoid temperatures below 0°C/32°F or above 45°C/113°F.

Don't try to dry your phone in a microwave oven.



Don't expose your phone to dust, dirt, sand, food, or other inappropriate materials.



other cleaning solutions.

shock and vibration Don't drop your phone

Information from the World Health Organization

Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If you are concerned, you may want to limit your own or your children's RF exposure by limiting the length of calls or by using handsfree devices to keep mobile phones away from your head and body. Source: WHO Fact Sheet 193

Further information: http://www.who.int/peh-emf

Caring for the Environment by Recycling

This symbol on a Motorola product means the product should not be disposed of with household waste.

Disposal of your Mobile Device & Accessories

Please do not dispose of mobile devices or electrical accessories (such as chargers, headsets, or batteries) with your household waste. Do not dispose of your battery or mobile device in a fire. These items should he disposed of in accordance with the national collection and recycling schemes operated by your local or regional authority. Alternatively, you may return unwanted mobile devices and electrical accessories to any distributor in your region. Details of Motorola approved national recycling schemes, and further information on Motorola recycling activities can be found at: www.motorola.com/

Disposal of your Mobile Device Packaging & Product Guide

Product packaging and product guides should only be disposed of in accordance with national collection and recycling requirements. Please contact your regional authorities for more details.

Privacy & Data Security

Motorola understands that privacy and data security are important to everyone. Because some features of your mobile device may affect your privacy or data security, please follow these recommendations to enhance protection of your

- . Monitor access—Keep your mobile device with you and do not leave it where others may have unmonitored access. Lock your device's keypad where this feature is available.
- Keep software up to date—If Motorola or a software/application vendor releases a patch or software fix for your mobile device that updates the device's security, install it as soon as possible
- Secure personal information—Your mobile device can store personal information in various locations including your SIM card, memory card, and phone memory. Be sure to remove or clear all personal information before you recycle, return, or give away your device. You can also backup your personal data to transfer to a new device.

Note: For information on how to backup or wipe data from your mobile device, go to www.motorola.com/support

- Online accounts—Some mobile devices provide a Motorola online account (such as MOTOBLUR). Go to your account for information on how to manage the account, and how to use security features such as remote wipe and device location (where available)
- Location-based information—Location-based information includes information that can be used to determine the approximate location of a mobile device. Mobile phones which are connected to a wireless network transmit location-based information. Devices enabled with GPS or AGPS technology also transmit location-based information. Additionally, if you use applications that require location-based information (e.g. driving directions) such applications transmit location-based information. This location-based information may be shared with third parties, including your wireless

service provider, applications providers, Motorola, and other third parties nroviding services

 Other information your device may transmit—Your device may also transmit testing and other diagnostic (including location-based) information, and other non-personal information to Motorola or other third-party servers. This information is used to help improve products and services offered by

If you have further questions regarding how the use of your mobile device may impact your privacy or data security, please contact Motorola at <u>privacy@motorola.com</u>, or contact your service provider.

Smart Practices While Driving

Drive Safe, Call Smart

Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas—for example, handsfree use only. Go to www.motorola.com/callsmart (in English only) for more information

Your mobile device lets you communicate by voice and data—almost anywhere anytime, wherever wireless service is available and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your mobile device while driving, remember the following tip:

- Get to know your Motorola mobile device and its features such as speed dial and redial. If available, these features help you to place your call without taking your attention off the road · When available, use a handsfree device. If
- nossible, add an additional layer of convenience to your mobile device with one of the many Motorola Original handsfree accessories available today. Position your mobile device within easy reach. Be
- eves from the road. If you receive an incoming call at an inconvenient time. if possible, let your voicemail answer it for you. · Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather

able to access your mobile device without removing your

- conditions. Rain, sleet, snow, ice, and even heavy traffic can be hazardous. Do not take notes or look up phone numbers while driving. Jotting down a "to do" list or going through your address book takes attention away from your primary responsibility—driving safely. Dial sensibly and assess the traffic; if possible, place calls when
- your car is not moving or before pulling into traffic. If you must make a call while moving, dial only a few numbers, check the road and your mirrors, then continue • Do not engage in stressful or emotional conversations that may be
- distracting. Make people you are talking with aware you are driving and suspend conversations that can divert your attention away from the road Use your mobile device to call for help. Dial 911 or other local emergency number in the case of fire, traffic accident, or medical
- emergencies (wherever wireless phone service is available) Use your mobile device to help others in emergencies. If you see an auto accident, crime in progress, or other serious emergency where lives are in danger, call 911 or other local emergency number (wherever wireless phone service is available), as you would want others to do for you.
- Call roadside assistance or a special non-emergency wireless assistance number when necessary. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number (wherever wireless phone service is available).

www.hellomoto.com Motorola Argentina S.A. Suinacha 1111 - Piso 18 C1008AAW Buenos Aires

ARGENTINA

Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features. may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality. All features, functionality, and other product specifications, as well as the information contained in this guide, are based upon the latest available information and believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. Obigo is a registered trademark of Obigo A. eZiText and Zi are trademarks of Zi Corporation and/or its Affiliates. All other product or service names are the property of their respective owners. © 2010 Motorola, Inc. All rights reserved.

Caution: Changes or modifications made in the radio phone, not expressly approved by Motorola, will void the user's authority to operate the equipment

Manual Number: 68000202693-A TCT Manual Number: CJB2161ALAAA

Motorola, Inc.

Consumer Advocacy Office 600 N US Hwy 45 Libertyville, II 60048