

---

## **Temporary Confidentiality Requested**

### **Exhibit 8: Draft User's Manual -- 47 CFR 2.1033(b)(3)**

The attached User's Manual is the final production-intended version of the generic Motorola International English User Manual. This guide will be adapted to carrier-specific versions, but the key information herein will be retained. Translations into other languages will also be done to support the needs of other markets. Minor revisions may be made to these manuals, prior to and subsequent to, placing this product onto the market. Selected portions of the User Guide can be found as indicated below:

<b>8.1 Safety and Regulatory Section:</b>	<b>Part 2,Page 14</b>
<b>8.2 Part 15B Declaration of Conformity (Pursuant to 47 CFR 2.1077):</b>	<b>Part 2 Page 24</b>
<b>8.3 Specific Absorption Rate (SAR) Data:</b>	<b>Part 2, Page 21</b>
<b>8.4 Guidance for use with Hearing Aids (Pursuant to 47 CFR 20.19(f)(1):</b>	<b>Part 2 Page 10 Part 2 Page 32</b>

MOTOROLA **i420**

LIFE.  POWERED.



# Congratulations

## MOTOROLA i420

Get the convenience of push-to-talk calls together with a sleek design in an affordable package.

- **Private Calls:** Stay in touch with your family, friends, and colleagues with the simple touch of a button.
- **FM Radio:** Listen to your favorite stations wherever you go.
- **My Phone, My Way:** It's your phone—make it that way. Customize your home screen with personal pictures, and change wallpapers and ringtones.

**Caution:** Before assembling, charging or using your phone for the first time, please read the important legal and safety information packaged with your product.

More information

**On your computer**—Go to [www.motorola.com/support/](http://www.motorola.com/support/).

# Your phone

*the important keys & connectors*



CONFIDENTIAL



DR  
& P




CONFIDENTIAL  
FORMATION

**Note:** Your phone might look a little different.

# Contacts

Menu map . . . . .	5
Let's go . . . . .	9
Basics . . . . .	11
Calls . . . . .	14
Push-to-Talk . . . . .	16
SDG calls . . . . .	18
Web . . . . .	19
Text entry . . . . .	20
Contacts . . . . .	22
Messaging . . . . .	23
Personalize . . . . .	26
Camera . . . . .	28
Media center . . . . .	29
FM radio . . . . .	30
Bluetooth™ wireless . . . . .	31
Tools . . . . .	33
Security . . . . .	36
Safety, Regulatory & Legal . . . . .	38

 DRAFT - MOTOROLA CONFIDENTIAL & PROPRIETARY INFORMATION

# Menu map

## main menu

### Call Alert

### Bluetooth®

- Hands Free
- Link to Devices
- Device History
- Setup
- Find Me

### Settings

- (see **settings** menu)

### Ring Tones

- Vibrate All: On/Off
- Ringtones
- Vibrate
- Silent

### Java Apps

- Java System
- FM Radio

### GPS

- Position
- Privacy
- Interface

### Media Center

### Camera

### Net

### My Info

- My name
- Line 1
- Line 2
- Private ID
- Group ID
- Carrier IP
- IP1 Address
- IP2 Address

### Datebook

### VoiceRecord

- [New VoiceRec]

### Memo

### Recent Calls

### Shortcuts

- [Help]
- 1)Shortcuts
- 2)Cntcs[New Contact]
- 3)Recent Calls
- 4)Contacts
- 5)Datebook
- 6)Messages
- 7)VoiceRecord
- 8)Net
- 9)Call Forward



## main menu (con't.)

### **Contacts**

- [New Contact]
- [New SDG List]
- [New Msg Group]

**Note:** Your service provider may not offer the Message Group feature.

### **Call Forward**

### **Quick PTT**

### **Profiles**

- [New Profile]
- Standard
- Car
- Meeting
- Office
- Outdoors
- Headset
- PRVT Only
- CNTCS Only
- Surveillance

### **Call Timers**

- Last Call
- Phone Reset
- Phone Lifetime
- Prvt/Grp Reset
- Prvt/Grp Life
- Kbytes Reset

### **PT Manager**

- Quick PTT
- Send Message
- Send Picture
- Send Event
- Send My Info
- Send Contact
- Configure

### **Messages**

- [Create Message]
- Voice Mail
- Inbox
- Drafts
- Outbox
- Fax Mail
- Net alert
- Sent Items

### **FM Radio**

**Note:** Your service provider may not offer the FM Radio feature.

This is the standard main menu layout.

**Your phone's menu may be different.**

## settings menu

### Display/Info

- Wallpaper
- Text Size
- Theme
- Home Icons
- Backlight
- Clock
- Menu View
- Large Dialing
- Language

### Phone Calls

- Set Line
- Any Key Ans
- Auto Redial
- Call Waiting
- Auto Ans
- Flip Activation
- Minute Beep
- Call Duration
- TTY
- Hearing Aid
- Notifications
- DTMF Dialing
- Prepend

### 2-Way Radio

- Tkgrp Silent
- Tkgrp Area
- One Touch PTT
- Alert Type
- PTT Quick Notes
- On/Off PTT
- Store Rcvd Info

### Personalize

- Menu Options
- Up Key
- Down Key
- Left Key
- Right Key
- Center Key
- Left Softkey
- Right Softkey
- Power Up

### Volume

- Line 1
- Line 2
- Messages
- Earpiece
- Speaker
- Keypad
- Java Earpiece
- Java Spkr
- Data

## settings menu (con't.)

### Security

- Phone Lock
- Keypad Lock
- SIM PIN
- GPS PIN
- Change Passwds

### Advanced

- Alert Timeout
- Headset/Spkr
- Connectivity
- Reset Defaults
- Return to Home
- Transmitters
- Phone Only
- Baud Rate

DRAFT - MOTOROLA CONFIDENTIAL  
PROPRIETARY INFORMATION

# Let's go

*let's get you up and running*

## Assemble & charge

1 Remove cover



2 SIM in



3 Battery in



4 Cover on




5 Charge up





**Caution:** Please read "Battery Use & Safety" on page 38.

## Turn it on & off

To turn on your phone, press and hold End/Power  for a few seconds or until the display turns on. If prompted, enter your four-digit unlock code.




**Note:** If you press End/Power  for more than four seconds, the phone will turn on in **Transmitters Off** mode.

To turn off your phone, press and hold End/Power .

## Enable security

You will need to enable security the first time you turn on your phone or within 10 days of using your phone.

- 1 Press **Ok**.
- 2 You are prompted to enable security. Press **Yes** and follow the on-screen instructions.
- 3 Press End/Power  to return to the home screen.





# Basics

## About this guide

This guide shows how to locate a menu feature as follows:

**Find it:** Menu  >  **Settings** > **Phone Calls**

This means that, from the home screen:

- 1 Press the Menu key  to open the main menu.
- 2 Press the navigation keys to scroll to the  **Settings** menu option, and press the center key  to select it.
- 3 Press the navigation keys to scroll to **Phone Calls**, and press the center key  to select it.

## Home screen

Your phone shows the *home screen* when you are not on a call or using the menu.

