

MOTOROLA XT875
Verizon
User's Guide
3/29/11

Dummy Page - To be discarded before printing

Use this template with A6MotoLandscapeProduct1 StructApps.

See the Reference Pages for template user instructions.

CONGRATULATIONS

MOTOROLA XT875


Stay connected, organize your life, and absolutely own the web with MOTOROLA XT875!

- Surf the web with a blistering fast 1 GHz dual-core processor. 4G LTE connectivity gives you download speeds up to 10x faster than before.
- Use your smartphone in over 200 countries. International roaming lets you make calls and stay in touch wherever you travel.
- Watch streaming Netflix videos on your 4.3" qHD touchscreen, or use mirror mode to view your smartphone on your TV screen for gaming, videos, web browsing, and more.
- Capture life's moments in full 1080p HD video. Use the gallery to gather all your photos and your friends' online albums in one place.

Note: Certain apps and features may not be available in all countries.

Caution: Before assembling, charging, or using your phone for the first time, please read the important legal and safety information packaged with your product.

MORE

- **Answers:** Touch **Launcher icon**  > **Help Center**.
- **Updates:** Smartphone updates, computer software, user guides, online help, and more at www.motorola.com/support.
- **Accessories:** Find accessories for your smartphone at www.motorola.com/products.

Notes:

- Unless specified otherwise, all instructions to perform tasks in this guide assume that you are starting from the home screen.
- All screens in this guide are simulated. Actual displays may vary.
- Your smartphone supports data-intensive apps and services. It is strongly recommended that you purchase a data plan that meets your needs. Contact your service provider for details.
- Instructions to perform tasks in this guide may change depending on the software version on your smartphone.

YOUR SMARTPHONE

the important keys & connectors



CONTENTS

LET'S GO.....	3
TOUCHSCREEN & KEYS	5
HOME SCREEN	8
APPS & UPDATES	11
CALLS	13
CONTACTS	16
MESSAGING.....	18
TEXT ENTRY	21
TIPS & TRICKS.....	23
DIGITAL LIVING.....	24
PHOTOS & VIDEOS	26
MUSIC.....	30
SOCIAL NETWORKING.....	32
WEB	33
PERSONALIZE.....	35
LOCATION	37
BLUETOOTH® WIRELESS.....	39
WI-FI®	40
MEMORY CARD & FILE MANAGEMENT	42
TOOLS.....	43
MANAGEMENT	45
SECURITY.....	46
GLOBAL PHONE	48
TROUBLESHOOTING.....	49
SAFETY, REGULATORY & LEGAL.....	50

Note: Your smartphone might look a little different.

LET'S GO

let's get you up and running

ASSEMBLE & CHARGE


- 1 SIM in
(already inserted).




- 2 MicroSD in
(sold separately).



- 3 Battery in.



Battery removal
tab (do not cut)



- 4 Cover on.



- 5 Charge up.



Caution: Please read “**BATTERY USE & SAFETY**” on page 50.

Note: GSM and UMTS-based global services work only with a SIM card supplied by Verizon Wireless® or by another GSM or UMTS service provider. When you set your phone to use a GSM 900/1800 or UMTS 2100 network (see “**MANUALLY SWITCH NETWORK MODE (OUTSIDE THE U.S.)**” on page 45), you may be prompted to enter a subsidy code. To get this code, contact Verizon Wireless.


Tip: To save battery life, see “**BATTERY TIPS**” on page 24.

SET UP & GO

The first time you turn on your smartphone, a setup wizard guides you through signing in to your Gmail™ account. If you don't have one, don't worry, the wizard will help you create one.

After you log in to Gmail, you can set up social networking, or you can do it later.

Note: Your smartphone supports data-intensive apps and services. It is strongly recommended that you purchase a data plan that meets your needs. Contact your service provider for details.

1 Press and hold Power  on top of your smartphone to turn it on.

2 Select a language.

3 Follow the setup wizard to create or log in to your Gmail account.



Note: If you have an existing Gmail account, your contacts from that account are synced to your smartphone. Whenever you choose to select all contacts for the one you want, your smartphone shows every contact, in every group.

WI-FI® CONNECT

If you want to use a Wi-Fi network for even faster Internet access, touch Menu  > **More** > **Settings** > **Wireless & networks** > **Wi-Fi settings**. Touch **Wi-Fi** to search for and connect to wireless networks. There's more in "**Wi-Fi**" on page 40.

COOL CONTENT & MORE

Browse and download thousands of the coolest apps on the planet from Android Market™.





Download new apps with "**BROWSE & INSTALL APPS**" on page 11. Your smartphone can use a microSD memory card (sold separately)—you can load it up with photos, videos, and music from your computer (see "**MEMORY CARD**" on page 42).

TOUCHSCREEN & KEYS

a few essentials

TOUCHSCREEN ON/OFF

Your touchscreen is on when you need it and off when you don't.

- To make your touchscreen sleep or wake up, just press Power .
- When you hold the phone to your ear during calls, your touchscreen sleeps to prevent accidental touches.
- To change how long your phone waits before the screen goes to sleep automatically, touch Menu  > **More** > **Settings** > **Display** > **Screen timeout**.
- To make the screen lock when it goes to sleep, use "**SCREEN LOCK**" on page 46. To unlock the screen, press Power  or open the phone. Then, drag  to the right.

Note: Your touchscreen might stay dark if the sensor just above it is covered. Don't use covers or screen protectors (even clear ones) that cover this sensor.




TOUCH TIPS


Here are some tips on how to navigate around your smartphone.

TOUCH

To choose an icon or option, *touch* it.



TOUCH & HOLD

To open special options, *touch and hold* an icon or other item. Try it: In the home screen, touch **Launcher icon**  > **Contacts**, then touch and hold a contact to open options.



DRAG

To scroll through a list or move slowly, *drag* across the touchscreen. Try it: In the home screen, touch  **Contacts**, then drag your **Contacts** list up or down.



FLICK

To scroll through a list or move quickly, *flick* across the touchscreen (drag quickly and release).

Tip: When you flick a long list, touch the screen to stop it from scrolling.

ZOOM

Get a closer look at Google Maps™ or web pages. To zoom in, *double-touch* (tap twice, quickly) the screen. To zoom out, *double-touch* the screen again.



You can also zoom in or out by pinching your fingers together or moving them apart on the screen.





To zoom in, touch with two fingers, then move them apart.


KEY TIPS

MENU, HOME, SEARCH, & BACK


Touch Home  to close any menu or app and return to the home screen. In the home screen, touch and hold Home  to show the last eight apps you used, then touch an app to open it.

Touch Search  for text search, or touch and hold for voice search.

Touch Menu  to open menu options, or touch Back  to go back.



POWER KEY MENU

Press and hold Power  to open the power key menu, where you can turn off your smartphone (**Power off**), or turn **Airplane mode** or **Silent mode** on or off.

ADJUST VOLUME

Press the volume keys to change the ring volume or the earpiece volume (during a call).



ROTATE THE SCREEN

In many apps, the touchscreen adjusts to display in landscape mode when you turn the smartphone sideways:


Find it: Menu  > **More** > **Settings** > **Display** > **Auto-rotate screen**

QUICK TIPS

If you're not sure what to do next, try one of these:


To...



Get the details—Open a text message, see details for a contact, or open items in other lists. Touch the message, contact, or item.

See screen menu—Open a menu for the current screen. Touch Menu .

To...

See item options—Open an options menu (if available) for an item on the screen. Touch & hold the item.


Start again—Go back to the home screen. Touch Home .

Wake up your smartphone—Turn on a sleeping touchscreen. Press Power  or touch Home .

HOME SCREEN

quick access to the things you need most

QUICK START: HOME SCREEN

The *home screen* gives you all your latest information in one place. It's what you see when you turn on the smartphone or touch Home  from a menu. It's basically like this:

