

MOTOROLA XT760™

LIFE. M POWERED.

LRESTRICTED :: MOT WESTENCTED:: MOTOROLACOMING. ON ROLLED DRAKE COMBONIES SON STREET ON THE STREET OF TH STAPAG GET JOROTON :: GESTRICTED :: MOTOROL

CONGRATULATIONS

MOTOROLA XT760

Your MOTOROLA **XT760** phone delivers more for your work and play!

- Search: Touch Search Q to search across your apps, contacts, web, and maps—or just enter the address for a place or a web page.
- Apps: Open
 \$\begin{align*}{l} Market to download games for fun, social networking apps to keep in touch (like Facebook™ or Twitter), or find something else you like with "APPS & UPDATES" on page 13.
- Web: Browse the web and pinch-to-zoom on the touch display in "WEB" on page 37.
- Camera: Capture photos and videos with the 8MP auto-focus camera in "PHOTOS & VIDEOS" on page 42.

Note: Some apps and features might not be available in all countries.

Caution: Before assembling, charging, or using your phone for the first time, please read the important legal and safety information packaged with your product.

SAR

This product meets the applicable limit for exposure to radio waves (known as SAR) of 2.0 W/kg (ICNIRP). The limits and guidelines

include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The highest SAR values measured for this device are listed in the regulatory information packaged with your product.

Note: When using the product while worn on your body, either use an approved accessory such as a holster or maintain a distance of 2.5 cm (1 inch) from the body to ensure compliance with SAR requirements. Note that the product may be transmitting even if you are not making a phone call.

WANT MORE?

More help, more accessories, more free stuff. We're here to help. February 22nd, 2012

- Updates: Phone updates, PC software, user's guides, online help, and more at www.motorola.com/support.
- Accessories: Find more for your phone at <u>www.motorola.com/products</u>.
- Social: The latest news, tips & tricks, videos, and so much more—join us on:
 - YouTube™ www.youtube.com/motorola
 - Facebook™ www.facebook.com/motorola
 - > Twitter www.twitter.com/motomobile.

YOUR PHONE

the important keys & connectors



CONTENTS

LET'S GO!	5
TOUCHSCREEN & KEYS	8
HOME & APPS	
PERSONALIZE19	
CALLS 23	
CONTACTS 20	6
MESSAGING 29	
TEXT ENTRY 3:	
SCHEDULE 3!	
WEB 3:	
LOCATION 39	9
PHOTOS & VIDEOS	2
MUSIC	5
CONNECTIONS 44	
SECURITY 54	4
TROUBLESHOOTING 50	6
SAFETY, REGULATORY & LEGAL	7
al 7 1 8 \ / 8 / 0 /:	

LET'S GO

let's get you up and running

ASSEMBLE & CHARGE



Caution: Please read "BATTERY USE & SAFETY" on page 57.

SET UP & GO

Note: This phone supports data-intensive apps and services. It is strongly recommended that you purchase a data plan that meets your needs. Contact your service provider for details.

When you turn on your new phone, you can create or enter a Google™ account so that you can download apps, use Gmail™, and much more:

- Press and hold
 Power/Lock Key to
 turn on your phone.
- 2 Touch the Android™ icon to begin setup.
- 3 Touch a button to
 Create a Google
 account, Sign in with one you have, or Skip.

You can log into your account from a computer at https://accounts.google.com.

- 4 Enter details to create or sign into your account. When your phone confirms the account, it shows account sync options.
 - To change whether your phone shows the Google account's contacts, GmailTM, and calendar, touch the Google account name.

- To add another account, touch Add account. For details, see "EMAIL" on page 30.
- To exit setup touch Home <a>_.

Note: If your phone cannot connect, touch Menu **>** > **Settings** > **Wireless & networks** to change mobile network settings.



TOUCHSCREEN & KEYS

a few essentials

TOUCHSCREEN ON/OFF

Your touchscreen is on when you need it and off when you don't.

- When you hold the smartphone to your ear during calls, your touchscreen sleeps to prevent accidental touches.
- To make your touchscreen sleep or wake up, just press Power 0.
- To unlock the screen, press Power (0), then touch and flick to 1.

Note: Your touchscreen might stay dark if the sensor iust above it is covered. Don't use covers or screen protectors (even clear ones) that cover this sensor.

TOUCH TIPS

It's all in the touch:

- Touch: Choose an icon or option
- Touch & Hold: Show options.
- Flick: Scroll or move quickly.

 Zoom: Slide fingers apart or together to zoom in or out on web pages, or photos.



KEY TIPS

MENU, HOME, BACK, & SEARCH

Touch Home to close any menu or app and return to the home screen. In the home screen, touch and hold Home to show the most recent apps used, then touch an app to open it.



Touch Menu (=) to open menu options.

Touch Back (to go back.

Touch Search of for text search, or touch and hold for voice search.

POWER KEY MENU

Press and hold Power **(0)** to open the power key menu, where you can turn off your smartphone (**Power off**), turn **Airplane mode** or **Silent mode** on and off.

HARESTRICTED :: MOTOROLA COMPINION

ADJUST VOLUME

Press the volume keys to change ring volume (in the home screen) or earpiece volume (during a call).

When playing music or video files, press the volume keys to adjust media volume.



ROTATE THE SCREEN

When you turn your smartphone, the touchscreen can rotate to stay right-side up:

Find it: Menu > Settings > Display > Auto-rotate screen


HOME & APPS

a few essentials

OUICK START: HOME SCREEN

Use your home screen for quick access to apps, search, and more. Download social networking apps (like Facebook™ or Twitter) to keep in touch.

You'll see the home screen when you turn on the phone or touch Home (from a menu:



- To open shortcuts or widgets, touch them. Touch Home to return to the home screen.
 - When you open shortcuts or widgets, touch Menu for options.
- To move or delete shortcuts or widgets, touch and hold them until you feel a vibration, then drag it to another spot, another panel, or at the top.
 In lists like Contacts, touch and hold list items for options.
- To add shortcuts, widgets, or wallpaper, touch and hold an empty spot until you see the menu. You can also add a folder to organize your shortcuts.
- To show more panels, drag or flick right or left. Touch and hold to show panel thumbnails.
 In lists like Contacts, drag or flick to scroll.

To change your ringtone, display brightness, and more, touch Menu Settings > Sound or Display. For details, see "PERSONALIZE" on page 19.

APPS & UPDATES

You can find all of your apps in one place. From the home screen, touch one to open the app menu. To see all of your apps, flick left and right.

From the app menu, touch All apps to view or create app groups.



To close the app menu, touch Home riangle or Back riangle

BROWSE & INSTALL APPS 2nd, 2012

Get all the fun games and cool apps you want! Android Market™ provides direct access to apps, games, and books that you can download and install on your smartphone.

Find it: 🖸 > 🍙 Market

Scroll to and touch the app you want to install. Then, touch **Install** (if app is free) or **Buy**.

New apps that you install are added to the app menu.

Tip: Choose your apps and updates carefully, from trusted sites like **Market**, as some may impact your

smartphone's performance—see "**choose carefully**" on page 15.

Note: When installing an app, make sure you read the alerts that tell you what information the app will access. If you don't want the app to have access to this information, cancel the installation.

RECENT APPS

Your smartphone remembers the apps that you used most recently. From the home screen, touch and hold Home a to show the most recent apps used. From the app menu, touch so Recent.

MANAGE & RESTORE APPS

From the home screen, touch Menu 🚍 > Manage Apps.

Touch an app in the list, then touch **Uninstall** (for apps you downloaded), **Clear cache**, or other options.

To reinstall apps from Android Market, touch > Market, then touch Menu > My apps. Apps that you have previously purchased from Android Market are listed and available for download.

CHOOSE CAREFULLY

Apps are great. There's something for everyone. Play, communicate, work, or have fun. But remember, choose your apps carefully. Here are a few tips:

- To help prevent spyware, phishing, or viruses from affecting your smartphone or privacy, use apps from trusted sites, like Market.
- In Market, check the apps' ratings and comments before installing.
- If you doubt the safety of an app, don't install it.
- Like all apps, downloaded apps will use up memory, data, battery, and processing power—some more than others. For example, a simple battery level widget will use less than a streaming music player app. After installing an app, if you're not happy with how much memory, data, battery or processing power it's using, uninstall it. You can always install it again later.
- Just like web browsing, you may want to monitor childrens' access to apps to help prevent exposure to inappropriate content.
- Certain apps may not provide completely accurate information. Take care, especially when it comes to personal health.

UPDATE MY SMARTPHONE

You can check, download, and install smartphone software updates using your smartphone, or using your computer:

· Using your smartphone:

You may get an automatic notification of an available update on your smartphone. Simply follow the instructions to download and install.

To manually check for updates, touch Menu = > Settings > About phone > System updates.

Your smartphone downloads any updates over your mobile network. Remember, these updates can be quite large (25MB or more) and may not be available in all countries. If you don't have an unlimited data plan, or mobile network updates are not available in your country, you can update using a computer.

Using your computer:

On your computer, go to www.motorola.com/myrazr and check the "Software" links. If an update is available, follow the installation instructions.

PHONE STATUS & NOTIFICATIONS

In the status bar at the top of your screen, the right side shows phone status. The left side shows new messages or events (for details, flick the bar down).



1	network strength	4	battery strength
8	new voicemail	(;	new text message