








	Bluetooth™ on		Bluetooth connected
	Wi-Fi connected		airplane mode
	USB connected		alarm set
	silent ringer		silent ringer, vibrate on
	mute call		speakerphone

February.22nd, 2012


PERSONALIZE

add your personal touch

QUICK START: PERSONALIZE


Customize your phone's sounds and appearance to make it unique to you.

From the home screen, touch Menu  > **Settings** > **Sound** or **Display**.



Choose separate volume settings for incoming calls, media, alarms, and notifications.

Call & Message Notifications









Turn on or off menu animations.

Animation


All window animations are shown

Screen timeout

Adjust the delay before the screen automatically turns off

- To choose a **ringtone** or **vibration** for calls and messages, touch Menu  > **Settings** > **Sound**, then choose **Phone ringtone**, **Notification ringtone**, or **Vibrate**.
- To change the **volume**, touch Menu  > **Settings** > **Sound** > **Volume**.
- To turn **dialpad** sounds on or off, touch Menu  > **Settings** > **Sound** > **Audible touch tones**.
- To turn menu **selection** sounds on or off, touch Menu  > **Settings** > **Sound** > **Audible selection**.
- To change your **wallpaper**, touch and hold an empty spot on the home screen, then touch **Wallpapers**.
- To change **shortcuts** and **widgets** on your home screen, touch and hold them. For details, see "**HOME & APPS**" on page 12.
- To set display **brightness**, touch Menu  > **Settings** > **Display** > **Brightness**.
- To control whether some apps **rotate** the screen when you rotate your phone, touch Menu  > **Settings** > **Display** > **Auto-rotate screen**.
- To turn on or off **animations** that make your menus look smoother, touch Menu  > **Settings** > **Display** > **Animation**.

LANGUAGE & REGION

To set your menu language and region, touch Menu 
> **Settings** > **Language & keyboard** > **Select language**



CALLS

it's good to talk


QUICK START: CALLS


Dial numbers, see recent calls, combine calls, or set up forwarding, restrictions, and more.

From the home screen, touch  **Phone**.



Open a list, then touch an entry to call.

Touch  to switch to **Smart dialer** mode.




Call.






Hang up.

Start a conference call.




Use a connected Bluetooth™ device.

- To **make** a call, touch  **Phone**, enter a number, then touch .

To enter the international dialing code, touch and hold .


- To **answer** a call, touch  and flick to .
- **During** a call, touch **Bluetooth** to switch to a Bluetooth **headset** (see “**CONNECTIONS**” on page 48). Touch Home  or Back  to hide the active call display (to reopen it, touch  **Phone**).


Note: Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.



- To use the **speakerphone** during a call, touch **Speaker**.
- To **enter numbers** during a call, touch **Dialpad**.
- To **mute** or **unmute** a call, touch **Mute**.
- To **end** a call, touch .
- To **ignore** an incoming call, touch  and flick to .

Tip: For quick access to contacts, see “**FAVORITES**” on page 27.

RECENT CALLS

To show recent calls, touch  **Phone** > **Call log**.

- To call, text, open, or save an entry, touch and hold it.
- To clear the list, touch Menu  > **Clear call log**.



Tip: To access the dial pad and a list of your most recent calls, touch  **Phone** > Menu  > **Smart dialer**.


CONFERENCE CALLS

To start a three-way call, call the first number. After they answer, touch **Add call** and call the next number. When the next number answers, touch **Merge calls**. To remove individual callers, touch **Manage**.

CALL WAITING

If you are on a call and a new call arrives:

- With call waiting on, touch  and flick to  to answer the new call and put the old call on hold. Then, touch **Swap** to switch between calls, or **Merge calls** to combine them.
- With call waiting off, the new call goes straight to your voicemail.

To turn on call waiting, touch Menu  > **Settings** > **Call settings** > **GSM call settings** > **Additional settings** > **Call waiting**.


COOL DOWN

In very limited circumstances, such as where your phone has been exposed to extreme heat, you may see “Cool Down” messages. To avoid possible damage to your battery and phone, you should follow these instructions until the phone is within its recommended

temperature range. When your phone is in “Cool Down” mode, only emergency calls can be made.

EMERGENCY CALLS

Note: Your service provider programs one or more emergency phone numbers that you can call under any circumstances, even when your phone is locked. Emergency numbers vary by country. Your pre-programmed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

- 1** Touch  (if your phone is locked, touch **Emergency Call**).
- 2** Enter the emergency number.
- 3** Touch **Call** to call the emergency number.


Note: Your mobile device can use AGPS satellite signals to help emergency services find you (“**LOCATION**” on page 39).


CONTACTS

contacts like you've never had before

QUICK START: CONTACTS


Keep each friend's email, phone number, and even address all in your **Contacts** for quick access.




From the home screen, touch  **Phone** > **Contacts**






Switch to the dialer, receive, and more.







Drag or flick to scroll.

Touch  to search, create, or more.


- To **create** a contact, touch  **Dialer** > **Contact** > Menu  > **New contact**, choose where you want to store the contact, then enter details (to close the display keyboard, touch Back ).

Tip: To quickly create contacts from the call log, touch  **Phone** > **Call log**, touch & hold the number then touch **Add new contact**.

Contacts shows the contacts from your Google™ account, which you can open from any computer at <https://contacts.google.com> (or open your contacts within <https://mail.google.com>). To stop synchronizing with your account, touch  **Dialer** > **Contacts** > Menu  > **More** > **Accounts**, touch your Google account, then uncheck **Sync Contacts**.

- To **call**, **text**, or **email** a contact, touch  **Dialer** > **Contacts**, touch the contact, then touch  (call),  (text), or  (email).
- To **edit** or **delete** a contact, touch  **Dialer** > **Contacts**, touch the contact, then touch Menu .

FAVORITES



For quick access to a favorite contact, open the contact, then touch the star next to their name. To show your favorites, touch  **Dialer** and touch **Favorites**.

To add a shortcut to your favorites, touch and hold a blank spot on your home screen, then touch **Folders** > **Starred contacts**. You can also add a shortcut for an individual contact: Touch and hold a blank spot on your home screen, then choose **Shortcuts** > **Contacts**.

STORAGE & TRANSFER

When you create a new contact, your phone asks if you want to store it in your Google™ account, phone memory, or SIM card. Contacts in all three places appear in your **Contacts** list, but if you change phones:

- Contacts in your Google™ account can download when you log into your Google account on a new Android™ device. You can open these contacts from any computer at <https://contacts.google.com>.
- Contacts on your SIM card can load to a new device when you insert your SIM card.
- Contacts in your phone memory stay in your old phone, unless you export them.


To import or export contacts between your phone memory and a SIM or memory card, touch  **Dialer** > **Contacts**, then touch Menu  > **More** > **Import/export**.


MESSAGING

sometimes it's best to text or email...

QUICK START: TEXT MESSAGING

Send and receive text with photos or other attachments, in quick text messages or full emails.



From the home screen, touch  **Messaging**.





Drag or flick to scroll.


Touch  to see options.

Tip: To see more messages, flick or drag up.



- To **create** a text message, touch  **Messaging** > **New message** > **Text message**. For options like attaching files, touch Menu .

- To **open** text messages, touch  **Messaging**, then touch the sender's name.

When you see  in the status bar at the top of your screen, flick down the status bar and touch the new message to open it.

- To **respond** to a text message, just open it and enter your response in the text box at the bottom.
- To **forward**, **copy**, and more, touch  **Messaging**, touch the sender's name, then touch and hold the message.

ATTACHMENTS

To send a file in a text message, touch  **Messaging** > **New message**, then touch Menu  > **Attach**.






When you open a message with an attachment, touch **Download** to download it. Touch the downloaded attachment to open it, then touch it again to save it, share it, and more.




Tip: To send and receive large attachments faster, use "**WI-FI NETWORKS**" on page 51.


EMAIL

- To **set up Google** or **Corporate** (Microsoft™ Exchange server) accounts, touch Menu  > **Settings** >


Accounts & sync > Add account. For details, contact the account provider.


To set up standard email accounts (not Gmail™ or Microsoft™ Exchange), touch  >  **Email** and follow the wizard. To add more standard accounts, open  **Email** and touch Menu  > **Accounts** > Menu  > **Add account**. For details, contact the account provider.

- To **open** email, touch  >  **Email** or  **Gmail**. Touch a message to open it.



Tip: Touch Menu  for options like **Refresh** or **Search**.


- To **create** an email, touch  >  **Email** or  **Gmail**, then touch Menu  > **Compose**.

Tip: Touch Menu  for options, like **Attach** or **Add Cc/Bcc**.

Gmail synchronizes with your Google™ account mail, which you can open from any computer at mail.google.com. To stop synchronizing with your account, touch Menu  > **Settings** > **Accounts & sync**, touch your Google account, then uncheck **Sync Gmail**.

VOICEMAIL

When you have a new voicemail,  shows in the status bar at the top of your screen. To hear voicemails, touch  **Dialer** then touch and hold **1**.

If you need to change your voicemail number, in the home screen touch Menu  > **Settings** > **Call settings** > **Voicemail settings**. For your voicemail number or other details, contact your service provider.

