

$RA\mathbb{Z}RM$ BY MOTOROLA



My Verizon

You're now connected to Verizon 4GTTE Lightning fast, lightning strong. For more information, visit verizonwireless.com/4GLTE.

REGISTER at verizonwireless.com/mvverizon.to learn how to use your smartphone:

- 1 Go to My Verizon.
- 2 Click on My Device
- 3 Click on Support
- 4 Click on Interactive "How To" Simulator

My Verizon allows you to manage your account, pay your bill, purchase accessories & more.

Assistance is at your fingertips anytime at verizonwireless.com

Customer Service is at your disposal at 1-800-922-0204 or at any Verizon Wireless Store.

A User's Guide is available on demand—simply download at support.vzw.com/phones. or call 1-800-734-5870 to order a copy.

Note: Devices and software are constantly evolving—the screen images and icons you see here are for reference only

Smartphone Features



Warning: Please use only an approved charging accessory to charge your device. Improper handling of the charging port, as well as the use of an incompatible charger, may cause damage to your device and void your warranty.

Tip: In the unlikely event that your device becomes unresponsive. try a forced reboot—press and hold both the Power key and the Down Volume key for up to 10 seconds. Note: Your home screen might look a little different.



Note: A Subscriber Identity Module (SIM Card) is a "smartcard"

that houses personal information, such as your mobile smartphone number, calling plan, account information, and content, such as contacts, text messages, and call history. The Verizon Wireless 4G Micro SIM Card is compatible with any Verizon Wireless 4G certified device You can move the 4G Micro SIM Card from one device to another and your wireless service will work seamlessly a long as you have a compatible device and service plan. To see which devices are compatible with the Verizon Wireless 4G Micro SIM Card, visit verizonwireless.com/certifieddevice.

Note: This product uses a non-removable battery.

Setting Up Your Smartphone

Assemble & Charge

Set Up & Go



After you power up, create or log into a Google™ account to access all of your Google services. Registration is secure and only takes a few

Tip: To learn more about your smartphone, touch Apps (::) > Help at any time.

Tip: To quickly change some common smartphone settings, flick the home screen right to go to Quick settings. To learn more about each setting, touch (?) in the upper right.



Make & Answer Calls

touch and flick to dunlock.

screen time out (don't press anything).

To make a call, touch I Phone, enter a number. then touch U

To lock the screen press the Power key or let the

Tip: When the screen is locked, touch and flick to Fhone. To answer a call, touch 🕟 and flick to 🕓.

To send an incoming call to your voicemail, touch 🕡 and flick to

To send a pre-set text message to the caller. touch and flick to . Select a message to immediately send it

Tip: When you hold your smartphone to your ear, the display goes dark to prevent accidental touches. When you move the smartphone away from your ear, the display lights up again.

Tip: To silence an incoming call alert, press the Power key or the

Ringtones

Make your smartphone dance to your tune. Choose a ringtone, change the tone, or silence your smartphone.

To personalize your ringtones, touch Apps (:::) > Settings > Sound > Phone ringtone or Default

Unlock & Lock Touchscreen Tip: To quickly change your ringtone, flick the home screen right go to Quick settings, then touch Phone ringtone at the ton To unlock the screen press the Power key then

> To silence your smartphone and make it vibrate for incoming calls, touch the Down Volume key one or more times until the smartphone vibrates and you see ≀ in the status bar

To set a personal ringtone for a contact, touch Apps (:::) > 1 People > contact > Menu > Set

To use a Wi-Fi network for Internet access touch the status bar at the top of the home screen and drag it down Touch the Wi-Fi networks available notification to select a preferred network.

To quickly activate Wi-Fi, flick the home screen right to go to Quick settings, then touch the Wi-Fi power switch to turn it And and scan.

Bluetooth®

To connect your smartphone with a Bluetooth headset or other device, you need to pair with it. You only need to do this once for each device—to connect again, just turn on the device.

1 Make sure the Bluetooth device you are pairing with is in discoverable mode

Note: Refer to the guide that came with the Bluetooth device for details.

2 Flick the home screen right to go to **Quick** settings then touch the Bluetooth power switch to turn it And scan

- 3 Touch the device name to connect
- 4 Touch **OK**, or enter the device passkey (like 0000) to connect to the device. When the device is connected the Bluetooth connected indicator appears in the status bar.

Note: Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive

Backup Assistant™ Plus

Backup Assistant and Media Manager are now Backup Assistant Plus Protect your contacts and access your media when you need it on the go or at home. Go to verizonwireless.com/baplus.

Set Up Your Google™ Account

Now your Gmail™, Google contacts, and Google calendar events can all be loaded to your smartphone automatically.


Record your Google account information. Please keep this document in a safe place.

Username:	(@gmail.co
Password:	

Note: You don't need to have a Google account to use your







This product meets the applicable limit for exposure to radio waves (known as SAR) of I.6 W/kg (FCC & IC). The limits and guidelines include a substantial safety margin designed to assure the safety of al persons, regardless of age and health. The nighest SAR values measured for this device are listed in the regulatory information packaged with your product



Set Up Other Fmail Accounts

Touch Apps (iii) > Settings > Accounts & sync > ADD ACCOUNT > Fmail For account details contact the account provider.

Set Up Voicemail

Dial *86 (*VM) If you hear a greeting touch # to interrupt it, and follow the setup tutorial

Access Voicemail

From your smartphone: Dial *86. When you hear the greeting, touch # to interrupt, follow the prompts.

From any phone: Dial your wireless number. When you hear the greeting, touch # to interrupt, follow the prompts

Note: Voice mailboxes not set up within 45 days will be canceled Your voice mailbox is not password protected until you create a password by following the setup tutorial.

Visual Voicemail

View a list of messages without dialing into a mailbox. Listen or erase with the touch of a button.

Media Store

Play it up with music ringtones wallpapers apps and games. Keep up with Twitter and Facebook®. For details and pricing, go to verizonwireless.com.

Installing Apps

Apps & More

Note: Data charges may apply.

Hundreds of thousands of apps are available to download from Google Play™ Store.

From the home screen, touch Play Store.

To view all of your installed apps, touch Apps (> All Apps > Downloaded.

Verizon Tones

Search, preview, purchase and manage ringback tones and ringtones from your favorite artists all in one place. Go to verizonwireless.com/mediastore.

Verizon Video

Watch full episodes of your favorite shows. Get hundreds of TV shows, live sports and events. Go to verizonwireless.com/video.

Find apps for entertainment, travel, productivity navigation, ringback tones, ringtones, games, wallpaper and more Go to verizonwireless.com/mediastore

Fmail

Check email on the go with popular Internet-based email accounts, including Yahoo!® Mail. AOI ® Mail Gmail™ Windows Live® Hotmail® and Verizon.net

Mobile Web

Take the Internet on the go. You can reach the latest news, get the weather and follow your stocks. From the home screen, touch Browser.

Verizon SafeGuards

Family and Safety Apps & Services. Get the most robust parental controls. Go to verizonwireless.com/safeguards.

Location Based Services

This smartphone can determine its location, which is useful for services such as navigation, shopping and weather For your safety it's defaulted to only acquire your location when you dial 911. To use Location Based Services, go to Apps (iii)

> Settings > Location services

Note: Your wireless device can determine its (and your) physical. geographical location ("Location Information") and can associate Location Information with other data Additionally certain applications, services and programs are capable of accessing. collecting, storing and using Location Information and disclosing Location Information to others. You should use caution when determining whether or not Location Information should be made available to others and you should review any applicable third part policies before providing access. To limit potential unauthorized access to your Location Information, Verizon Wireless offers various mechanisms and settings to manage access to location data. By enabling location settings you are permitting third party access to Location Information through software, widgets or peripheral components you choose to download, add or attach to vour wireless device or through web access, messaging capabilitie or other means and you are authorizing Verizon Wireless to collect use and disclose your Location Information as appropriate to provide you with any location services that you enabled.

V7 Navigator®

Get premium GPS voice pavigations and 3D maps with snoken real-time traffic alerts. Find movie times event info and gas stations. Go to verizonwireless.com/navigator verizonwireless.com/navigator

VZ Navigator® Global

Enjoy the benefits of VZ Navigator when you travel overseas and don't let unfamiliar areas and road signs in different languages keep you from arriving at your destination on time. Go to verizonwireless.com/navigator

Global Ready™

Verizon Wireless keeps you connected around the corner and around the world. For up-to-date information on destinations and rates go to verizonwireless.com/tripplanner verizonwireless.com/tripplanner

Global Travel Program

Voice service available in more than 220 countries and data available in more than 205 countries including more than 150 countries with 3G speed This is the perfect short-term solution for the occasional or infrequent global traveler when traveling outside of the U.S. to GSM locations. For more information go to verizonwireless.com/globaltravel. associated application, product or service.

Customer Information

Verizon Wireless is the mobile carrier associated with this wireless device but many services and features offered through this wireless device are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this wireless device or any non-Verizon Wireless applications, services and products including any personal information you choose to use submit or share with others. Specific third party terms and conditions terms of use, and privacy policies shall apply Please review carefully all applicable terms and conditions and policies prior to using this wireless device and any

Your Wireless Device and Third Party Services:

Hearing Aid Compatibility Information:

terms, conditions and/or charges may apply. Contact your hearing aids for some of the wireless technologies that it service provider for details uses. However there may be some newer wireless. technologies used in this smartphone that have not been tested yet for use with hearing aids. It is important to try
the different features of this smartphone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this without notice or obligation. smartphone for information on hearing aid compatibility. you have questions about return or exchange policies consult your service provider or smartphone retailer.

Copyright & Trademarks

Motorola Mobility III C Consumer Advocacy Office 600 NUS Hwy 45 Libertyville II 60048

www.motorola.com

return your product for repairs, replacement, or warranty service. please contact the Motorola Customer Support Center at: 1-800-734-5870 (United States) 1-888-390-6456 (TTY/TDD United States for hearing

1-800-461-4575 (Canada)

Certain features services and applications are network dependent and may not be available in all areas additional

All features functionality and other product specifications as well as the information contained in this guide, are based upon the latest available information and believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications

Note: The images in this guide are examples only.

MOTOROLA and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings. LLC. DROID is a trademark of Lucasfilm Ltd. and its related companies. Used under license. Google, the Google logo, Google Maps, Google Talk, Google Latitude, Gmail, YouTube, Google Books, Google Docs, Google Goggles, Google Finance, Google Local, Google Maps Navigation Beta, Google Calendar, Google Play and Android are trademarks of Google, Inc. All other product or service names are the

© 2012 Motorola Mobility LLC. All rights reserved.

Caution: Motorola does not take responsibility for changes/modification to the transceiver.

Product ID: DROID RAZR M (Model XT907) Manual Number: 68017155001-A

