

OR PLOROTOM :: GETOIRTE

At a glance

Let's get started. We'll guide you through startup and tell you about your phone.

Note: Software updates happen frequently, so your phone may look a little different.

Remove the back cover

To insert SIM and memory cards, remove the back

Caution: Don't use tools to remove the cover—doing so may damage your phone.

Put in the cards

Your phone might support using two SIM cards.

Caution: Make sure you use the correct size SIM cards and don't cut the SIM cards.



Nano SIM

charge your phone fully, then turn on the power. Select your language and follow the screen prompts to get started.

Charge up & power on.

Put on the back cover. Connect your charger to

wo SIM cards, follow the

Note: Fully charge

your phone before using it.

Press & hold Power until the screen lights

Finish up




Put on the back cover.

or carried, at a distance of 1.0 cm from the body. The

https://motorola.com/sar. To view additional SAR information on your phone, swipe up A > Settings > Legal information > RF information. www.motorola.com/rfhealth

motorola.com







Lock and unlock your phone, navigate your phone and make mobile purchases with just one touch.

- To find lock/unlock settings, swipe up ↑> ⑥ Settings > Security > Fingerprint

Note:



Home screen & settings

From the home screen, you can explore apps, check notifications, speak commands, and more.

- Add a shortcut: Swine up ^ tan and hold an ann then drag it to your home screen.
- Settings: To change your and more swine the fingers. To open me

finger for notification

Swine down with one

Swipe up 🔨 to see

Discover your Moto app

Find it: O Moto

Explore special features designed to save you time and make your day easier.

- Moto Actions: Use gestures as phone shortcuts
- Moto Display: See your notifications
- COMOL Key: Securely log into your

Help & more

Get answers undates and info-

- Help is here: Swipe up \land > Device Help to get your phone.
- walk-through tutorials, how-tos, or FAQs, right on

aa Moto E4 Plus: Get software, user guide

> Play Store to

If your mobile device becomes unresponsive, try a reboot—press and hold the Power button until the screen goes dark and your device restarts.

Before assembling, charging or using your mobile device for the first time.

please read the important product safety and legal information provided

Battery Safety

with your product

the warranty by contacting Motorola at: Motorola Mobility LLC, Attention Customer Service--Warranty Request, 222 West Merchandise Mart Plaza. Suite 1800, Chicago, IL 60654.

Arbitration & Opt-out

relating to any Motorola product will be resolved by binding arbitration instead of in court linless you opt-out. To opt-out, send a written rejection.

STRICTED :: MOTOROLA CO