

## At a glance

Let's get started. We'll guide you through startup and tell you about your phone.

Note: Software undates happen frequently, so your phone may look a little different.

## Remove the back cover & battery

To insert SIM and memory cards, remove the back

Caution: Don't use tools to remove the cover—doing so may damage your phone.

#### Put in the cards

Your phone might support using two SIM cards.

Caution: Make sure you use the correct size SIM cards and don't cut the SIM cards. Don't use tools to remove the battery—doing so may damage your battery or your phone.



# Finish up

Put on the back cover. Connect your charger to charge your phone fully, then turn on the power. Select your language and follow the screen prompts to get started.

For phones that use two SIM cards follow the prompts to set them up.



read me

Caution: Before using your phone, information provided with your product.







# One SIM card If your phone uses one SIM card, insert the SIM card first, then insert the optional microSD card 1 SIM 2. microSD (optional) Micro









https://motorola.com/sar. To view additional SAR information on your phone, swipe up A > Settings > Legal information > RF information. www.motorola.com/rfhealth

motorola.com



#### Home screen & settings

From the home screen, you can explore apps, check notifications speak commands and more

- Add a shortcut: Swine up ^ tan and hold an ann then drag it to your home screen.
- Settings: To change your Wi-Fi, display brightness. and more, swipe the status bar down with two fingers. To open more settings, tap 🌣
- Share your phone: To add a guest user, swipe the status bar down with two fingers and tap (A).



#### Google Duo™

Make and receive video calls with any friend who also has the Duo ann

Find it: Swine up  $\wedge$  > 🖪 Duo

- Start a new video call: Tan then tan a name in your contacts to start the video call.
- Preview incoming calls: Tap > Settings > Knock Knock.
- Change settings: Tap to change the vibration setting, block numbers, and more.

▼⊿ 111:35



#### **Photos**

Take crisp clear photos

- Launch it: From the lockscreen, open your camera by swiping 🔘 up.
- See it: Swipe left for your photo gallery.
- Share it: View a photo or video from your gallery. then tap <

change the focus.

Swipe right for camera

Tap to take a photo

ake multiple shots

 Switch to video camera or panorama mode.

Switch to front camera.

Touch and hold to

**Tip:** Swipe right for effects and settings.

# Help & more

Get answers undates and info-

- Help is here: Swine up  $\wedge$  > ? Device Help to get walk-through tutorials, how-tos, or FAQs, right on your phone.
- Everything Moto C Plus: Get software, user guides. and more at www.motorola.com/mymotoc
- Get apps: Swipe up  $\wedge$  > Play Store to buy and download apps.
- News: Here's how to find us:
- YouTube™ www.voutube.com/motorola
- f Facebook™ www.facebook.com/motorola
- Twitter www.twitter.com/moto
- Section 5. Section 1. Sectio

# Where is my legal, safety and regulatory information?

In order to provide you with better access to this important information, we've made the materials accessible from the phone's settings menu and on the web. Review these materials prior to using your device. To access the materials from a connected phone, go to Settings > Legal information, and select a topic. To access the materials on the web, visit www.motorola.com/device-legal

## **Battery Safety**

Before assembling charging or using your mobile device for the first time nlease read the important product safety and legal information provided with your product

If your mobile device becomes unresponsive, try a reboot—press and hold the Power button until the screen goes dark and your device restarts. Your mobile device uses a removable battery. Only use Motorola Original batteries for safety and hest performance

- . Don't use tools sharp objects or excessive force to insert or remove the battery. This may damage the battery and could cause burning and
- Don't try to take apart or fix your battery. This may damage the battery. and could cause burning and injury
- . Don't crush, bend, or expose your battery or mobile device to heat or liquid. This may damage the battery and could cause burning and injury
- Don't try to dry your mobile device using a microwave oven. conventional oven, or dryer,

### Warning about High Volume Usage

To prevent possible hearing damage, do not listen at high volume levels for long periods.

# Disposal & Recycling

Help do your part! Please don't dispose of mobile devices or electrical accessories (such as chargers, headsets, or batteries) with your household waste. Product packaging and product guides should only be disposed of in accordance with national collection and recycling requirements. For details on approved national recycling schemes and Motorola recycling activities, go to: www.motorola.com/recycling.

#### Usage

This phone supports apps and services that could use a lot of data, so make sure your data plan meets your needs. Contact your service provider for details. Certain apps and features may not be available in all countries.

# Regulatory Information

To view the Regulatory ID (such as FCC ID) for this device, on the phone, go to Settings > Legal information > Regulatory information, or visit www.motorola.com/device-legal

## Warranty

This product is covered by Motorola's limited warranty. To review the warranty on your phone go to Settings > Legal information > Warranty or visit www.motorola.com/device-legal. You may also obtain a copy of the warranty by contacting Motorola at: Motorola Mobility LTC. Attention Customer Service--Warranty Request 222 West Merchandise Mart Plaza Suite 1800 Chicago II 60654

#### **Arbitration & Opt-out**

Except where prohibited by law, any controversy or claim arising out of or relating to any Motorola product will be resolved by binding arbitration. instead of in court, unless you opt-out. To opt-out, send a written rejection notice within 30 days of purchase that includes your name, address, phone number, device, and device serial number, and tells Motorola that you are rejecting this Arbitration provision to: Motorola Mobility LLC, 222 West Merchandise Mart Plaza, Suite 1800, Attn: Arbitration Provision Opt-Out Chicago, II 60654 or arbitrat@motorola.com. For more information on this arbitration provision, on your phone, go to Settings > Legal information > Arbitration and opt-out, or visit www.motorola.com/device-legal

#### Legal Disclaimers

Certain features, services and applications are network dependent and might not be available in all areas; additional terms, conditions and/or charges might apply. Contact your service provider for details. All features functionality, and other product specifications, as well as the information contained in this guide, are based upon the latest available information and believed to be accurate at the time of printing. Motorola reserves the right to correct, change or modify any information or specifications without notice or obligation.

#### Copyright & Trademarks

MOTOROLA, the stylized M logo, MOTO, and the MOTO family of marks are trademarks or registered trademarks of Motorola Trademark Holdings. LLC. LENOVO is a trademark of Lenovo. Google, Android, Google Play and other marks are trademarks of Google Inc. microSD Logo is a trademark of SD-3C, LLC, All other product or service names are the property of their respective owners

© 2017 Motorola Mobility LLC, All rights reserved.

Product ID: Moto C Plus (Model XT1721, XT1723, XT1724, XT1725) Manual Number: XXXXXXXXXXX

Motorola Mobility LLC 222 W. Merchandise Mart Plaza Chicago, II 60654 www.motorola.com