

# MOTOROKR EQ5 Bluetooth Speaker Quick Start Guide

DRAFT 6 - 11/30/07

**Temp Page - To be discarded before printing**  
use this template with A7MotoQSG StructApps



# MOTOROKR™ EQ5

## Quick Start Guide



# welcome


The MOTOROKR™ EQ5 Portable Bluetooth® Stereo Speaker lets you enjoy high definition stereo sound and convenient, handsfree communication in pocket-sized portability through wireless technology.

- **Pocket rocker**—The MOTOROKR EQ5 fits comfortably in your pocket—perfect for sharing your music on-the-move.
- **Small in size, big in sound**—SRS™ WOW HD™ enhanced audio technology provides better width and improved bass and definition control for a rich music listening experience.
- **True untethered mobility**—Bluetooth stereo connectivity cuts the speaker cable, and the rechargeable battery unplugs you from the wall.
- **Calls, too**—With speakerphone functionality and integrated music and call controls, there's no need to reach for your phone. Your music automatically pauses with each call you take or make, and echo and noise cancellation keeps you sounding clear.

**Note:** Before using your speaker for the first time, be sure to review the important safety and legal pamphlet and follow instructions. Periodically review this information so you remember how to safely use your speaker.

# before you begin


Take a moment before you get started to familiarize yourself with the components of your speaker.



# charge it

You'll need to charge your speaker's battery for a minimum of 1 hour using the included Motorola charger.

- 1 Plug the Motorola charger into the charging port on your speaker, as shown.



The Power indicator light turns red when battery is charging. It may take up to 1 minute for the indicator light to turn on. When the speaker's battery is fully charged, the Power indicator light turns green.


- 2 Disconnect the charger.

**Note:** Speaker is functional during charging.

**Note:** This product uses a lithium ion, rechargeable, non-replaceable battery. Under normal use, the expected life of the rechargeable battery is approximately 500 charges.

# turn it on & off

**To turn your speaker on and off**, slide the Power switch to the ON position. The main indicator light flashes 3 times.



# connect wirelessly

**To listen to your music via Bluetooth wireless connection**, as well as make and receive handsfree calls, you need to pair (link) it with your Bluetooth phone and/or music device.

- 1 Turn off any Bluetooth devices previously paired with speaker.
- 2 Turn on the Bluetooth feature on your Bluetooth phone or music device.
- 3 Turn on your speaker.

The main indicator light is steadily lit in blue to indicate the speaker is in discoverable mode.

- 4 Place phone or music device in Bluetooth search mode.

The phone or music device searches for your speaker.

- 5 Select **Motorola EQ5** from search results on your phone or music device.
- 6 Select **OK** or **Yes** to pair your speaker with your phone or music device.
- 7 If prompted, enter **0000** for passkey.



# connect wirelessly

When your speaker successfully pairs and connects with your phone or music device, the main indicator light flashes blue and purple. Music playing from your connected music source is heard on your speaker.

After you have successfully paired your speaker and Bluetooth device, you don't need to repeat these steps. For each use, ensure that your speaker is turned ON and that your device's Bluetooth feature is ON.


## a note on wireless streaming music

You can listen to wireless streaming music received from a Bluetooth phone or music device that supports the A2DP Bluetooth profile.

You can also control music playback from your speaker when the streaming music connection provides Bluetooth AVRCP capabilities. If AVRCP capabilities are not supported by your music player, the EQ5 simply acts as a speaker for the wireless streaming audio.

# connect with wires


**To listen to your music via wired connection**, connect your music device to the Audio port on your speaker using a 3.5mm cable (not included) as shown.



Music playing on your connected music source is heard on your speaker.

# control wireless tunes

Playback controls provided on your speaker can be used when listening to Bluetooth wireless streaming music with remote control capabilities.




**Tap**—play/pause music  
**Press and hold**—stop music

**Tap**—skip to previous track  
**Press and hold**—rewind track

**Tap**—skip to next track  
**Press and hold**—fast-forward track

# crank it up

**To adjust music volume**, use the Volume buttons on your speaker.




When maximum or minimum volume is reached on your speaker, you'll hear a tone.

**Note:** To achieve desired volume, it may also be necessary to adjust the volume on your music player.

# handsfree calls

To make and receive calls, the speaker must be turned on, and a Bluetooth handsfree (HFP) connection must be established with your phone (see “connect wirelessly” on page 7 for details).


You'll use these controls and indicators on your speaker when making and receiving handsfree calls.



# receiving calls

When there's an incoming call, the main indicator light flashes quickly in blue on your speaker and you hear ringing. If music is playing when a call is received, the music either automatically pauses or mutes depending on your music player and connection setup.

**Tap**—answer incoming call




**Press and hold (either button)**—  
reject call

# during calls

When a call is active, the main indicator light slowly pulses in blue on your speaker.

**Tap**—adjust volume up/down one step

**Press and hold**—adjust volume up/down continuously




**Tap**—mute call (main indicator light pulses in purple when mute)

**Tap**—end call

# during calls

When there's a second incoming call, the main indicator light flashes quickly in blue on your speaker and you hear ringing.

**Tap**—answer second incoming call /  
end active call (and resume call on hold) /  
resume call on hold (when remote caller hangs up)



**Press and hold (either button)**—  
reject second incoming call




# making calls

To make a call, you can redial the last dialed number or make a voice dial call (if your phone supports this feature). When making a voice dial call, the microphone on the speaker is enabled and you hear a prompt from your phone.

**Tap**—make a voice dial call (you hear a prompt from your phone)

**Press and hold**—redial last number



# check battery

**To check your speaker's battery charge level**, press and hold both Volume buttons. The main indicator light displays charge status until the Volume buttons are released.

<b>Main Indicator Light</b>	<b>Battery Charge Status</b>
Red	Less than 10% charge
Yellow	Between 10% and 80% charge
Green	More than 80% charge

When your speaker is in a low battery charge state, the main indicator light flashes quickly in red, and a tone is repeated every minute.

# wireless status

The main indicator light on your speaker displays current status of Bluetooth wireless connection(s) to your phone and/or music device.

<b>Main Indicator Light</b>	<b>Wireless Status</b>
steady blue	pairing mode
long blue flash	standby (handsfree connection only)
long yellow flash	standby (streaming music connection only)
long green flash	standby (both handsfree and streaming music connection)
quick blue flash	incoming/outgoing call
long blue pulse	connected on a call
long purple pulse	connected call muted
three green flashes	started/paused music player
long green pulse	music streaming (with handsfree connection active)

# wireless status

<b>Main Indicator Light</b>	<b>Wireless Status</b>
long yellow pulse	music streaming (without handsfree connection active)
long purple pulse	music from wired connection active
three yellow flashes	stopped music player
slow red flash	idle (not connected to a device)


# extra tips

TBD

## European Union Directives Conformance Statement

**CE** Hereby, Motorola declares that this product is in compliance with:

- The essential requirements and other relevant provisions of Directive 1999/5/EC.
- All other relevant EU Directives.



The above gives an example of a typical Product Approval Number.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (to R&TTE Directive) at [www.motorola.com/rtte](http://www.motorola.com/rtte). To find your DoC, enter the product Approval Number from your product's label in the "Search" bar on the web site.

Motorola, Inc.  
Consumer Advocacy Office  
1307 East Algonquin Road  
Schaumburg, IL 60196

**[www.hellomoto.com](http://www.hellomoto.com)**

**[www.hellomoto.com/Bluetoothsupport](http://www.hellomoto.com/Bluetoothsupport)**

1-877-MOTOBLU (Motorola Bluetooth Support)

1-800-331-6456 (United States)

1-888-390-6456 (TTY/TDD United States for hearing impaired)

1-800-461-4575 (Canada)

The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. SRS and WOW HD are trademarks of SRS Labs, Inc. All other product and service names are the property of their respective owners.

© Motorola, Inc. 2007.

Manual Number: 6809519A01-X