



motorola Portable Bluetooth® Hands-Free Speaker



MOTOSTART
T305
Get connected in 4 quick steps.

BEFORE YOU BEGIN

Before using this product, read the Important Safety and Legal Information pamphlet and follow its instructions.

Take a moment before you get started to familiarize yourself with your new T305 Portable Bluetooth Hands-Free Speaker.



1 CHARGE YOUR HANDS-FREE SPEAKER

Charge your hands-free speaker's battery for 2 hours:



Note: Do not place hands-free speaker with clip installed on visor when charging.

- 1 Plug the Motorola charger into the charging port on the end of the hands-free speaker.

The indicator light turns steadily red when the battery is charging and the hands-free speaker is turned off. It may take up to 1 minute for the indicator light to turn on. When the hands-free speaker's battery is fully charged (about 2 hours), the indicator light turns steadily blue.

- 2 Disconnect the charger.

Note: Hands-free speaker is functional while charging; however, when charging the hands-free speaker while turned on, the indicator light does not provide charging status.

2 START BLUETOOTH FEATURE

Your Phone

Your phone's Bluetooth feature is off by default. To use your hands-free speaker, you must turn on the Bluetooth feature in your phone.

For most Motorola phones (at the main menu):

- 1 Press **Menu** > **Settings** > **Connection** > **Bluetooth Link** > **Setup**.
- 2 Scroll to **Power**.
- 3 Select **Change**.
- 4 Scroll to **On**.
- 5 Press **Select** to turn on the Bluetooth feature. The Bluetooth feature remains on until you turn the feature off.

Note: These steps are for most Motorola phones. For other phones, see your phone's user's guide.

3

PAIR

Your Hands-Free Speaker

Before you can use your hands-free speaker, you must pair (link) it with your phone.

Step A - ENSURE HANDS-FREE SPEAKER IS IN PAIRING MODE

To initiate easy pairing, power on hands-free speaker by pressing and holding the Power button until the indicator light becomes steadily lit in purple. Release the button and, after a few moments, the indicator light will be steadily lit in blue to indicate hands-free speaker is in pairing mode.

Indicator Light
(steadily blue
for pairing mode)



If the hands-free speaker does not enter pairing mode, see **TROUBLESHOOTING** for help.

Motorola, Inc.
Consumer Advocacy Office
1307 East Algonquin Road
Schaumburg, IL 60196

www.hellomoto.com
1-877-MOTOBLU
1-888-390-6456 (TTY/TDD United States for hearing impaired)

Guide Number: 6809503A47-A

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. All other product or service names are the property of their respective owners.

© Motorola, Inc. 2006.

3

PAIR *CONTINUED*

Your Phone

Step B - SET YOUR PHONE TO LOOK FOR YOUR HANDS-FREE SPEAKER

For most Motorola phones:

- 1 On your Motorola phone, press  (Menu) > **Settings** > **Connection** > **Bluetooth Link** > **Handfree** > **Look for Devices**.

The phone lists Bluetooth devices it finds.

- 2 Select **Motorola T305**.
- 3 Select **OK** or **Yes** to pair your hands-free speaker with your phone.
- 4 Enter the passkey: **0000**
- 5 Select **OK**.

When your hands-free speaker successfully pairs with your phone, the indicator light changes to flashing blue with quick purple flashes.

Note: These steps are for most Motorola phones. For other phones, see your phone's user's guide.

4

TEST AND USE

Your phone and hands-free speaker are now paired and ready to make and receive calls. To confirm they are operating properly, make a call:

- 1 Install visor clip and place hands-free speaker onto your visor. See "Installing Hands-Free Speaker in Car" on the reverse side of this guide for details.
- 2 On your phone, dial the number you want to call and press the **Send** key.
- 3 If your phone and hands-free speaker are successfully paired, you will hear ringing on the hands-free speaker.

After you have successfully paired your phone and hands-free speaker, you don't need to repeat these steps. For daily use, ensure that your hands-free speaker is turned ON and that your phone's Bluetooth feature is ON.

To save battery power, your hands-free speaker will power down when not connected to your phone for more than 30 minutes.

USING YOUR T305

See
**Features and
Functions Guide**
on the reverse side
for information on
using your T305



TROUBLESHOOTING

My hands-free speaker will not enter pairing mode.

Make sure that any devices previously paired with the hands-free speaker are turned off. If the indicator light is flashing in blue, turn off the other device and wait for 10 seconds. The indicator light becomes steadily lit in blue indicating the hands-free speaker is now in pairing mode.

My phone does not find my hands-free speaker.

Make sure the indicator light on your hands-free speaker is on and steadily lit in blue when your phone is searching for devices (see step 3).

My hands-free speaker worked with my phone before but now they are not working.

Make sure your phone is on and the Bluetooth feature is turned on in your phone (see step 2). If the Bluetooth feature was turned off or was turned on only temporarily, you may need to restart the Bluetooth feature (see step 2) and pair your phone and hands-free speaker again (see step 3).

Support.

If you need more help, contact us at **1-877-MOTOBLU** or visit us at www.hellomoto.com/Bluetoothsupport

Features and Functions Guide

T305
Portable Bluetooth®
Hands-Free Speaker

IMPORTANT:

Be sure to first follow the
MOTOSTART

Quick Start Guide
on the reverse side
of this guide
to complete initial setup
of your T305.


TURNING HANDS-FREE SPEAKER ON AND OFF

To turn hands-free speaker on, press and hold the Power button until the indicator light turns purple. Then, release the button.

Note: Hands-free speaker may take up to 3 to 4 seconds to turn on.

To turn your hands-free speaker off, press and hold the Power button until the indicator light turns purple and then turns off.

To conserve battery power, your hands-free speaker will turn off when not connected to your phone for more than 30 minutes.



INSTALLING HANDS-FREE SPEAKER IN YOUR CAR

Follow these steps to install your hands-free speaker in your car:

- 1 Slide the visor clip onto the mounting bracket on the bottom of the hands-free speaker. To do this, place the loop end first onto the hands-free speaker and slide forward as shown below.



INSTALLING HANDS-FREE SPEAKER IN YOUR CAR

Continued

- 2 Slide the visor clip onto your sun visor.



When installed, the Power button must be facing toward you as shown.

The visor clip is reversible to allow placement of your hands-free speaker on either the front or the back of your car's sun visor.

ADJUSTING HANDS-FREE SPEAKER VOLUME

You can adjust hands-free speaker volume using the Volume buttons. To adjust volume, tap or press and hold button.



Note: Hands-free speaker volume cannot be adjusted during an incoming call.

European Union Directives Conformance Statement

CE Hereby, Motorola declares that this product is in compliance with:

- The essential requirements and other relevant provisions of Directive 1999/5/EC.
- All other relevant EU Directives.

IMEI: 350034/40/394721/9

CE 0168

Type: MC2-41H14

Product Approval Number

The above gives an example of a typical Product Approval Number.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (to R&TTE Directive) at www.motorola.com/rtte. To find your DoC, enter the product Approval Number from your product's label in the "Search" bar on the web site.

MAKING CALLS

Function	Action
Make a voice dial call	Tap the Call button and speak the name after the tone
End a call	Tap the Call button (if a call is on hold, tap twice to end all calls)
Receive a call	Tap the Call button
Reject a call	Tap either Volume button
Redial last call	Press and hold the Call button until you hear a beep

Note: Your T305 supports both Handsfree and Headset Profiles. Accessing call functions depends upon which profile your phone supports. See your phone's user's guide for more information.

MAKING CALLS *CONTINUED*

Function	Action
Answer a second incoming call	Press and hold the Call button (places first call on hold)
Toggle between two active calls	Press and hold the Call button
Mute or unmute a call	Tap both Volume buttons

Note: Some features are phone/network dependent.

Note: When turning on your hands-free speaker during a phone call, audio is transferred automatically to your hands-free speaker (when your hands-free speaker and phone have previously been connected, and your phone supports this feature).

INDICATOR LIGHTS

With the Charger Plugged In

Indicator Light	Status
Steady red	Charging
Steady blue	Charging complete

Note: Charging status not displayed when hands-free speaker is in use.

With No Charger Plugged In

Indicator Light	Status
Off	Power off
Steady purple	Powering up
Steady blue	Pairing mode
Quick red flash	Battery low
Blue with quick purple flashes	Pairing successful
Slow blue pulse	Connected (on a call)
Blue flash	Standby (not on call)
Quick blue flash	Incoming call
Slow purple pulse	Muted

AUDIOTONES

The audio tones provide information about your hands-free speaker status.

Audio Tone	Status
Single high tone when pressing Volume button	Volume at minimum or maximum
Five rapid high tones repeated every 60 sec.	Low battery
No audio indications; deteriorating quality	Out of range
Ring tone	Incoming call
Single high tone	Pairing confirmation
Single low tone	Voice activation
Dual high/low tone (phone dependent)	Voice tag not recognized
Single high tone	End call
Low to high tone	Phone network not available
Two ascending tones	Mute enabled
Two descending tones	Mute disabled