

## **User Manual**

Since this module is not sold to general end users directly, there is no user manual of module.

For the details about this module, please refer to the specification sheet of module.

This module should be installed in the host device according to the interface specification (installation procedure).

The following information must be indicated on the host device of this module;

**[for FCC]**

**Contains Transmitter Module FCC ID: VPYLXRF026**

or

**Contains FCC ID: VPYLXRF026**

**This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.**

\*If it is difficult to describe this statement on the host product due to the size, please describe in the User's manual.

**[for IC]**

**Contains Transmitter Module IC: 772C-LXRF026**

or

**Contains IC: 772C-LXRF026**

The following statements must be described on the user manual of the host device of this module;

[for FCC]

**FCC CAUTION**

**Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**

[for IC]

**This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:**

- (1) This device may not cause interference; and**
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.**

**Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :**

- 1) l'appareil ne doit pas produire de brouillage;**
- 2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.**