

# capello<sup>TM</sup>

**MODEL :CB350**



**User Guide**

## **Contents**


- A. Package Contents**
- B. Important Safety Notifications**
- C. Your CB350**
- D. Power Up**
- E. Get Connected**
- F. Get Listening**
- G. USB Universal Charging**
- H. Trouble Shooting**
- I. Specifications**

## A. Package contents


Your CB350 comes with the following :

- AC Power adaptor
- User guide
- 3.5mm Line In Audio Cable

## B. Important Safety Notifications



**CAUTION:** TO REDUCE THE RISK OF ELECTRIC SHOCK. DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



### **DANGEROUS VOLTAGE:**

The lightning flash with arrowhead symbol, within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



### **ATTENTION:**

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

### **NOTE:**

Any unapproved changes or modifications will void the warranty.

**Section 15.105 Information to the user.**

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment"

**SURGE PROTECTORS:**

It is recommended to use a surge protector when connected to AC power. Lightning and power surges are NOT covered under the product warranty .

## C. Your CB350



### LED Status Indicator

LED	LED Status	Speaker Status
Blue LED	Steady	Power On
	Steady	Connected to Bluetooth device
	Flashes	Music is paused Bluetooth Pairing mode Bluetooth Connecting mode

## D. Power Up

### AC Connection

1. Connect the supplied AC adaptor (DC 12V 1A) to the DC IN jack on the back of your CB350 and plug the other end into a standard wall outlet (100-240V 50-60Hz).
2. Press Power button and the blue LED will illuminate.
3. Your CB350 also includes a USB power jack (5V 0.5A) on the back that can charge most standard USB devices.

## E. Get connected

### STREAMING AUDIO WIRELESSLY FROM DEVICES WITH



You can stream audio wirelessly to your **CB350** from up to 33' away using your iPod touch, iPhone, iPad, Android, laptop, or other A2DP Bluetooth enabled device.

- 1 Press the Power Button to turn on your **CB350** and then press the Pair Button. The Blue LED on your **CB350** will flash.
- 2 On your A2DP-enabled device (check with your device manufacturer to ensure that it supports the A2DP Bluetooth profile), enable Bluetooth, then search for Bluetooth devices and select "**CB350**". If asked for a passcode, enter "0000".
- 3 The Blue LED on your **CB350** will change from flashing to solid, indicating that your Bluetooth device is connected to your **CB350**.

**NOTE:** Press and hold the Pair Button for 3 seconds to disconnect the Bluetooth connection. Your **CB350** will return to pairing mode and the Blue LED will flash.

- 4 Once your Bluetooth device has been paired with your **CB350**, it is simple to reconnect them. Make sure that your **CB350** is on and within range and simply select "**CB350**" from the list on your Bluetooth device (check with your device manufacturer for more information about Bluetooth pairing).

**NOTES:** For the best audio performance, turn the volume on your Bluetooth source device all the way up.

Your **CB350** can only play audio from one source at a time. If your **CB350** is connected to a Line In source, the Bluetooth will not function. Simply unplug the 3.5mm Line In audio cable and press the Pair Button to switch to Bluetooth (if necessary, select "**CB350**" on your Bluetooth device).


## CONNECTING AUDIO DEVICES THROUGH LINE IN

You can also play audio from other devices using a standard 3.5mm Line In audio cable.

Press the Power Button to turn on your **CB350**, then insert one end of a standard 3.5mm audio cable into the Line In jack on the back of your **CB350** and the other end into the Line Out or headphone jack of your audio device.

**NOTE:** For the best audio performance and minimal distortion, avoid turning the volume on your audio source all the way up.

### F. Get In Control



#### Play/Pause

Press the Play/Pause button (▶||) to start playback. Press again to pause playback. The blue LED will flash while the music is paused.

#### Volume Control

Increase or decrease the volume using the VOL + or VOL - buttons.

**NOTE:** The VOL + or VOL - buttons do NOT function when playing music through Line in.

### H. Troubleshooting

Issue	Solution
Distortion	Lower the volume on your CB350 and/or audio device
Not loud enough	Turn up the volume on your CB350 and/or audio source
Intermittent sound	If using Bluetooth, move the audio source and CB350 closer together (within the 33' range)
	Unpair CB350 from your Bluetooth device (check with your device manufacturer for more information about Bluetooth pairing), then re-pair following the steps in the section GET CONNECTED
Cannot play audio via Bluetooth	Confirm your device is A2DP Bluetooth compatible Ensure that both your Bluetooth device and CB350 are not connected to any other devices
	If your CB350 is connected to a Line In source, the Bluetooth will not function. Unplug the 3.5mm Line In audio cable and press the Pair Button to switch to Bluetooth
	Unpair CB350 from your Bluetooth device (check with your device manufacturer for more information about Bluetooth pairing), then re-pair following the steps in the section GET CONNECTED

## I. SPECIFICATIONS

- Class 2 Bluetooth Ranges : 33ft (10m)
- Supported Bluetooth profile : A2DP
- Power: 2 x 3W <10%THD
- Power Adaptor AC Input : 100-240V 50-60Hz
- Power Adaptor DC Output : 12V 1 A
- USB jack DC power output : 5V 0.5A

**NOTE:** Specifications are subject to change without notice.

For operating assistance, please contact customer service at (*email address*) or (*phone no.*).