Phone Performance

Technical Information

133 x 46 x 24mm Dimensions (without

" x " x " antenna)

152g (Li-lon Weight

Transmitting Power

Operating Voltage 3.6V

70 MHz (TX) Cellular Frequency Band

.970 MHz (RX) **90**.99 09.95 MHz MHz (RX) (TX PCS Frequency

Standard Battery 80 mAh ??? (NiMH)

1050 mAh??? (Li-lon) Capacity

Number 6 Channel 832 Memory Loca 99

26 numeric digits per location Memory Capacity

10 letters per location

Battery Care & Disposal

Your phone battery is a sealed unit with no serviceable parts inside; do not attempt to open the case. To ensure the maximum life from your battery, allow the battery to fully discharge at least once a week. To fully discharge the battery, leave the phone turned on until the message

RECHARGE BATTERY

is displayed and the phone shuts itself off. If left unused, a fully charged battery discharges in approximately one month. Store batteries uncharged in a cool, dark, and dry place.

Batteries must be recycled or disposed of properly; they must not be disposed of in municipal waste. Contact local waste management officials for information on the environmentally sound collection, recycling, and disposal of batteries.