

# User Manual


Read instruction before use, keep for future reference and do not throw away.

## MAINTENANCE

After using 5-6 times, or 3-5 days, please clean the product as follow:

Unplug the AC-adapter from the main unit and the power socket, and empty the water tank and using a damp clean cloth wipe the basin. Do not immerse the unit in water. Use a cotton swab to remove excess oil residue. Do not use harsh cleansers or alcohol. Clean regularly.

Note: Pour out the water as below photos show




## PRECAUTIONS

Please check below to avoid malfunction of the unit:

- Do not fill over 300ml water.
- Do not switch on power when the tank is empty.
- Do not touch the ultrasonic vibration plate when using.
- Unplug the unit before maintenance and clean regularly with a damp clean cloth.
- Do not fill water directly, please add water with measuring cup.
- Keep away from direct sunshine heat sources and air conditioners or fans.
- Always keep on flat, moisture-resistant surface, do not place on carpet, duvet or unstable area.
- Keep away from electronic equipment, such as TV and other auto equipment.
- Do not flip the unit when in operation, this may cause water to enter the machine and cause malfunction.
- Product use time : About 10 hours .
- Wait 60 minutes before restart to avoid damage to ultrasonic plate.
- Do not touch any part of the product with wet hands.
- Keep out of reach of children and pets. Children , elder people and person with reduced physical, sensory or mental capabilities should use under guidance.
- If smoke or burning smell is detected, unplug immediately.

## FUNCTION

(11K,12K,13K,17K,21K Same functional except the outer shape )



● This Aroma Diffuser uses ultrasonic waves to instantly vaporize water and essential oil in the tank, to produce a cool, dry fragrant mist.

## PRECAUTIONS

- 1.Product use time: About 10 hours.
- 2.The mist intensity and amount produced will vary and it's normal and should not be considered as a fault.
- 3.Factors that affect above reason include water type, humidity,temperature, air currents.
- 4.Auto power off when water runs out.
- 5.Applies only 100% natural essential oils, if they contain chemical ingredients,flavors or impurities may cause damage.
- 6.Before replacing another essential oil, follow the maintenance part to clean the unit.

## ACCIDENTAL LEKAGE

In the event of the unit being knocked over or tipped during use,please follow the steps as below to avoid malfunction.

- 1.Unplug the unit and remove cover.
- 2.Empty the water from tank.
- 3.Shank the unit gently to drain water, and keep it in a well ventilated area.

## TROUBLESHOOTING

Please refer to the table below in the event of the product operating abnormally:

If product doesn't work well, please refer to the following points before requesting repairs:	
Cannot switch on	Is there enough water in the tank? --Please add water to the tank. Is the power cord connected properly? --Please disconnect, check cables and re-connect carefully.
No mist or abnormal mist	Not enough water? or too much water? --Please add suitable amount of water in the tank, water must never be filled over 300ML (MAX) line. Dirt on the ultrasonic plate? --Please refer to maintenance instructions remove and re-install correctly, so vapors can be released freely. Cover and inner cover are not installed properly? Dirt on the air suction port on the underside of the base? --If too much dust in the air suction port, the mist will be restricted to come out. Just clean it.
Water leakage from product	Cover and inner are not installed properly? --Remove and reinstall correctly, so vapors can be released freely. Low temperature or high humidity? --Under these conditions, the mist may condense quickly into water droplets.

## OPERATION

1. Keep product straighten, remove the upper lid and water cap vertical direction.
2. Please connect the AC adapter to the base of DC socket of the main body via cable guide.
3. Please use the measure cup to supply water(Do not add high temperature water) from the water pipe, pay attention to the filled water level: do not exceed the max line, Please do not add water when the product is working. Drop essential oil water tank vertically.
4. Install the cover of the main body with the original channel, to fall to the vertical direction, rotate the cover to adjust the desired position mouth spray. You must cover the upper cover when you want to use the product.
5. Please connect the AC adaptor with family user power supply socket.
6. Press "MIST" button, choose the time needed, (1H, 3H, 6H or ON continuous spray time). Long press the "MIST" button shown the mist high and low (one sound B is high, sound B is low). If you want to turn it off, please press "MIST" button five times (from 1H, 3H, 6h, ON to OFF).
7. Press "LIGHT" to turn on the light. Adjust the light intensity. (Strong/weak/OFF).
8. If you do not use it for a long time, please drain out the water from tank water, dry and then keep it well. If you want to use it again, please use the neutral detergent to clean the water tank again, then you can use it.
9. When the power is switched on, the initial state of aromatherapy machine is turned off.
10. If lack of water in the tank, even though the MIST switch, aromatherapy machine will automatically turn off.
11. Mist and light off automatically when runs out.

## **Federal Communications Commission (FCC) Statement**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by Xian Chishine Optoelectronics Technology Co.,Ltd may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Radiation Exposure Statement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.