

171mm

104mm

SL074

True Wireless Bluetooth Earbuds + UL Power Bank
Each Headset can be used separately

Congratulations, and thank you for choosing SL074 Bluetooth earbuds. This manual will help you operate the Earbuds, but you should first familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Earbuds. To enjoy your time with our product.

IMPORTANT SAFETY PRECAUTION

Power Bank
WARNING – When using this product, basic precautions should always be followed, including the following:

1. Read all the instructions before using the product.
2. Power bank main unit contains an internal lithium ion battery. Upon initial use or after a prolonged storage period, fully charge it once. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
3. Power banks are not allowed in checked luggage on commercial airline flights. Handle with care and dispose of in accordance to local regulations. Carry-on only.
4. To reduce the risk of injury, close supervision is necessary when the product is used near children.
5. Do not put fingers or hands into the product.
6. Do not expose power bank to rain or snow.
7. Use of a power supply or charger not recommended or sold by power pack manufacturer may result in a risk of fire or injury to persons.

8. Do not use the power bank in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury to persons.

9. Do not use the power bank that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.

10. Do not disassemble the power bank. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury to persons.

11. Do not expose a power pack to fire or excessive temperature. Exposure to fire or temperature above 100°C may cause explosion. The temperature of 100°C can be replaced by the temperature of 212°F.

12. Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.

13. Do not charge the power bank while using the power bank to charge a device. Do not charge the power bank for more than 4-6 hours and do not leave unattended.

14. Disconnect the power bank when not in use.

Earbuds:

1. Please follow the rules described in this manual closely to ensure your safety. Before using this Stereo Earbuds, we would strongly encourage you to read through this user manual.
2. Be more wary of any edges, uneven surfaces, metal parts accessories and its packaging so as to prevent any possible injury or damage.
3. Do not modify, repair or dismantle this Bluetooth Stereo Earbuds. Doing so may result in fires, electric shocks, complete breakdown of this Sport Bluetooth Stereo Earbuds, etc. All of which, are not covered under warranty.
4. Do not use any diluents or volatile liquid to clean the Sport Bluetooth Stereo Earbuds.
5. Do not use the Sport Bluetooth Stereo Earbuds in a hazardous location.

Accessories

Earbuds

- Left
- Right
- Large
- Medium
- Small

Ear Tips

Power bank, USB charging cable, User manual

FIT

In order to get best audio performance, try every ear tip (small, medium and large). The correct seal in your ear to achieve optimal fit and stability.

In order to get better signal distance, please wear earbuds as below pictures showed. Multifunction button round end should towards to mouth direction.

Right ear, Left ear

Graphical Representation

1. Multifunction button
2. Microphone and LED indicator
3. Ear Tips
4. Power bank
5. USB input
6. Power Bank LED indicator
7. USB output

2. Two earbuds will pair to each other automatically, after then one earbuds blue LED flashes slowly, another earbuds LED flashes red and blue alternately, at this time you can see only one "SL074" in your phone.

5 Pairing successful
Master and slaver earbuds LED flash blue slowly after paired successfully, only one "SL074" show in your phone it means connected already. (For the paired previously earbuds and cellphone the earbuds will connect automatically after you power on)

6 Calling
Only that Mast earbuds can hear the voice when calling and only the button of it can work.
Reject call: Double press the control button to reject the incoming call. Press the control button once to answer the incoming call. Press the control button once to end a call.
Redial: Press the control button for 2 seconds to redial the last number you called on your phone.

7 Play music
Master
Play music: Press any one of the Multifunction button once to play music.
Pause music: Press any one of the multifunction button once to pause music.

4 Search and connection
When master earbuds flashes red and blue alternately. Please wait several seconds until only one "SL074" shows in your phone then click to connect. It will pair automatically.

6 Calling
Only that Mast earbuds can hear the voice when calling and only the button of it can work.
Reject call: Double press the control button to reject the incoming call. Press the control button once to answer the incoming call. Press the control button once to end a call.
Redial: Press the control button for 2 seconds to redial the last number you called on your phone.

7 Play music
Master
Play music: Press any one of the Multifunction button once to play music.
Pause music: Press any one of the multifunction button once to pause music.

Warning

1. Do not put the product at the environment of too low or too high temperature for a long time, that may cause deformation, reduce the battery capacity, even shorten service lifetime.
2. Do not use the device when the thunderstorm coming, may cause a failure, and increase the risk of struck by lightning.
3. Do not remove or modified earbuds for any reason, otherwise may lead to earbuds fault or burned, please send earbuds to authorized service center for repairs.
4. Place the device and all accessories out of the reach of children and pets, small parts may be swallowed cause suffocation and serious consequences.
5. Do not put the earbuds into the water.

Troubleshooting

Phenomenon	Reason	Solution
Starting-up failure	low battery	charge for the earbuds
Not pairing after paired	wrong paired	re-pairing
Power bank not charging	power bank not open the charging cable well	check the earbuds if it's well put into
Shut down automatically	low battery	charge for the earbuds
Noise during phone calls	environment disturbance or headphone is too far away from device	change environment or shorten the distance between headphone and device
Low volume of the caller	wrong wear of headphone	adjust headphone position far away from the earpiece signal or shorten the distance between headphone and device
Signal is not well transferring	environment disturbance or headphone is too far away from device	

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices). This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable operation condition without restriction.

Charging

The Bluetooth earbuds and charging cradle must be fully charged before first time to use.

1 Charge the bluetooth earbuds
Magnetic contact recharging, the LED indicator will be solid red when charging, and will turn into blue when the earbuds fully charged.

The indicator will be lighted blue if it's fully charged.

Note:
1. When you playing the music, blue LED light flashed slowly.

2 Charging the power bank
Use the USB cable to connect the adaptor or computer USB socket to charge the power bank.

Single earbuds operation

1 Power on/ Power off
Power on: Long press the Multifunction button for about 3 seconds, the indicator lights red once and you will hear a warning tone.
Power off: Long press the Multifunction button for about 5 seconds, the red LED will light once, then turn off. You also will hear a warning tone.

2 Pairing : first time to use
In power off status, long press the multifunction button for 5 seconds, the indicator lights will flash red and blue alternately, then turn on your cellphone bluetooth, search "SL074" and click connecting, it will pair automatically.

3 Once the earbuds is successfully paired and connected with your mobile phone, you can use it to make a call and listen music.

4 Answer call/End call: Press the control button once to answer the incoming call. Press the control button once to end a call.

5 Reject call: Double press the control button to reject the incoming call.

6 Redial: Press the control button for 2 seconds to redial the last number you called on your phone.

7 Music: short press Multifunction button to pause music/play music.

2 Power off: power off one earbuds only
Press and hold the Multifunction button for 5 seconds the LED will be lighted red and a notification sound will be heard accordingly. Only need to power off one earbuds, the other one will power off automatically if two earbuds connected.

3 Pairing: first time to use
1. In power off status, press and hold the Multifunction buttons of two earbuds at the same time for 5 seconds, the red and blue LEDs will flash alternately, put two earbuds close each other.
Please do not click any one of them to pair.

Stereo earbuds operation

1 Power on
Long press the Multifunction button for about 3 seconds, the indicator lights red once and you will hear a warning tone.

Slaver
Play music: Press any one of the Multifunction button once to next song.

Power bank LED Indicator

State	LED Indicator
Charging	Flash (Red)
Fully charged	LED (Blue)
Working	LED (Blue)

Charge for digital products

Specifications

Items	Specifications
Earbuds Battery	Button cell 40mAh
Bluetooth Version	V4.1
Working voltage	3.7V-4.2V
Microphones sensitivity	-42±3db
Bluetooth frequency brand	2.4-2.48GHz
Bluetooth range	10M
Audio transmission protocols	A2DP/HFP/HSP/AURCP

Power Bank Model SL074
Item No 2746
Input DC 5.3V/1000mA
Maximum input DC 5.3V/1000mA, 60mA, 60mA
Output 7.4Wh, 3.7V / 2000mAh
Battery/Cell capacity 5.5Wh, 5V / 1100mAh
Product capacity 0-45°C for Charging
Operating temperature 0-50°C for Discharging

EN CAUTION: Risk of Fire and Burns, don't open, crush, disassemble and dispose of in fire. Accessible surfaces held or touched for short periods only. Don't heat above 50 °C or incinerate. Follow Manufacturer's Instructions

FR: DANGER: risque d'incendie et de brûlures, ne pas ouvrir, démontez, écraser ni jeter au feu. Ne pas toucher ou tenir les surfaces accessibles sur une longue durée. Ne pas chauffer au-dessus de 50 °C. Instructions de fabricant suivre

Notice
1. The Mobile can not find the earbuds if the 2746 is not paired. Please ensure the earbuds is in pairing mode before you search it. (red and blue lights flashing alternately)
2. If the earbuds can not find any pairing device for five minutes, it will power off automatically.

Warm tips
You must select a qualified adapter to charge this product. You must charge the bluetooth earbuds if it has not been used for more than 3 months.

FCC ID: 2ABHA0019
Bluetooth Listing Declaration ID:XXXXXX
Made in China

Front

Back