D-94B Manual

Getting started

Please read this manual before operating your bluetooth, and keep it for future reference. Please read all Satety precautions before using your blue tooth to ensure safe and proper use

Bluetooth overview: Power switch ON/OFF 1)V- Previous(Long press for Volume Down) 2)V+ Nexrt(Long press for Volume Up) 3)Answer phone/Play/Pause 4)LED light Indicator 5)Aux-in 6)DC 5V(USB Port, only for charge)

Charging the Bluetooth

The product has a rechargeable built-in battery which is nonremoveable .Make sure the Bluetooth is fully charged before using it for the first time. To charging the Bluetooth, Connect it with the micro usb port cable provided into any available USB DC 5V power source(PC or Adapter).This charging time is 2 hours and it can play back for 3.5 -4 hours

Bluetooth Mode

To ensure you get the best performance from your Bluetooth.

Keep the distance between your Bluetooth and device as small as possible and avoid placing your body or other objects in the signals path.

- 1. Switch it on, the LED light indicator turns blue flashing fast and you will head the remind sound: Bluetooth/pairing.
- 2. Turn on the Bluetooth function of your device, and you will find the User Name :Mr.D, click on to make connecting.
- 3. Press the button V- or V+, it will go to song selection previous or next, long press V- or V+, will be volume up or down.
- 4. When using Bluetooth function to play music from mobile phone ,if there is a coming ,the music will be mute automatically. After the call ended. The music will play again.

Hand Free Assistant Function

Make sure the Bluetooth is pairing to your mobile as well.

1. Making a call

To dialing a number from your cell phone.then music will be paused until Hanging up.

2. Answering a call.

Press the button to answer a call when there is a incoming call. Music is paused until Hanging up.

Enjoy your hands free call with this Bluetooth.

Micro SD Music Playing(with micro SD card slot) Insert the Micro SD into the card slot, then the product will play the music automatically. Short press will stop the music playing. Press V- or V+ button to select previous or next song. Long press will volume down or up.

AUX-IN

AUX-IN Mode:

Power on, blue light is lit. Connect 3.5 mm cable to Bluetooth and plug the 3.5 mm connector to your music device, it will transfer to the AUX IN mode directly.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class C digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.