Instruction Manual for Transmitters TX-337A-R01 and TX-3377A-R01

BATTERY INSTRUCTIONS:

- 1. Remove battery compartment covers on vehicle and transmitter with a coin or a screwdriver.
- 2. Install "AA" alkaline batteries in the battery compartments with positive (+) and negative (-) ends matching the compartment markings.
- 3. Replace the battery covers.

OPERATION:

- 1. START: Move switch on bottom of vehicle to "ON" position.
 The vehicle will automatically begin reverse and turning action.
- 2. FORWARD: Squeeze trigger on handle.
- 3. REVERSE & TURNING: Release trigger.
- 4. STOP: Move switch to "OFF" position.

FOR BEST RESULTS:

- 1. Do not mix old and new batteries.
- 2. Do not mix alkaline, standard or rechargeable batteries.
- 3. Use alkaline batteries only.

Remark: Modifications not authorized by the manufacturer may void users authority to operate this device.