


# Explanation of remote control buttons

The remote control buttons have different functions depending on the active mode. To change the mode, press the desired button on the right side of the panel (Input/Output mode select buttons).

To check which mode is selected, just press any button other than the Input/Output select buttons and the active mode will light up.





**R2-D2 SOUND** About R2-D2 sound (R2-D2 sounds are emitted by a special internal speaker inside R2-D2): When the power is ON, etc., R2-D2 sounds will be made automatically. Also, R2-D2 sounds can be made by pressing the R2-D2 sounds button. Each time the button is pressed, R2-D2 sounds are randomly played.













### Power switch

- Turns projector power ON/OFF
- Turns DVD drive power ON/OFF
- Turns power of iPod inserted in slot ON/OFF
- When this button is pressed while in DVD mode, it changes to MEDIA mode.

**Button used when adjusting sound**

Button	In Projector Mode	In DVD mode	In iPod mode	In DVI-I mode	In Media mode
		(MUTE R L)	(MUTE R L)		(MUTE R L)
	—	Volume UP/DOWN	—	—	Volume UP/DOWN

**Convenient functions**


Button	In Projector Mode	In DVD mode	In iPod mode	In DVI-I mode	In Media mode	
	—		—	Page down (next page when using PowerPoint)	—	
	Cursor ("move cursor up" when using Office application)		—	Cursor ("move cursor up" when using Office application)	—	
	Page Up ("previous page" when using Office application)		—	Page Up ("previous page" when using Office application)	—	
	Cursor ("move cursor left" when using Office application)		—	Cursor ("move cursor left" when using Office application)	—	
	ENTER ("enter" when using Office application)	Instant chapter, track selection See "Direct Accessing chapter/track via the remote control" on pg. 37	—	ENTER ("enter" when using Office application)	—	
	Cursor ("move cursor right" when using Office application)		—	Cursor ("move cursor right" when using Office application)	—	
	STATUS (display projector status) instant display		—	—	—	
	—		—	Cursor ("move cursor down" when using Office application)	—	
	AUTO ( automatic adjustment of phase, tracking, position) *4		—	—	AUTO ( automatic adjustment of phase, tracking, position) *4	—
	FM CH - (FM channel down)		Repeat	—	—	—
	FM CH + (FM channel up)		Repeat	—	—	—
	FM ON/OFF (FM broadcast start/stop)		Change multiangle	—	—	—


Remote control and stand setup

\*4 Only possible in VGA input.



## Broadcasting sound with FM transmitter

Use the “FM transmitter” to broadcast FM signal and play R2-D2 audio through component stereos and FM radios.




Select 


Press 

Select the channel you wish to play audio on with  and .

USA / EU / JAPAN	
CH1	88.1MHz
CH2	88.3MHz
CH3	88.5MHz
CH4	88.7MHz
CH5	88.9MHz




Indicator Display :Pg.72



Projector screen

Selected channel will be shown on the indicator and your screen.

Change the channel (frequency) of component stereos or FM radios to the channel you are broadcasting from.

Pressing  switch ON and OFF.

**POINT** Due to the broadcast output power limited by law, the distance from which you can listen at a good sound quality is limited.

**POINT** The speaker sound from R2-D2 is still ON although the FM transmitter is broadcasting. To turn off the sound from R2-D2, refer to page 28 under ‘mute’.

Additional control features of R2-D2



For the best FM signal reception from an FM transmission signal of R2-D2, use an indoor FM antenna instead of external FM outdoor antenna and/or cable TV line.



Turn OFF the SPDIF of DVD when using FM transmitter. Refer to page 69.