

by PIN2.

-Credit

You can view a credit. If the call cost goes beyond the limit, the phone cannot be used to make a pay call.

-Set Credit

You can set limits to the total call cost. This function sustained by PIN2.

-Tariff

This option allows you to view a tariff.

-Set Tariff

You can set the tariff. This function sustained by PIN2.

-Sent SMS

You can view the number of sent SMS.

-Clear Message Count

You can clear up the number of sent SMS.

Call Timers

This function notes several call time.

-Last Call

Show duration of the last call in hours, minutes & seconds.

-Total Time

Show the total duration of all types of calls.

-Outgoing Time

Show the total duration of all outgoing calls.

-Incoming Time

Show the total duration of all incoming calls.

-Clear Timers

Clear all duration data.

Options

-Clear Call list

Delete all the records of missed, received and dialed calls.

-Set Call list

Show the records to be missed, received and dialed calls. You can check into either on or off.

Call Info 25 **LIRD**

Phone Book

You can create a personal phonebook by saving phone numbers and accompanying names. An easy way to make calls is by recalling the phone numbers and names saved in your phonebook.

In Standby mode, press down key directly to this menu.

Find Number

Retrieves the phonebook by name or position.

-By name

This menu allows you to find an entry by a person's name. There two methods for you to search the needed number.

1. You can input the whole name or the initial.

2. If you are not sure of the name, press the

key directly to enter the PBK, and then

press the navigation key up or down to find

the number you needed. After the number

appeared, You can dial it.

Press the key to select,

• Call

You can call the number directly.

• Copy Number

Copy the saved in phone number to SIM or copy the saved in SIM number to phone.

• Edit

Edit the data of the number.

• Add Number

You can select the number add to SIM or add to mobile.

• Delete

Delete the data of the number.

• Send SMS

Edit message to send.

-By position

This menu allows you to find an entry by the position.

Add Number






This menu allows you to create a new entry.

Enter the PBK menu, select "Add Number",

press the key to select "Add new?" or the

dialed number which not saved.

LIRD 26 Phone Book

1. Press the  key select new number to "Add to SIM " or " Add to phone " .
2. Press the  key Select, edit the number.
3. Press the  key Enter, put in the name.
4. Press the  key Enter, it will appoint the save position automatically. You can also enter the position yourself, press the  key, "saved" appear.

Delete Number

-Delete All

This option allows you to delete all entries in the Phonebook memory.

• Delete number in SIM

Delete all the Phonebook memory in the SIM card.

• Delete number in me

Delete all the Phonebook memory in the phone.

-Delete One by One

Delete the Phonebook memory one by one.

Copy Number

This option allows you to copy the selected entry from the phone memory to the SIM memory and vice versa.

-Copy All

• Copy from card

Copy all the Phonebook memory from the SIM card to the phone.

• Copy to card

Copy all the Phonebook memory from the phone to the SIM card.

-Copy One by One

Copy the Phonebook memory one by one.

Options

-Browse Field

• Browse All

Browse all the phone numbers

• Browse SIM

Only browse the numbers in the SIM card.

• Browse Me

Only browse the Phone numbers in the phone.

Phone Book 27 

-Sort Order

• By name

Array the phone numbers by spelled order of the names.

• By position


Array by the position of the phone numbers.

-Refuse Call

• Accept Option

Refuse call from all, from list, from no one, or from refuse

• Refuse List

Press the  key to add refused number.

• Accepted List

Press the  key to add accepted number.


-Ask to Save

Open or close the save function of the new number.


-Fixed Dialing

This function supplied by your service provider, it needed PIN2 code.

Groups

Groups phonebook entries under a name in order to organize them in an orderly manner. Enter the PBK menu, choose "Groups", press the  key to enter the group management function menu.

-Add new ?

Firstly named the new group, press the  key "enter", select group member, group ring, group icon. You can delete the group, rename it, examine it's status.

There five groups inside the phone, family, friends, workmates, VIP, Others, the user can edit and modify them.

My Numbers

This feature allows you to save your SIM card phone number in your SIM card memory. You can save two phone numbers and one fax number.

Memory Status

This option allows you to check how many



entries are currently stored in the phonebook (SIM card, phone memory and groups). Also you can see the capacity of each memory.

Fixed Number


Only can be supplied by your network provider.

Sound Settings


Bell Signals

- **All Voice Calls**
Choose ring type for all voice calls.
- **Bell Volume**
Turn up or down with the navigation key.
- **Turn Silent on/off**
Press the  key to mute or activate the ringers.
- **Vibrating Alert**
 - On**
Activate vibrating alert.
 - On if Silent**
Activate vibrating alert only when the ringer is mute.
 - Bell after Vibration**
A ringer sounds on after vibration.
 - Off**
Deactivate vibrating alert.
- **Increasing Bell**
Press the  key to activate or deactivate an increasing ringer.

Message Alert

- **-Melody Type**
Choose melody type for message alert.
- **-Turn Silent On/off**
Press the  key to mute or activate the ringers.
- **-Alert Volume**
Turn up or down with the navigation key.
- **-Vibrating Alert**
 - Only Vibration On**
* Activate vibrating alert.
 - Vibration off**
* Deactivate Vibrating alert.
 - Vibration And Bell**
Activate vibrating alert and Bell together.

Key Sound

- **-Turn Silent On/Off**
Press the  key to mute or activate the ringers.

-Key Volume

In this option, you can use the Navigation keys to set the keypad tone volume.

-Key Tone Type

Choose KeyTone Type.

Power On/Off

Choose ring type for power on/off.

Lower Battery Alarm

Activate or mute the warning tone of low battery.

Network Alarm

To activate or deactivate the sound for landing the network.

Phone Settings

Time and Date

This menu allows you to set time and date as well as customize the ways they are displayed on the idle screen.

-Time Setting

- **Set Time**
Set current time.
- **Time Format**
You can select the 12 hours or 24 hours format.

-Date Setting

- **Set Date**
Set the current date.
- **Date Format**
You can set the date format.

-Screen Setting

- **Clock Style**
Select the clock style: Digital, Analog.

-Set Time Zone

You can look for the current time to the city




time which you select the time for each city around the world.

Set Language

You can select the language : English, Automatic, Chinese.

Input

You can choose different input method you like.

All input methods will be displayed on the screen, press the up or down navigation key, and then press  key or  key to select/no select the input method. Finally press the  key to confirm.

KeyPadLight

Select On or Off to activate or deactivate Key Light.

Auto Key lock

Select On or Off to activate or deactivate the Auto Key lock function.

Display

-Set Wallpaper

From the menu, you can select different wallpapers you like.

-Desktop Setting

From the menu, you can select different contents displayed on the Main LCD.

-Light

From the menu, you can select the light mode: Auto on/off, on, 30 second.

-Contract

• Screen Contrast

From the menu, you can adjust the lightness on the Main LCD by the navigation key.


Call Option

-Minute minder

If you select on, you can check the call duration by beep sound every minute during a call.

-Forward Calls

• All Voice Calls

press the  key to enter this menu.

Activate: Activating the corresponding service.

Cancel: Deactivating the corresponding service.

Get status: Checking the status of the corresponding service.

• When Busy, No Reply, Not Reachable,

Data Calls, Fax Calls

You can refer to "All Voice Calls".

• Check All

View the status of all voice calls.

• Cancel All

Cancel the status of all voice calls.


-Call Waiting

When your phone are on line and another call comes in, an incoming call number and a callwaiting message will appear to remind you. Choose to Answer, Busy or Release & Answer. (This function need network support.)



-Restrict Calls

The display of all **Outgoing, all Incoming, Outgoing Intl, Inc when Roam, Outg Intl Roam** can refer to "All Voice Calls" of "Forward Call".

• Cancel All

Press the  key, enter phone code, cancel all restrict.

• Change Passwd

Press the  key, enter the current password before you can specify a new twice, and then press the  key to confirm the modification.

Networks

With this function your phone can search for different networks automatically. If the network you apply is forbidden, the phone will search for another network automatically. This operation will register your phone the most appropriate network automatically.

Security

-Card Lock

The Card lock helps prevent unauthorized use of your SIM card.

• Protection

Enable/Disable the card lock function. Choose On or Off. Before disabling or enabling this feature, you must enter your PIN code.

• Change PIN2

You can change PIN2 the same way as you change your PIN.

-Phone Lock

The phone lock helps prevent unauthorized use of your phone. When this function is on,

you must enter your phone lock code every time you power on your phone.

• **Protection**

Select On or Automatic or Off. When changing the phone lock status, you must enter your phone lock code.

• **Change Code**

You can change the phone lock code the same way as you change your PIN.

Master Reset

Resetting the phone restores the default value of all of the menu settings. Enter the phone code to activate it.

Accessories

This menu allows you to use your phone as your assistant providing you with various convenient features, such as calendar, calculator, world time and so on.

Alarm Clock

You can set the phone to alarm at a specified time at this menu.

-Alarm Clock1

• **Set New Time**
You can set the time (Hour and Minute) for the alarm, press the key to confirm.

• **Set Alarm Signal**

You can set ring type for alarm clock.

• **Set Alarm Mode**

Choose time for the alarm clock to work in one week.

• **Set Alarm Prompt**

Set Alarm Prompt.

Alarm Clock2

The same as Alarm Clock1.

Calculator

Using this feature, you can use the phone as a calculator. The calculator provides the basic arithmetic functions: addition, subtraction, multiplication and division.



key: dot .



key: negative




key: Clear the input number or symbol;



key: Calculate the result.

Calendar

-View today

Shows the note of the first schedule on the today. Press the navigation key up or down to read other schedule, Press the  key to delete the schedule that is being read.

-View all tasks

You can see all tasks have been set. Press the navigation key up and down to read the schedule.