



Groups

You may classify the names and numbers stored in the phonebook into different groups, and this will facilitate you in managing and operating the phonebook. You send messages to the group and select the ring tone for the group, etc. This phone provides 2 fixed groups: "SIM" and "No group". All numbers in your SIM card will be placed in the "SIM" group, and the "No group" is used to store the numbers of the mobile phone (numbers already existing in other groups will not be placed in this group). In the interface of the list of groups, press  key to spring up the menu, you may choose the increase groups. And when you choose "send SMS", you may edit a new message and send it to all members of the group.

The number of groups in this mobile phone, including the 2 fixed groups, is restricted to 12. After adding new groups, you may add number to the new group (the numbers must be stored in the mobile phone).

Memory



-Preferred memory

After entering "Preferred memory", "Phone" and "SIM" will appear on the display. Press  key to choose one of them as the default memory of the phonebook.

-Capacity


After entering "Capacity", use of the mobile phone and SIM card will appear on the display.

Own number

After entering "Own number", the list of number of the phone will appear. Choose one of them and press  key to display detailed information of the function. Press  key to return the immediate upper menu.

Sound settings

Your mobile phone provides several settings for ring tone and the manner of display so as to facilitate you in setting ring tone of the mobile phone on the basis of different events and environments. First, please make personalized setting for the ring tone on the basis of your preference, then you only need to set the manner of alerting on the basis of your actual need.


In standby mode, press  key to enter the main menu, select "Sound settings", then you will be able to set the sound and the manner of alerting. And in standby mode, you may also enter the "Sound settings" menu by pressing the left navigation key.

Select ringtone


You may set "Incoming ringtone", "Message ringtone" and "Alarm" through this function.

Adjust volume

Press up-down or left-right navigation key to make adjustment to the volume of the ring

tone, press  key to save your setting.

Prompt mode

You may set the manner of alerting for incoming calls and messages. In standby mode, you may also press and hold  key to do quick change between the manner of alerting.

Manners of alerting available are: "Ring", "Vibration", "silent" and "vibrate then ring".

Keypad tone

You may choose to turn on or turn off key tone.

Alert tone

You may choose to set whether the phone gives out alarming tone when it is in shortage of power or the mailbox is full.




SMS sent tone

You may choose whether alerting tone will be given out when the phone completes transmission of messages, etc.

Settings

Time and date

-time and date

In standby mode, press  key to enter the main menu, select "settings", "Time and date" by turn. After selecting "Time and date", the mobile phone will enter the interface for setting time and date. Press the up-down and left-right navigation key to select correct time and date; press  key to confirm. The display will enter the interface for setting time and date; similarly, press the up-down and left-right navigation key to select correct date and press  key to confirm, and when "setting saved" appears on the display, your setting of the time and date is complete.



If the battery is taken out of the mobile phone, or the battery is out of power for a long time, then when you insert the battery once again or start the mobile phone after charging the mobile phone, you may need to set the time once again.

-Time format


You may choose to set the time in a AM/PM (12-hour) or 24-hour system.


Display settings


-Wallpaper

You may set the background picture, i.e., wallpaper, of the phone in standby mode. In standby mode, press  key to enter the main menu, select "Settings", "Display settings" and "Wallpaper" and the phone will enter into the interface for setting wallpaper. Press the up-down and left-right navigation key to choose the wallpaper that you favor, and press  key to confirm. When "Setting saved" appears on the display, your wallpaper setting is complete.

-Backlight



You may choose to set the opening and time options of the backlight of your mobile phone. In standby mode, press  key to enter the main menu. Select "Settings", "Display settings",


Settings 33 

"Backlight" and enter the interface for the setting of the time of backlight, press the up-down navigation key to scroll to the option that you choose, press  key to confirm. When "Setting saved" appears on the display, your wallpaper setting is complete.

-Contrast



You may change the contrast of the inner and outer displays.

In standby mode, press  key to enter the main menu, select "Settings", "Display settings", "Contrast" and enter the interface for the setting of contrast. Select the display that you want to set, press left/right navigation key to scroll to the setting that you want, press  key to confirm. When "Setting saved" appears on the display, your wallpaper setting is complete.



In standby mode, press  key to quickly enter the menu of display setting.

Keypad light

You may choose to set the options of the key light of mobile phone.

In standby mode, press  key to enter the main menu, select "Settings", "keypad light" by turn to enter the interface for setting the key light. Press the up-down navigation key to select "On", "Off during 8:00-17:00" or "Off", press  key to confirm. When "Setting saved" appears on the display, your wallpaper setting is complete.

Refuse call

This function provides the function for rejecting calls from specific telephone numbers. If you do not want to receive a call, you may add the number to the incoming call firewall. If the number calls you once again, "the number you dialed is busy" will appear in his/her earpiece. In standby mode, press  key to enter the main menu, select "Setting" and "Refuse call" by turn to enter the interface for setting the firewall, press  key to spring up the menu:


-Add number

You may add the numbers that you will reject to the incoming call firewall.

-Activate


This will start the incoming call firewall.

Call settings

In standby mode, press  key to enter the main menu; select "Settings" and "Call settings" by turn to enter the call setting menu. In standby mode, you may also press the navigation key to enter the call setting menu.


-Call divert

To use the call transfer function, you may transfer the incoming call to another number, for example, to the number of your voice mailbox. Please make inquiry to you service providers for relevant details.

Unconditional divert: Select "unconditional divert" menu, press  key to enter all sub-menus of "unconditional divert", you may choose to cancel all past settings for call transfer and turn the transfer function off. Select the sub-menu of "Deactivate", you may cancel all past settings on call transfer, and close the function of call transfer. Select the sub-menu of "Status", "service


already effective+ transfer number" or "service cancelled" will appear on the display.

Divert if busy, Divert If no answer, Divert if unreachable: Please refer to **unconditional Divert** for specific options.

Cancel all divers: Select "Cancel all divers" menu, press  key to cancel all call divers functions.


-Call waiting


Use call waiting function, you may know of the existence of another call when you are in the process of a call, and choose whether or not to receive the call.


Select "Call waiting" menu, press  key to enter the function of "Call waiting", you may choose to Deactivate or Activate the call waiting function.

-Call barring

By using call restriction function, you may realize the "barring" function for incoming calls and outgoing calls meeting the conditions, where restricted incoming calls and outgoing calls will pull through.



All outgoing calls: Select "All outgoing calls" menu, press  key to enter all sub-menus of "All outgoing calls".


Select the sub-menu of "Activate", then you will be reminded to enter "Barring code", after entering correct password, press  key to confirm, then all calls dialed out will be restricted, i.e., restricted call.

Select the sub-menu of "Deactivate", then you will reminded to enter "Barring code", after entering correct password, press  key to confirm, then all calls dialed out will be returned to normal, i.e., the restriction is cancelled.




Select the sub-menu of "Status", then "Service already activated" or "Service deactivated" will appear on the display.

All int'l outgoing, All incoming calls: Please refer to **All outgoing calls** for specific selection.

Cancel all barring: Select the menu of "Cancel all barring", press  key, "Cancel all?" will appear on the display, press  key, and the call restriction function will be cancelled, and the display will alert you to


enter "Barring code", and after entering correct password, press  key to cancel "Call barring" function and return to the "call barring" sub-menu.

-Speaker volume

Press the left-right navigation key to adjust the call volume, and press the right navigation key, the volume will be increased, and press the left navigation key, the volume will be reduced. Press  key to confirm your choice, or press  key or  key to cancel your choice and return to the menu. During a call, the side key may also be used to increase or reduce the volume, and during the adjustment, the volume of the call will change accordingly without pressing other keys for confirmation or cancellation, and in 2 seconds, the mobile phone will automatically enter into the interface of call.

-Open to answer


After entering the interface of receiving calls by opening the fold, you may set "Activate". When you have new incoming calls, the call

will be connected when the fold is opened. If it is "Deactivate", then the call will be connected after pressing .

-Minute reminder


After entering the interface of minute alert, you may set "Activate", then during call, you will hear a alert tone at intervals (the length of the time may be set), and when you set "Deactivate", then this function will be turned off.

-IP access number

Enter the interface for editing IP access number, enter corresponding IP access number and press  key to confirm, then the IP access number setting is complete. IP access number is fixed to be 5-digit, and if the IP access number is 00000, then the IP access number will have no effect.

Security settings


This function provides security protection for your mobile phone and personal information to ensure that your mobile phone is safely used.

In standby mode, press  key to enter the main menu, select "Settings" and "Security settings" by turn and enter the interface for security setting.

-SIM card lock

Select SIM card locking to enter the interface for locking the SIM card.

Settings: You may set the status of SIM card lock, select "Activate" and enter correct PIN, then the SIM card lock function will be started.

Change PIN: You may change your PIN. Press the original PIN, enter new PIN for 2 times, and press  key to confirm.


-Phone lock

Select the Phone lock to enter the interface for locking the mobile phone.


Settings: After this function is on, when you switch you phone on, the system will remind

you to enter "Phone password", and the mobile phone will be started only when correct mobile phone password is entered (the original password is 0000).

lock now: If in standby mode you leave your mobile phone and do not want your mobile phone to be operated by others, start this function. After entering correct phone password, the mobile phone will return to the operation interface.

Change phone number: After entering this menu, you may change phone password. It will first alert you to enter the original phone password, and after entering correcting phone password, the phone will alert you to enter your new password. Press  key to confirm after entering new password, then the password of the mobile phone will be complete.

Network settings

In standby mode, press  key to enter the main menu, select "Settings" and "Network settings" by turn, and enter the function menu of "Network settings".

-Change frequency

You may change your current operation frequency.

-Existing networks

You can search and display the list of networks that your mobile phone is in.

-Settings

You may set the manner of your registered network and network searching.


-Preferred networks

You may add or delete your prioritized networks.

-New network



To show the list of new networks of your mobile phone in current environment.

Language

In standby mode, press  key to enter the main menu, select "Settings" and "Language" by turn and enter the menu of "Language". You may choose among the available operation .

Restoring factory settings

This function may restore some functions to factory settings.



In standby mode, press  key to enter the main menu, select "Settings" and "Restoring factory setting" to enter the function menu of restoring factory settings, enter mobile phone password and press  key to confirm, then the system will automatically restore certain functions to factory settings.

Accessories

This mobile phone provides you with many practical accessories, such as: Alarm, calendar, calculator, and stopwatch, etc. to facilitate your daily use.

Alarm






When set, the mobile phone will give out alarm tone or vibration at fixed time everyday to remind you.

In standby mode, press  key to enter the main menu, select "Accessories" and "Alarm" by turn and enter the interface for setting time. After selecting the time that you want, press  key to confirm. When the alarm clock is set, you may choose to turn off the alarm clock or reset the time of the alarm clock.

Games


This mobile phone provides 2 games: Tetris and Submarine war. See help file of the mobile phone for the method of operation.

Calendar

In standby mode, press  key to enter the main menu, select "Accessories" and "Calendar" to enter the calendar menu, display the calendar, the cursor will rest on current date. Press the left-right navigation key to move the cursor. Press  key to enter the menu for the selection for date. Enter the date that you want to make inquiry about, press  key to confirm, and the calendar will show information of the date that you are inquiring about, press  key to return to the immediate upper tool menu, press  key to return the standby interface.

Calculator

The calculator in the mobile phone has simple function of addition, deduction, multiplication and division.

In standby mode, press  key to enter the main menu. Select "Accessories" and "Calculator" by turn. Then enter the first