

**-Credit**

You can view a credit. If the call cost goes beyond the limit, the phone cannot be used to make a pay call.

**-Set Credit**

You can set limits to the total call cost. This function sustained by PIN2.

**-Tariff**

This option allows you to view a tariff.

**-Set Tariff**

You can set the tariff. This function sustained by PIN2.

**-Sent SMS**

You can view the number of sent SMS.

**-Clear Message Count**

You can clear up the number of sent SMS.

**Call Timers**

This function notes several call time.

**-Last Call**

Show duration of the last call in hours, minutes & seconds.

**-Total Time**

Show the total duration of all types of calls.

**-Outgoing Time**

Show the total duration of all outgoing calls.

**-Incoming Time**

Show the total duration of all incoming calls.

**-Clear Timers**

Clear all duration data.

**Options****-Clear Call list**

Delete all the records of missed, received and dialed calls.

**-Set Call list**

Show the records to be missed, received and dialed calls. You can check into either on or off.

Call Info 25 **GIRD**

**Phone Book**

You can create a personal phonebook by saving phone numbers and accompanying names. An easy way to make calls is by recalling the phone numbers and names saved in your phonebook.

In Standby mode, press down key directly to this menu.

**Find Number**

Retrieves the phonebook by name or position.

**-By name**

This menu allows you to find an entry by a person's name. There two methods for you to search the needed number.

1. You can input the whole name or the initial.

2. If you are not sure of the name, press the

 key directly to enter the PBK, and then

press the navigation key up or down to find the number you needed. After the number appeared, You can dial it.

Press the  key to select,

**• Call**

You can call the number directly.

**• Copy Number**

Copy the saved in phone number to SIM or copy the saved in SIM number to phone.

**• Edit**

Edit the data of the number.

**• Add Number**

You can select the number add to SIM or add to mobile.

**• Delete**

Delete the data of the number.


**• Send SMS**

Edit message to send.






**-By position**

This menu allows you to find an entry by the position.

**Add Number**

This menu allows you to create a new entry. Enter the PBK menu, select "Add Number", press the  key to select "Add new?" or the dialed number which not saved.

**GIRD** 26 Phone Book

1. Press the  key select new number to "Add to SIM " or " Add to phone " .
2. Press the  key Select, edit the number.
3. Press the  key Enter, put in the name.
4. Press the  key Enter, it will appoint the save position automatically. You can also enter the position yourself, press the  key, "saved" appear.

#### **Delete Number**

##### **-Delete All**

This option allows you to delete all entries in the Phonebook memory.

- **Delete number in SIM**

Delete all the Phonebook memory in the SIM card.

- **Delete number in me**

Delete all the Phonebook memory in the phone.

##### **-Delete One by One**

Delete the Phonebook memory one by one.

#### **Copy Number**

This option allows you to copy the selected entry from the phone memory to the SIM memory and vice versa.

##### **-Copy All**

- **Copy from card**

Copy all the Phonebook memory from the SIM card to the phone.

- **Copy to card**

Copy all the Phonebook memory from the phone to the SIM card.

##### **-Copy One by One**

Copy the Phonebook memory one by one.

#### **Options**

##### **-Browse Field**

- **Browse All**

Browse all the phone numbers

- **Browse SIM**

Only browse the numbers in the SIM card.

- **Browse Me**

Only browse the Phone numbers in the phone.

**Phone Book 27** 

##### **-Sort Order**

- **By name**

Array the phone numbers by spelled order of the names.

- **By position**


Array by the position of the phone numbers.

##### **-Refuse Call**


- **Accept Option**

Refuse call from all, from list, from no one, or from refuse

- **Refuse List**

Press the  key to add refused number.

- **Accepted List**

Press the  key to add accepted number.


##### **-Ask to Save**

Open or close the save function of the new number.


##### **-Fixed Dialing**

This function supplied by your service provider, it needed PIN2 code.

#### **Groups**

Groups phonebook entries under a name in order to organize them in an orderly manner. Enter the PBK menu, choose "Groups", press the  key to enter the group management function menu.

##### **-Add new ?**

Firstly named the new group, press the  key "enter", select group member, group ring, group icon. You can delete the group, rename it, examine it's status.

There five groups inside the phone, family, friends, workmates, VIP, Others, the user can edit and modify them.

#### **My Numbers**

This feature allows you to save your SIM card phone number in your SIM card memory. You can save two phone numbers and one fax number.

#### **Memory Status**

This option allows you to check how many



entries are currently stored in the phonebook (SIM card, phone memory and Groups Status). Also you can see the capacity of each memory.

**Fixed Number**


Only can be supplied by your network provider.

**Sound Settings**

**Bell Signals**

- **All Voice Calls**  
Choose ring type for all voice calls.
- **Bell Volume**  
Turn up and down with the navigation key.
- **Turn Silent on/off**  
Press the  key to mute or activate the ringers.
- **Vibrating Alert**
  - On**  
Activate vibrating alert.
  - On if Silent**  
Activate vibrating alert only when a ringer is mute.
  - Bell after Vibration**  
A ringer sounds off after vibration.
  - Off**  
Deactivate vibrating alert.
- **Increasing Bell**  
Press the  key to activate or deactivate an increasing ringer.

**Message Alert**

- Melody Type**  
Choose melody type for message alert.
- Turn Silent On/off**  
Press the  key to mute or activate the ringers.
- Alert Volume**  
Turn up and down with the navigation key.
- Vibrating Alert**
  - **Only Vibration On**  
Activate vibrating alert only.
  - **Vibration off**  
Deactivate Vibrating alert.
  - **Vibration And Bell**  
Activate vibrating alert and Bell together.

**Key Sound**

- Turn Silent On/Off**  
Press the key to mute or activate the ringers.
- Key Volume**  
Allows to set the keypad tone for adjusting environment.

**-Key Tone Type**

Choose KeyTone Type.

**Power On/Off**

Choose ring type for power on/off.

**Lower Battery Alarm**

Allows the open or close the warning tone of low battery.

**Network Alarm**

Press the key to activate or deactivate the sound for landing the network.

**Phone Settings****Time and Data**

This menu allows you to set time and date as well as customize the ways they are displayed on the idle screen.

**-Time Setting****• Set Time**

Set current time.

**• Time Format**

You can select the 12 hours or 24 hours format.

**-Date Setting****• Set Date**

Set the current date.

**• Date Format**

You can set date format.

**-Screen Setting****• OutScreen Setting**

Select the clock style: Analog, Digital, Neome, Greeting.

**• Clock Style**

Select the clock style: Digital, Analog.




**-Set Time Zone**

You can look for the current time to the city time which you select the time for each city around the world.

**Set Language**

You can select the language used to display information: English, Automatic, 简体中文.

**Input**

You can choose different input method that comes along with the message and PBK. All input method will be displayed on the screen, press navigation up or down, and then press  key or  key to select/no select the input method. Finally press the  key to confirm.

**KeyPadLight**

Check into On or Off to activate or deactivate Key Light.

**Auto Key lock**

Check into On or Off to activate or deactivate Auto Key lock.

## Display

### -Set Wallpaper

From the menu, you can select different wallpapers you like.

### -Desktop Setting

From the menu, you can select different contents displayed on the Main LCD.

### -Light

From the menu, you can select the light mode: Auto on/off, on, 30 second.

### -Contrast

- **Screen Contrast**  
From the menu, you can adjust the lightness on the Main LCD with the navigation key.
- **External Screen**  
From the menu, you can adjust the lightness on the Children LCD with the navigation key.

## Call Option

### -Clam Shell Answer


You can receive an incoming call when only opening folder. Choose On or Off.

### -Minute minder

If you select on, you can check the call duration by beep sound every minute during a call.

### -Forward Calls

- **All Voice Calls**

press the  key to enter this menu.

**Activate:** Activating the corresponding service.

**Cancel:** Deactivating the corresponding service.

**Get status:** Checking the status of the corresponding service.

- **When Busy, No Reply, Not Reachable, Data Calls, Fax Calls**  
These menus can refer to "All Voice Calls" .

- **Check All**

View the status of all voice calls.

- **Cancel All**

Cancel the status of all voice calls.


### -Call Waiting

When you are speaking over your phone and another call comes in, an incoming call number and a callwaiting message will appear to remind you. Choose to Answer, Busy or Release & Answer.  
(This function need network support.)



### -Restrict Calls

The display of **all Outgoing, all Incoming, Outgoing Intl, Inc when Roam, Outg Intl Roam** can refer to "All Voice Calls" of "Forward Call ".

- **Cancel All**

Press the  key, enter phone code, cancel all restrict.

- **Change Passwd**

Press the  key, enter the current password before you can specify a new twice, and then press the  key to confirm the modify.

## Networks

With this function your phone can search for different networks automatically. If the network you apply is forbidden, the phone will search for another network automatically. This operation will register your phone the most appropriate network automatically.

## Security

### -Card Lock

The Card lock helps prevent unauthorized use of your SIM card.

- **Protection**

Enable/Disable the card lock function. Choose On or Off. Before disabling or enabling this feature, you must enter your PIN code.

- **Change PIN2**

You can change PIN2 the same way as you change your PIN.

### -Phone Lock

The phone lock helps prevent unauthorized use of your phone. When this function is on,

you must enter your phone lock code every time you power on your phone.

- **Protection**

Select On or Automatic or Off. When changing the phone lock status, you must enter your phone lock code.

- **Change Code**

You can change the phone lock code the same way as you change your PIN.

**Master Reset**

Resetting the phone restores the default value of all of the menu settings. Enter the phone code to activate it.

## Accessories

This menu allows you to use your phone as your assistant providing you with various convenient features, such as calendar, calculator, world time and so on.

**Alarm Clock**

You can set the phone to alarm at a specified time at this menu.

**-Alarm Clock1**

- **Set New Time**

You can set the time (Hour and Minute) for the alarm, press the key to confirm.

- **Set Alarm Signal**

You can set ring type for alarm clock.

- **Set Alarm Mode**

Choose time for the alarm clock to work in one week.

- **Set Alarm Prompt**

Set Alarm Prompt.


**Alarm Clock2**

The same as Alarm Clock1.


**Calculator**

Using this feature, you can use the phone as a calculator. The calculator provides the basic arithmetic functions: addition, subtraction, multiplication and division.

 key: dot .


 key: negative

 key: Clear the input number or symbol;

 key: Calculate the result.

**Calendar**

**-View today**

Shows the note of the first schedule on the today. Press the navigation key up or down to read other schedule, Press the  key to delete the schedule that is being read.

**-View all tasks**

You can see all tasks have been set. Press the navigation key up and down to read the schedule.