

## **EASY INSTALLATION:**

1. One transmitter operates all three receivers.
2. Plug the receiver/switch into a 3-wire indoor outlet, then plug the lights or device to be switched into the receiver/switch.

Make sure that there is power to the outlet that the receiver/switch is plugged into.

3. The device must be mounted in a vertical position with the receptacles facing downward.
4. Red indicator light is lit when the indoor unit is powered on.

## **BATTERY INFORMATION AND REPLACEMENT:**

1. On the bottom of the remote use your finger to slide out the battery holder.
2. Remove the used battery and insert a new CR2032 Lithium 3-volt battery with the “+” polarity mark facing up.
3. Slide the battery holder back inside so that it sets in place.
4. Dispose of old battery properly.

## **WARNING:**

Keep batteries away from children and pets.

Follow the battery manufacturer’s safety and usage instructions.

- Remove battery if product is to be left unused for a long time.
- Clean the battery contacts prior to battery installation.
- Do not dispose of batteries in fire. Batteries may explode or leak.

NOTE: In case of power failure, the system will need to be reset.

## **Remote Control**

1. Press: “ON” button of “A” on the transmitter, the No. A Receiver is power ON continuously and the red indicator will come on.
  - 1.1. Press “OFF” button of “A”, the No. A Receiver is power OFF instantly and the red indicator will go out.
2. Press: “ON” button of “B” on the transmitter, the No. A Receiver is power ON continuously and the red indicator will come on.
  - 2.1 Press “OFF” button of “B”, the No. B Receiver is power OFF instantly and the red indicator will go out.
3. Press: “ON” button of “C” on the transmitter, the No. A Receiver is power ON continuously and the red indicator will come on.
  - 3.1 Press “OFF” button of “C”, the No. C Receiver is power OFF instantly and the red indicator will go out.

## **CAUTION**

- Risk of Fire.
- DO NOT PLUG IN MORE THAN THE RATED LOAD.
- This is a Radio Frequency (RF) Device. Therefore the range of the transmitter is affected by obstructions, walls and other electronic devices.

## **ATTENTION: INSTRUCTIONS FOR PROPER USE**

- USE WITHIN THE ELECTRICAL RATING MARKED ON THE PRODUCT
- RATED 125 VOLTS
- Inspect periodically

## **WARNING:**

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

