

Scan QR code to download APP



Smart Cable Lock  
Model: O16


Instruction

### Register an account

Register an account  
(mobile phone No., Email, Wechat, Facebook)

- Step 1: New user need to register (use Wechat or Facebook account to sign in directly)
- Step 2: Input your mobile phone No. or email
- Step 3: Set password
- Step 4: Click the register button to sign in successfully

Only mainland China mobile phone No. to register




### Add the lock

- Step 1: Add the lock (Scan the QR code or Search by Bluetooth)
- Step 2: Turn on mobile phone's Bluetooth - click the right lock on main screen - and then click button on the lock (red light blinks) to activate Bluetooth signal to match with APP.
- Step 3: Bluetooth connects successfully and blue light blinks (battery level will be shown when done)
- Step 4: Click the button "unlock"

Battery level

Remove binding




### Add friends

Attention: Authorization to unlock requires both parties to be friends in the APP. The first account of adding the lock approve as administrator of the lock facility. The administrator can authorize unlock privileges to other friends under this account (unlock via Bluetooth).

- Step 1: Click the white button "..." on the home page
- Step 2: Click "My friends"
- Step 3: Click "+" on the top right corner to add friends

Add by QR code: Scan others' QR code (Personal Center---My QR code)

Add by account: input others' APP account




### Authorize to unlock

Attention: Authorization to unlock requires both parties to be friends in the APP, authorized account can only unlock via Bluetooth.


- Step 1: click the home page of which lock you want to authorize
- Step 2: click the button of "Authorization"
- Step 3: Find the friend you want to authorize in your friend list after entered the page, click "Batch" to start on and off authorization

Authorization is a permanent authorization that can be granted and cancelled at any time.



### Using record

- Step 1: Click the home page of which lock you want to use
- Step 2: Click the "usage records" at the bottom
- Step 3: Find the unlocking and sharing records.



**FCC Statement**  
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
- Reorient or relocate the receiving antenna.  
- Increase the separation between the equipment and receiver.  
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
- Consult the dealer or an experienced radio/TV technician for help.  
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.  
  
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.